

Stresses at the wellbore wall (Kirsch[PP]+Kirsch[S])

$$\begin{cases} \sigma_{rr} = \Delta P \\ \sigma_{\theta\theta} = \sigma_{11} + \sigma_{22} - 2(\sigma_{11} - \sigma_{22})\cos 2\theta - 4\sigma_{12}\sin 2\theta - \Delta P \\ \tau_{\theta z} = 2(\sigma_{23}\cos \theta - \sigma_{13}\sin \theta) \\ \sigma_{zz} = \sigma_{33} - 2\nu(\sigma_{11} - \sigma_{22})\cos 2\theta - 4\nu\sigma_{12}\sin 2\theta \end{cases}$$