

OTIS ESCALATOR MODEL-NPE SERVICE MANUAL

Equipment manual - Otis Model-NPE - Generated from Operio source markdown

This manual provides service and diagnostic protocols for the Otis Model-NPE Heavy Duty Escalator.

1. Safety Interlocks and Error Codes

Diagnostic: Escalator Stop and Fault Codes

If the escalator halts operations, check the primary diagnostic display located inside the upper truss access panel.

- **Error Code E-01 (Broken Drive Chain):** Drive chain safety switch tripped. Escalator is locked. Do not attempt restart. Verify chain integrity.
- **Error Code E-04 (Comb Plate Impact):** Comb plate safety switch tripped. Indicates an object (e.g., shoe, luggage strap) is caught between the steps and the comb plate.
- **Troubleshooting:**
 1. Turn off main power key-switch.
 2. Inspect comb teeth for obstruction; clear any debris.
 3. Verify comb plate alignment sensor clearance (must be 3.5mm).
 4. Reset switch and restart using the key-switch.
- **Error Code E-09 (Skirt Safety):** Object caught between step and side skirt panel.