## **CONFIDENTIAL**

## Table of Contents

| 1. C                          | Overview       |  | 1  |
|-------------------------------|----------------|--|----|
| 1.1                           | Overview       |  |    |
| 1.2                           | Function       |  |    |
| 1.3                           | Reference      |  | 3  |
| 1                             | .3.1 Stand     | dard                                   | 3  |
| 1                             | .3.2 Relat     | ted Document                           | 3  |
| 1.4                           | Restrictions   | S                                      | 4  |
| 1                             | .4.1 Knov      | wn issues                              | 5  |
| 1                             | .4.2 Close     | ed issues                              | 8  |
| 1.5                           | Notice         |  | 9  |
| 2. T                          | erminology.    |  | 10 |
| 3. C                          | Operating En   | vironment                              | 11 |
| 3.1 Hardware Environment      |                |  |    |
| 3.2 Module Configuration      |                |  | 11 |
| 3.3 State Transition Diagram  |                |  | 12 |
| 4. E                          | External Inter | rface                                  | 13 |
| 5. Iı                         | ntegration     |  | 14 |
| 5.1                           |                |  |    |
| 5.2                           | •              | Procedure                              |    |
| 5.3                           | IPMMU set      | tting                                  | 15 |
| 5.3.1 Device tree description |                |  | 15 |
| 5                             | 5.3.2 How      | to enable IPMMU support                | 16 |
|                               | 5.3.2.1        | For R-Car H3 Ver.2.0/Ver.3.0 (R8A7795) | 18 |
|                               | 5.3.2.2        | For R-Car M3 (R8A7796)                 | 23 |
|                               | 5.3.2.3        | For R-Car M3N (R8A77965)               | 26 |
|                               | 5.3.2.4        | For R-Car E3 (R8A77990)                | 28 |
|                               | 5.3.2.5        | For R-Car D3 (R8A77995)                | 30 |
|                               | 5.3.2.6        | For R-Car V3U (R8A779A0)               | 32 |
|                               | 5.3.2.7        | For R-Car V3H (R8A77980)               | 38 |
| 5.4                           | Option Sett    | ing                                    | 41 |
| 5                             | 5.4.1 Mod      | lule Parameters                        | 41 |
| 5                             | 5.4.2 Kern     | nel Parameters                         | 41 |