CONFIDENTIAL

Table of Contents

1. C)vervi	ew	1
1.1	Ove	rview	1
1.2	Fund	ction	1
1.3	Refe	erence	2
1	.3.1	Standard	2
1	.3.2	Related documents	3
1.4	Rest	rictions	3
1.5	Noti	ice	3
2. T	`ermin	ology	4
3. S	ystem	Configuration	5
3.1 Hardware Environment			
3.2	Soft	ware Configuration	6
4 E		on	0
4.1		J Hotplug	
-	.1.1	CPU Offline	
	.1.2	CPU Online	
		J Idle	
		J Freq	
	.3.1	DVFS	
-	.3.2	Frequency and AVS support	
4.4		time PM	
4.5	•	em Suspend to RAM	
4.6		rmal Management	
-	.6.1	IPA	
	.6.2	EMS	
4	.6.3	System Shutdown	30
5. E	xterna	al Interface	31
5.1	CPU	J Hotplug	32
5	.1.1	CPU Hotplug definition	32
5	.1.2	CPU Hotplug operation	
5.2	CPU	J Idle	33
5	.2.1	CPU Idle definition	33
5	.2.2	CPU Idle operation	
5.3	CPU	J Freq	
	.3.1	CPU Freq definition	
5	.3.2	CPU Freq operation	
5.4	Syst	em Suspend to RAM	
	.4.1	System Suspend to RAM definition	
5	.4.2	System Suspend to RAM operation	
5.5		time PM	
	.5.1	Runtime PM Definition	
	.5.2	Runtime PM operation	
5.6		rmal management (IPA/EMS)	
	.6.1	Thermal management (IPA/EMS) definition	
	.6.2	Thermal management (IPA/EMS) operation	
	.6.3	Disabling thermal management (IPA/EMS) operation	
		U	

CONFIDENTIAL

6. In	ntegration	46
	Directory Configuration	
7. R	leference	48
7.1	Design Note for System Suspend to RAM support	48
7.2	Power management function depend on PMIC	51