## **CONFIDENTIAL**

## Table of Contents

1. Overvi	ew	1
1.1 Ove	erview	
1.2 Refe	erence	
1.2.1	Standard	
1.2.2	Related Document	
1.3 Res	trictions	2
1.4 Not	ice	2
2. Termin	nology	4
3. Operati	ing Environment	5
-	dware Environment	
3.2 Mod	dule Configuration	6
3.3 Stat	re Transition Diagram	
4. Functio	on	11
4.1 Con	nnected Device	11
4.2 Inpu	ut / Output Format	
4.3 Inpu	ut Resolution	
4.4 Clip	pping and Scaling	
4.5 Har	dware Parameters	
4.6 Fiel	d order	23
4.7 Initi	ialization Process	24
4.8 Cap	ture Process	
4.8.1	Capture Control (enqueue / dequeue buffer)	
4.8.2	Start or Stop Capturing	
4.8.3	Pause capturing	
4.8.4	Changing Output Image Size	27
4.8.5	Changing CROP of Captured Image	27
5. Externa	al Interface	28
5.1 Vid	eo for Linux Two API	
5.1.1	ioctl(VIDIOC_QUERYCAP)	
5.1.2	ioctl(VIDIOC_REQBUFS)	
5.1.3	ioctl(VIDIOC_G_FMT)	
5.1.4	ioctl(VIDIOC_S_FMT)	
5.1.5	ioctl(VIDIOC_TRY_FMT)	
5.1.6	ioctl(VIDIOC_QUERYCTRL)	
5.1.7	ioctl(VIDIOC_G_CTRL)	
5.1.8	ioctl(VIDIOC_S_CTRL)	
5.1.9	ioctl(VIDIOC_CROPCAP)	
5.1.10	ioctl(VIDIOC_G_CROP)	
5.1.11	ioctl(VIDIOC_S_CROP)	
5.1.12	ioctl(VIDIOC_QUERYBUF)	
5.1.13	ioctl(VIDIOC_DQBUF)	
5.1.14	ioctl(VIDIOC_QBUF)	
5.1.15	ioctl(VIDIOC_STREAMON)	
5.1.16	ioctl(VIDIOC_STREAMOFF)	
5.2 Med	dia Controller API	36

## **CONFIDENTIAL**

5.2.1	Show current routing	36
5.2.2	Activate/Deactivate a link	37
5.2.3	Configuring the pipeline and propagate format	38
5.2.4	Deactivate all active links	40
6. Integra	tion	41
6.1 Dire	ectory Configuration	41
6.2 Inte	gration Procedure	42
	Video Capture Driver [R-Car H3 / M3 / M3N / E3 / D3 / V3U / V3H]	
	I2C Driver	
6.3 Opt	ion Setting	43
6.3.1	Module Parameters	
6.3.2	Kernel Parameters	46