

Preparation for Fasteners			
Fasteners		Door or Frame	Drill Sizes
Standard	#14 type "A" S.M. screw Arm: 1-1/4" (32mm) Closer: 2-3/4 (70mm)	Wood	3/16" (4.30mm)
	1/4-20 machine-screw	Metal	drill: #7 (.201" dia) tap: 1/4-20
	Sleeve nuts & bolts (Standard with tri-pack closer)	Hollow-Metal	9/32" (7.00mm) through; 3/8" (9.50mm) on door or transom-face opposite to closer
		Aluminum or Wood	3/8" (9.500mm) through
Optional	Through-bolts and grommet-nuts	All	9/32" (7.00mm) through; 3/8" (9.50mm) dia. x 3/8" (9.500mm) deep on door or transom-face opposite to closer

TEMPLATE NUMBER	REV	DATE
7377-0101	5	06/26