

Aiming Methods

Date: 2026-01-12

Long wires radiate strongest off the wire ends when length > 1 lambda.

Orient the wire so the main lobes point toward the target area.

Use modeling to find lobe angles at your operating frequency.

For short wires (< 0.5 lambda), broadside radiation is dominant.

Confirm direction with on-air reports or beacons.