

Deployment Techniques

Date: 2026-01-12

Survey the site for clear spans, trees, and safe anchor points.

Keep the wire away from power lines and public access areas.

Use a throw line or mast to elevate the far end.

Tension gently to reduce sag while avoiding overstress.

Route feed line downward to reduce RF on the line.