

# Assembly Procedures

Date: 2026-01-12

Cut wire to calculated length and add extra for end terminations.

Install end insulators and tie-off points with figure-eight knots.

Attach feed point insulator and strain relief.

Connect matching transformer or balun and verify continuity.

Label the feed line and store the antenna coiled without kinks.