

# Orientation Techniques

Date: 2026-01-12

Place the wire as high as practical to reduce ground loss.

Avoid routing parallel to metal structures that detune the antenna.

Keep the feed line at right angles for several meters if possible.

Use a consistent compass bearing for repeatable deployments.