

## ATmega32U4-Breakout nack

**Assembly Instructions** 


by @dop3j0e



Except for steps 1 and 3 (and 8, duh!;), orientation never matters.




In case you mix up the LEDs: The green one's chip looks red-ish, and the red one's chip looks black.





The switches are easier to solder while the pullups are not yet in place.






After this, flip the board and tack it down (double-sided tape against the  $\mu$ C) so it doesn't jiggle.







Solder the pins first. Check the solder joints. Then solder down the shield.