
First, open the setting tool, select the printer connection mode, click Test communication, and enter the setting parameters after success.



Second, select Download, click Browse to select the program file, click Update, you can see the update status in the lower left corner.

