



## Connectivity

Connect Your Device

## **Communication Protocols**

Overview

Hologram Cloud Messaging

Direct IP

SpaceBridge IP Tunnel

SMS via Hologram Cloud

Circuit-Switched SMS

## Nova

Dach

Getting Started with Nova

Hologram CLI and Python SDK

Open-Sourced Hardware

## Overview

This guide discusses the options for sending data to and from your cellular device. In the table below, *Outbound* refers to sending data from the device, and *Inbound* refers to outside data reaching the device.

METHOD	OUTBOUND	INBOUND	PRICING	DASH Support	NOVA Support
Hologram Cloud messaging	Yes	Yes	Data	Yes	Yes
Direct IP	Yes	Reply only	Data	No	Yes