

- REFER TO preferenceV2_dispenser_trough.sldprt FOR UNSPECIFIED DIMENSIONS

- THE RAMP ANGLE DEPENDS ON THE LENGTH OF THE TROUGH AND MUST BE CHANGED IF THE LENGTH IS ADJUSTED

$ \begin{array}{c cccc} \text{TOLERANCES} & & \text{X.X} & \pm & 1 \\ \text{UNLESS} & & \text{X.XX} & \pm & 0.5 \\ \text{NOTED:} & & \text{X.XXX} & \pm & 0.05 \\ \text{UNITS: MM} & & \text{X.X}^\circ & 2^\circ \\ \end{array} $	UNIVERSITY OF COLORADO BOULDER DONALDSON LAB
MATERIAL ZORTRAX ULTRAT	DESCRIPTION TROUGH
REMOVE SUPPORT AND DEBUR	dispenser_trough REV A SHEET 1 of 2

