

AURORA

HM-7 Ultrasonic Humidifier

Owner's Manual

Model HM-7 · 4.5 L Cool Mist

Contents

1. Setting up · page 3
2. Control panel and indicator lights · page 4
3. Cleaning and descaling · page 5
4. Troubleshooting · page 6
5. Specifications · page 7

1. Setting up

Place the Aurora HM-7 on a flat, level surface at least 30 cm from walls and furniture. Do not place it directly on carpet or on wooden furniture that could be damaged by moisture.

Filling the tank

Lift the tank straight up by the recessed handle. Turn it over, unscrew the cap on the base, and fill with cool tap water. Do not add essential oils directly to the tank — use the dedicated fragrance tray described on page 4.

Refit the cap firmly and lower the tank back onto the base. A small amount of water will release into the reservoir; this is normal.

2. Control panel and indicator lights

The HM-7 has four touch controls: Power, Mist (low / high), Ionizer, and Timer. Three indicator lights sit above them.

Light	Colour	What it means
Refill	Red	The water tank is empty. The unit has stopped misting. Refill the tank (page 3) and
Ionizer Active	Amber	The ion generator is running. Press and hold the Ionizer button for three seconds to
Descale	Blue, flashing	The unit has run for 120 hours since the last descaling. See page 5. The light clears

Fragrance tray

Pull out the small tray on the left side and add a few drops of essential oil to the felt pad. Never put oil in the water tank.

3. Cleaning and descaling

Hard water leaves a chalky mineral scale on the ultrasonic disc. Left to build up, it reduces mist output and shortens the life of the unit. Removing it is called **descaling**, and the HM-7 reminds you with the flashing blue Descale light (page 4).

Descaling, every two weeks

1. Unplug the unit and lift off the tank.
2. Fill the reservoir with a 50/50 mix of white vinegar and cool water, enough to cover the ultrasonic disc.
3. Leave it to stand for 20 minutes. The acid loosens the mineral deposits without scrubbing.
4. Tip out the solution. Wipe the disc gently with the supplied soft brush — never a metal tool, which will scratch the disc.
5. Rinse the reservoir twice with clean water before refilling.

For heavy buildup, citric-acid descaling powder may be used in place of vinegar. Do not use bleach or abrasive cleaners.

4. Troubleshooting

Symptom	Likely cause and fix
No mist, Refill light on	Tank empty. Refill (page 3).
Little or no mist, tank full	Mineral scale on the disc. Descale the unit (page 5).
White dust on nearby surfaces	Minerals in hard tap water. Use distilled water, or descale more often.
Unit is noisy or rattles	Tank not seated. Lift it off and lower it straight back down.
Blue light keeps flashing	Descale reminder. It clears only after a completed descale (page 5).

5. Specifications

Tank capacity: 4.5 litres

Run time: up to 30 hours on low, 12 hours on high

Coverage: rooms up to 40 m²

Power: 24 W, 100–240 V AC

Auto shut-off: when the tank runs dry

Dimensions: 20 × 20 × 30 cm

Aurora is a fictional brand. This manual was written as a sample document and describes no real product.