
DOT ONE MEDIA

Producer Packet

Running the broadcast: graphics, episodes, live

A DECLARED STANDPOINT
Confidential · for Dot One Media staff

YOUR ROLE

Producing the broadcast

You run the studio: the on-air graphics, recorded episodes, and going live. This packet is the hands-on version; the handbook and the printable Live Broadcast Guide have the full detail.

Signing in

Use your newsroom login at **editorial.dot1.media**; you need broadcast permission (Producer or Owner) to drive graphics, publish episodes, and go live.

Equipment & signal flow

The chain: **Cameras** → **ATEM switcher** → **OBS (adds graphics)** → **recording or live stream**. Graphics reach OBS from the portal.

- Cameras (Canon C50 / C400) → HDMI into ATEM inputs 1–4.
- ATEM Mini Pro ISO switches cameras and mixes audio; one USB-C cable carries the program to the computer as a webcam.
- A mic goes into the ATEM's 3.5 mm input; OBS takes the ATEM feed and adds the overlay.

Note: Cameras, ATEM, and OBS must all run the same frame rate (all 1080p 30, or all 60).

Cameras, audio, ATEM

- Cameras: clean HDMI output on, all 1920×1080 same frame rate, subjects near centre for the 9:16 crop.
- Audio: mic into the ATEM, host mic ON, peaks around –12 to –6 dB (red is clipping).
- ATEM: Program buttons pick what's live (CUT hard-cuts, AUTO transitions); optional USB-C SSD ISO-records each input.

OBS — 16:9 and 9:16

- 16:9: ATEM as a Video Capture Device (1920×1080) + the overlay Browser Source (Program URL from Broadcast → Live tools) placed above the camera; it runs transparent automatically.
- 9:16: a separate OBS profile at 1080×1920, the ATEM cropped to a centre 9:16, and the vertical overlay on top. Same graphics drive both; the ticker shows as a headline strap on vertical.

On-air graphics (from the portal)

- Lower thirds: Broadcast → a rundown segment → Take to air; Clear removes it.
- Bug, ticker, breaking: Broadcast → On-air graphics → Show / Hide; edit the ticker and Update.
- Pushes appear on the OBS overlay within about a second, on both outputs.

Recorded episodes (DaVinci → publish)

1. Record (OBS or ATEM ISO), then edit and colour in DaVinci; export 1080p.

2. Broadcast → Publish episode; add title, description, category, host.
3. Drop in the file; Upload & publish (or draft). It encodes and appears in the app and site.

Going live

1. Broadcast → Go live → Set up live input (once); copy the OBS Server URL and Stream key.
2. OBS: Settings → Stream → Custom; paste them; Start Streaming.
3. In the portal, press Go live with a title; the LIVE surface appears and a notification goes out.
4. End broadcast when done; the recording is kept.

Note: The Stream key is a credential — never paste it publicly. Normal: a 10–20s beat before playable, and a short delay behind real time.

Notifications

- Going live and publishing an episode notify readers automatically.
- Use Send Alert for breaking news (preview + confirm).

Before every broadcast — dry run

1. Cameras clean + same frame rate, into ATEM 1–4; audio ON, no clipping.
2. OBS: ATEM as capture device; overlay on top; audio in the mixer.
3. Portal: Show the bug → confirm in OBS → Hide; Take a lower third → confirm → Clear.
4. Record a 60-second test while switching cameras and pushing graphics; review it.

This is your quick packet. The full **Dot One Media Employee Handbook** (in the portal Guide, and as a PDF) has every detail; each system also has its own in-app guide.