

1 • THE RIG

- 01 **Cameras into the ATEM.** C400 HDMI out to ATEM input 1, C50 to input 2. Set both HDMI outputs to 1080p at the same frame rate.
- 02 **ATEM to the Mac over USB-C.** It shows up in OBS like a webcam named Blackmagic Design.
- 03 **Arm the ISO recording** to the ATEM SSD. That captures every camera plus the program cut, which is your Resolve backup.
- 04 **Switch on the ATEM buttons** or in Software Control. OBS simply receives whatever you cut.

2 • OBS • THE MAIN SHOW

- 01 **Profile "Dot 1 Live".** Settings, then Video: Base and Output both 1920x1080, 30 fps.
- 02 **Scene "LIVE".** Add a Video Capture Device and pick the ATEM. Stretch it to fill the canvas.
- 03 **Add a Browser source above it.** Check Local file, choose `dot1-news-broadcast.html`, Width 1920, Height 1080. The file senses OBS and switches itself to a clean, transparent overlay with no panel.
- 04 **Add the control dock.** View menu, Docks, Custom Browser Docks. Name it `D1N Control`. For the URL, drag the same file into any browser, copy the address bar, and add `?panel` to the end. It looks like `file:///Users/you/Documents/Dot1News/dot1-news-broadcast.html?panel`
- 05 **Dock it beside your preview and drive the show from there.** Type in the dock and the program updates as you type. The keyboard keys on the cheat sheet work while the dock has focus.
- 06 **Vertical works the same way.** A second profile at 1080x1920, the ATEM cropped tall, `dot1-news-vertical.html` as the browser source, and its own dock with `?panel` on the URL.

3 • WHY THE DOCK

- The overlay and the dock are the same file in two roles. The dock publishes every change; the overlay listens and stays clean. If you ever see the control panel on the program, the source URL has `?panel` on it by mistake; the source takes the plain file, only the dock gets `?panel`.

4 • AUDIO • MD 46 WITH THE TASCAM

PATH A • TASCAM WITH XLR INPUTS (DR-40X, DR-60D, DR-70D)

- 01 **MD 46 into TASCAM XLR 1.** Phantom 48V stays OFF; the MD 46 is dynamic and does not need it.
- 02 **TASCAM records the whole show.** 24-bit, 48k WAV, with dual record on so a safety copy runs at minus 12.
- 03 **TASCAM line out to the camera mic input** with a 3.5mm cable. Set the camera input to LINE if it offers it; otherwise MIC with the TASCAM output low, then trim until speech peaks near minus 12 on the camera meters.
- 04 **Camera HDMI carries that audio to the ATEM.** On the ATEM, set that camera's audio channel to ON, not AFV, so the sound stays up on every cut.
- 05 **Confirm the meters move in OBS,** not only on the ATEM.

PATH B • TASCAM WITHOUT XLR (DR-05X STYLE)

- 01 **MD 46 straight into the camera XLR** at MIC level, 48V off, exactly like the checklist.
- 02 **The TASCAM sits at the desk** as an independent safety and room recorder, running the whole show on its own mics.
- 03 **Clap once on camera** right after it starts rolling. That spike lines every track up in Resolve later.

Both paths: fresh batteries, a formatted card, and headphones on for the entire check.

5 • TROUBLESHOOTING

ATEM missing in OBS

Replug the USB-C, then re-pick Blackmagic Design in the Video Capture Device list.

Dock not changing the program

Dock and source must point at the same file on disk. Refresh both.

No audio in OBS

ATEM channel ON, not AFV. Then check the OBS mixer is not muted.

Browser source black

Re-choose the file in its properties, then press Refresh.

Panel visible on air

The source URL has ?panel on it. The source takes the plain file; only the dock gets ?panel.

Graphics look stale

In the browser source properties, press Refresh cache of current page.

THE ORDER OF A SHOW DAY

Power and cables, ATEM ISO armed ♦ Run the Lighting + Audio checklist ♦ OBS on LIVE, dock open ♦ Bug and ticker on ♦
 Play intro to start ♦ Wipe between segments, S at the break ♦ After: stop ATEM, cut thumbnails in the Studio