

[Answer ID: 14115]

Forgotten password / Reset for TeraStation / LinkStation

Created 05/30/2012 03:16 | Updated 07/17/2014 01:23

- 1. Look for the Init button on back of device.
- 2. Press and hold for 10 seconds. The Diag led will start flashing. All settings have been changed to default.

TeraStation TGL / HTGL / RHTGL / ITGL / RITGL / DHTGL / TS-X series

- 1. Open the front panel and look under the left corner of the LCD screen for the red lnit button.
- Press and hold the red button for 10 seconds. The device will start beeping. The password and IP address has been changed to default.

LinkStation - HD-HLAN, HD-HGLAN, HS-DGL or LS-LGL

- 1. Look for the Init button on back of device.
- 2. Press and hold for 10 seconds. The Diag led will start flashing. All settings have been changed to default.

LinkStation - LS-GL, HS-DHGL or LS-WTGL/R1 Ver.1

- 1. Look for the Init button on back of device.
- Press and hold the red button for 10 seconds. The device will start beeping (no beep for LS-W TGL/R1).The password and IP address has been changed to default.

LinkStation - with a function (Func) button

- 1. Normal 0 false false false MicrosoftInternetExplorer4 /* Style Definitions */ table.MsoNormalTable {mso-style-name:"Table Normal"; mso-tstyle-rowband-size:0; mso-tstyle-colband-size:0; mso-style-noshow:yes; mso-style-parent:""; mso-padding-alt:0cm 5.4pt 0cm 5.4pt; mso-para-margin:0cm; mso-para-margin-bottom:.0001pt; mso-pagination:widow-orphan; font-size:10.0pt; font-family:"Times New Roman"; mso-ansi-language:#0400; mso-fareast-language:#0400; mso-bidi-language:#0400;} Move the power switch to OFF and let the unit power down.
- 2. Then move the power switch to On while press and holding the Function Button. The Function LED will begin to flash blue for a minute.
- 3. While the Function LED is Flashing, push the Function Button again to begin the initialization process. All settings have been changed to default. Normal 0 false false false MicrosoftInternetExplorer4

Refine your search
Select Product / OS & Hardware
Select Product
Select OS & Hardware
Enter Keywords or a specified ID

Search

<u>Details</u>

Was this answer helpful?

No

Yee

[EUROPE] English | Deutsch | Francais | Italiano | Espanol [AFRICA] AFRICA | NORTH AMERICA] COSTA RICA | EL SALVADOR | GUATEMALA | MEXICO | PANAMA UNITED STATES & CANADA | SOUTH AMERICA] BRASIL | CHILE | COLOMBIA | ASIA PACIFIC] AUSTRALIA | CHINA | HONG KONG | INDIA | INDONESIA | JAPAN KOREA | MALAYSIA | MIDDLE EAST | NEPAL | PHILIPPINES | SINGAPORE TAIWAN | THAILAND | VIETNAM

BUFFALO GLOBAL

c 2012, BUFFALO Inc. All Rights Reserved.