
Adafruit MAX98357 I2S Class-D Mono Amp

Created by lady ada




Last updated on 2017-05-03 08:10:50 PM UTC

Guide Contents

| Guide Contents | 2 |
|---|----------|
| Overview | 4 |
| Pinouts | 7 |
| Speaker Output | 7 |
| Power Pins | 8 |
| I2S Pins | 8 |
| Other Pins | 9 |
| Gain | 10 |
| SD / MODE | 10 |
| Assembly | 11 |
| Prepare the header strip: | 11 |
| Add the breakout board: | 11 |
| And Solder! | 12 |
| Raspberry Pi Wiring | 14 |
| Raspberry Pi Setup | 15 |
| Fast Install | 15 |
| Detailed Install | 15 |
| Update /etc/modprobe.d (if it exists) | |
| Disable headphone audio (if it's set) | 16 |
| Create asound.conf file | 17 |
| Add Device Tree Overlay Pasphorny Di Tost | 18 20 |
| Raspberry Pi Test | |
| Speaker Tests! | 20 |
| Simple white noise speaker test Simple WAV speaker test | 20 |
| Simple MP3 speaker test | 20 |
| Reducing popping | 20 |
| Play Audio with PyGame | 22 |
| Install PyGame | 22 |
| Run Demo | 22 |
| Downloads | 24 |
| Schematic | 24 |
| | |
| Fabrication Print | 24 |

| © Adafruit Industries | https://learn.adafruit.com/adafruit-max98357-i2s-class-d-mono-amp | Page 3 of 25 |
|-----------------------|---|--------------|

Overview




If your microcontroller or microcomputer has digital audio capability, this amp is for you! It takes standard I2S digital audio input and, not only decodes it into analog, but also amplifies it directly into a speaker. Perfect for adding compact amplified sound, it takes 2 breakouts (I2S DAC + Amp) and combines them into one.

I2S (not to be confused with I2C) in a digital sound protocol that is used on circuit boards to pass audio data around. Many high end chips and processors manage all of the audio in digital I2S format. Then, to input or output data, three or four pins are used (data in, data out, bit clock and left-right channel select). Usually, for audio devices, there's a DAC chip that will take I2S in and convert it to analog that can drive a headphone.

This small mono amplifier is surprisingly powerful - able to deliver 3.2 Watts of power into a 4 ohm impedance speaker (5V power @ 10% THD). Inside the miniature chip is a class D controller, able to run from 2.7V-5.5VDC. Since the amp is a class D, it's incredibly efficient - making it perfect for portable and battery-powered projects. It has built in thermal and over-current protection but we could barely tell it got hot.

The audio input is I2S standard, you can use 3.3V or 5V logic data. The outputs are "Bridge Tied" - that means they connect directly to the outputs, no connection to ground. The output is a ~300KHz square wave PWM that is then 'averaged out' by the speaker coil - the high frequencies are not heard. All the above means that you can't connect the output into another amplifier, it should drive the speakers directly.




There's a Gain pin that can be manipulated to change the gain. By default, the amp will give you**9dB** of gain. By connecting a pullup or pull down resistor, or wiring directly, the Gain pin can be set up to give 3dB, 6dB, 9dB, 12dB or 15dB.

the ShutDown/Mode pin can be used to put the chip in shutdown or set up which I2S audio channel is piped to the speaker. By default, the amp will output (L+R)/2 stereo mix into mono out. By adding a resistor, you can change it to be just left or just right output

Works great with Raspberry Pi, Arduino Zero, and any other microcontroller or microcomputer with I2S audio outputs


Specs:

- Output Power: 3.2W at 4Ω, 10% THD, 1.8W at 8Ω, 10% THD, with 5V supply
- PSRR: 77 dB typ @ 1KHz
- I2S sample rates from 8kHz to 96kHz
- No MCLK required
- Click + Pop reduction
- Five pin-selectable gains: 3dB, 6dB, 9dB, 12dB, 15dB
- Excellent click-and-pop suppression
- · Thermal shutdown protection




Comes as an assembled and tested breakout board, with a small piece of optional header and 3.5mm terminal block. Some soldering is required to attach the header and terminal block if those are desired.

Pinouts



The MAX98357A is an **I2S** amplifier - it does not use analog inputs, it only has digital audio input support! Don't confuse I2S with I2C, I2S is a sound protocol whereas I2C is for small amounts of data.

Speaker Output



This amplifier is designed to drive moving coil loudpeakers only. Speaker impedence must be 4Ω or more. The output


signal is a 330KHz PWM square wave with a duty cycle proportional to the audio signal. The inductance of the speaker coil serves as a low-pass filter to average out the high-frequency components. Do not try to use this as a pre-amplifier.

The outputs of *each channel* are "Bridge-Tied" with no connection to ground. This means that for each channels, the + and - alternate polarity to create a single channel amplifier with twice the available power.

Connect your speakers using the 3.5mm screw-terminal blocks.

- 5V into 4Ω @ 10% THD 3W max
- 5V into 4Ω @ 1% THD 2.5W max
- 3.3V into 4Ω @ 10% THD 1.3W max
- 3.3V into 4 Ω @ 1% THD 1.0W max
- 5V into 8Ω @ 10% THD 1.8W max
- 5V into 8Ω @ 1% THD 1.4W max
- 3.3V into 8Ω @ 10% THD 0.8W max
- 3.3V into 8Ω @ 1% THD 0.6W max


Power Pins



This is the power for the amplifier and logic of the amplifier. You can provide 2.5V up to 5.5V. Note that at 5V you can end up putting up to 2.8W into your speaker, so make sure your power supply can easily handle up to 650mA and we recommend a power supply spec'd for at least 800mA to give yourself some 'room'

If you have a 3.3V logic device, you can still power the amp from 5V, and that's recommended to get the most power output!

I2S Pins




Three pins are used to receive audio data. These can be 3.3-5V logic

- LRC (Left/Right Clock) this is the pin that tells the amplifier when the data is for the left channel and when its for the right channel
- BCLK (Bit Clock) This is the pin that tells the amplifier when to read data on the data pin.
- **DIN** (Data In) This is the pin that has the actual data coming in, both left and right data are sent on this pin, the LRC pin indicates when left or right is being transmitted

Note that this amplifier does not require an MCLK pin, if you have an MCLK output, you can leave it disconnected!

Other Pins



The other settings are handled by GAIN and SD

Gain

GAIN is, well, the gain setting. You can have a gain of3dB, 6dB, 9dB, 12dB or 15dB.

- 15dB if a 100K resistor is connected between GAIN and GND
- 12dB if GAIN is connected directly to GND
- 9dB if GAIN is not connected to anything (this is the default)
- 6dB if GAIN is conneted directly to Vin
- 3dB if a 100K resistor is connected between GAIN and Vin

This way, the default gain is 9dB but you can easily change it by tweaking the connection to the GAIN pin. Note you may need to perform a power reset to adjust the gain.

SD / MODE


This pin is used for shutdown mode but is also used for setting which channel is output. It's a little confusing but essentially:


- If SD is connected to ground directly (voltage is under 0.16V) then the amp isshut down
- If the voltage on **SD** is between 0.16V and 0.77V then the output is (Left + Right)/2, that is the stereo average.
- If the voltage on SD is between 0.77V and 1.4V then the output is just the Right channel
- If the voltage on SD is higher than 1.4V then the output is the Left channel.

This is compounded by an internal 100K pulldown resistor on SD so you need to use a pullup resistor on SD to balance out the 100K internal pulldown.

For the breakout board, there's a 1Mohm resistor from SD to Vin which, when powering from 5V will give you the 'stereo average' output. If you want left or right channel only, or if you are powering from non-5V power, you may need to experiment with different resistors to get the desired voltage on SD


Assembly






Prepare the header strip:


Cut the strip to length if necessary. It will be easier to solder if you insert it into a breadboard - long pins down



Add the breakout board:

Place the breakout board over the pins so that the short pins poke through the breakout pads






And Solder!

Be sure to solder all pins for reliable electrical contact.

(For tips on soldering, be sure to check out our Guide to Excellent Soldering (http://adafru.it/aTk)).






You're done! Check your solder joints visually and continue onto the next steps



If you want to use a terminal block for connecting a speaker, place the 3.5mm terminal so the mouthes point out.




Solder in both pins with plenty of solder!



Raspberry Pi Wiring

if you have a Raspberry Pi and you want higher quality audio than the headphone jack can provide, I2S is a good option! You only use 3 pins, and since its a pure-digital output, there can be less noise and interference. Of course, you'll need to make sure that you have a nice strong 5V power supply so make sure to add 500mA or more to your power supply requirements!

This technique will work with any Raspberry Pi with the 2x20 connector. Older Pi 1's with a 2x13 connector do not bring out the I2S pins as easily



Connect:

- Amp Vin to Raspbery Pi 5V
- Amp GND to Raspbery PiGND
- Amp DIN to Raspbery Pi#21
- Amp BCLK to Raspbery Pi#18
- Amp LRCLK to Raspbery Pi#19

Raspberry Pi Setup

At this time, Jessie Raspbery Pi kernel does not support mono audio out of the I2S interface, you can only play stereo, so any mono audio files may need conversion to stereo!


Fast Install

Luckily its quite easy to install support for I2S DACs on Raspbian Jessie.

These instructions are totally cribbed from the PhatDAC instructions at the lovely folks at Pimoroni (http://adafru.it/nFy)

Run the following from your Raspberry Pi with Internet connectivity:

 $curl - sS \ https://raw.githubusercontent.com/adafruit/Raspberry-Pi-Installer-Scripts/master/i2samp.sh \ | \ bash \ | \$



You may need to reboot once. After rebooting, log back in and re-run the script!

You can then go to the next section on testing

Detailed Install

If, for some reason, you can't just run the script and you want to go through the install by hand - here's all the steps!

Update /etc/modprobe.d (if it exists)

Log into your Pi and get into a serial console (either via a console cable, the TV console, RXVT, or what have you)

Edit the raspi blacklist with


sudo nano /etc/modprobe.d/raspi-blacklist.conf




If the file is empty, just skip this step

However, if you see the following lines:

blacklist i2c-bcm2708 blacklist snd-soc-pcm512x blacklist snd-soc-wm8804



Update the lines by putting a# before each line



Save by typing Control-X Y < return>


Disable headphone audio (if it's set)

Edit the raspi modules list with


If the file is empty, just skip this step

However, if you see the following line:

snd_bcm2835



Put a # in front of it




and save with Control-X Y <return>

Create asound.conf file

Edit the raspi modules list with

sudo nano /etc/asound.conf


This file ought to be blank!



Copy and paste the following text into the file

pcm.!default {
type hw card 0

```
}
ctl.!default {
  type hw card 0
}
```




Save the file as usual

Add Device Tree Overlay

Edit your Pi configuration file with

sudo nano /boot/config.txt


And scroll down to the bottom. If you see a line that says:dtparam=audio=on



Disable it by putting a# in front.

Then add: dtoverlay=hifiberry-dac

on the next line. Save the file.



Reboot your Pi with sudo reboot

Raspberry Pi Test

Speaker Tests!

OK you can use whatever software you like to play audio but if you'd like to test the speaker output, here's some quick commands that will let you verify your amp and speaker are working as they should!

Simple white noise speaker test

Run speaker-test -c2 to generate white noise out of the speaker, alternating left and right. Since the I2S amp merges left and right channels, you'll hear continuous white noise

Simple WAV speaker test

Once you've got something coming out, try to play an audio file withspeaker-test (for WAV files, not MP3)

speaker-test -c2 --test=wav -w /usr/share/sounds/alsa/Front_Center.wav

Simple MP3 speaker test

If you want to play a stream of music, you can try

```
sudo apt-get install -y mpg123 mpg123 http://ice1.somafm.com/u80s-128-mp3
```

If you want to play MP3's on command, check out this tutorial which covers how to set that up(http://adafru.it/aTD)

At this time, Jessie Raspbery Pi kernel does not support mono audio out of the I2S interface, you can only play stereo, so any mono audio files may need conversion to stereo!

Reducing popping

When the I2S amplifier gets a new frequency input it may 'pop' the speakers which can be annoying.

The workaround is to use a software mixer to output a fixed sample rate to the MAX98357 so the bit clock does not change. I use ALSA so I configured **dmixer** and I no longer have any pops or clicks. Note that the RaspPi I2S driver does not support by default and you must follow the instructions provided below (http://adafru.it/sHF) to modify/boot/config.txt to add

dtoverlay=i2s-mmap

and change /etc/asound.conf to:

```
pcm.hifiberry {
type hw card 0
}

pcm.ldefault {
type plug
slave.pcm "dmixer"
}

pcm.dmixer {
type dmix
ipc_key 1024
slave {
pcm "hifiberry"
channels 2
}
}
```

ctl.dmixer { type hw card 0 }

Then reboot

Play Audio with PyGame

You can use **mpg123** for basic testing but it's a little clumsy for use where you want to dynamically change the volume or have an interactive program. For more powerful audio playback we suggest using PyGame to playback a variety of audio formats (MP3 included!)

Install PyGame

Start by installing pygame support, you'll need to open up a console on your Pi with network access and run:

sudo apt-get install python-pygame

Next, download this pygame example zip to your Pi

Click to download PyGame example code & sample mp3s http://adafru.it/wbp

On the command line, run

wget https://cdn-learn.adafruit.com/assets/assets/000/041/506/original/pygame_example.zip (http://adafru.it/wbq)

unzip pygame example.zip (http://adafru.it/wbq)

Run Demo

Inside the zip is an example called pygameMP3.py

This example will playback all MP3's within the script's folder. To demonstrate that you can also adjust the volume within pygame, the second argument is the volume for playback. Specify a volume to playback with a command line argument between 0.0 and 1.0

For example here is how to play at 75% volume:

python pygameMP3.py 0.75

Here's the code if you have your own mp3s!

```
"' pg_midi_sound101.py
play midi music files (also mp3 files) using pygame
tested with Python273/331 and pygame192 by vegaseat
"'
```

#code modified by James DeVito from here: https://www.daniweb.com/programming/software-development/code/454835/let-pygame-play-your-midi-or-mp3-files

```
#!/usr/bin/python
```

```
import sys
import pygame as pg
import os
import time
```

```
def play_music(music_file):
    ""
```

```
stream music with mixer.music module in blocking manner this will stream the sound from disk while playing "

clock = pg.time.Clock()

try:
    pg.mixer.music.load(music_file)
    print("Music file {} loaded!".format(music_file))

except pygame.error:
```


```
print("File {} not found! {}".format(music_file, pg.get_error()))
     return
  pg.mixer.music.play()
  # If you want to fade in the audio...
  # for x in range(0,100):
  # pg.mixer.music.set_volume(float(x)/100.0)
  # time.sleep(.0075)
  ## check if playback has finished
  while pg.mixer.music.get_busy():
     clock.tick(30)
freq = 44100 # audio CD quality
bitsize = -16 # unsigned 16 bit
channels = 2 # 1 is mono, 2 is stereo
buffer = 2048 # number of samples (experiment to get right sound)
pg.mixer.init(freq, bitsize, channels, buffer)
if len(sys.argv) > 1:
  try:
     user_volume = float(sys.argv[1])
  except ValueError:
     print "Volume argument invalid. Please use a float (0.0 - 1.0)"
     pg.mixer.music.fadeout(1000)
     pg.mixer.music.stop()
     raise SystemExit
  print("Playing at volume: " + str(user_volume)+ "\n")
  pg.mixer.music.set_volume(user_volume)
  mp3s = []
  for file in os.listdir("."):
     if file.endswith(".mp3"):
       mp3s.append(file)
  print mp3s
  for x in mp3s:
     try:
       play_music(x)
       time.sleep(.25)
     except KeyboardInterrupt:
       # if user hits Ctrl/C then exit
       # (works only in console mode)
       pg.mixer.music.fadeout(1000)
       pg.mixer.music.stop()
       raise SystemExit
else:
  print("Please specify volume as a float! (0.0 - 1.0)")
```

Downloads

- MAX98357 Datasheet (http://adafru.it/nFz)
- GitHub with EagleCAD PCB Files (http://adafru.it/nFB)
- Fritzing object in the Adafruit Fritzing library (http://adafru.it/aP3)

Schematic

Click to embiggen



Fabrication Print

Dimensions in Inches

