PCB-1.99j-mag1 command reference ©19

misc operations	
backspace	remove object
*[S][C]Btn*1	remove object
scroll wheel	vertical pan
*[S]*scroll wheel	horizontal pan
*Btn*1	current mode action
u	undo operation
*[S]*r	redo operation
*[S][C]*u	clear undo-list
tab	switch viewing side
cursor key	move crosshair 1 grid
*[S]*cursor key	move crosshair 10 grid

connections	
*[S]*f	reset found connections
f	find connections
*[S]*backspace	remove connections

user (:) commands	
:DRC()	check layout for rule violations
:l [file]	load data file
:le [file]	load element to buffer
:m [file]	load layout to buffer
:q	quit application
:rn [file]	load netlist
:s [file]	save data as file

display	
c	center display
g	increase grid spacing
*[S]*g	decrease grid spacing
*[C]*m	mark location
r	clear and redraw output
z	zoom in
*[S]*z	zoom out
v	zoom extents
*[S]Btn*3	temporary zoom extents

selection	
*Btn*2	select/deselect object
*[S]Btn*2	toggle object to selection
drag *Btn*2	select only objects in box
drag *[S]Btn*2	add box to selection
*[S]*m	move selected to current layer

copy and move	
drag *Btn*2	move object or selection
drag *[M]Btn*2	copy object
drag *[S][M]Btn*2	override rubberband & move
m	move to current layer

pastebuffer	
*[C]*x	copy selected objects to buffer and enter pastebuffer mode
*[S][C]*x	cut selected objects to buffer and enter pastebuffer mode
*Btn*1	in pastebuffer mode copy to layout
*[C]*1···5	select buffer # 1···5

sizing	
s	increase size of TLAPV *a*
*[S]*s	decrease size of TLAPV
*[M]*s	increase drill size of PV
*[S][M]*s	decrease drill size of PV
k	increase clearance of LAPV
[S] k	decrease clearance of LAPV

element	
d	display pinout
*[S]*d	open pinout window
h	hide/show element name
n	change element name

pin/pad	
n	change name
q	toggle square flag

*F*1
*[C]*v
[S][C]
*[M]*v
[S][M]
*[C]*h

*F*2
*F*3
l
*[S]*l
period
/
[S]

*F*5
*F*6
*[S]*p
insert

*F*4
n
t
*[S]*t

w
*[S]*w
e
*[S]*e
o
*[S]*o

---
*a*TLAPV: text, line, arc, pin or via

Obviously *[S]*, *[C]*, *[M]*, *F* and *Btn* mean the shift, control, modifier1 (BTNMOD for buttons), function key and mouse butto