Copyright by Professor_jonny@hotmail.com (Suiziki Vitara XL-7) (special note)

	(30	uiziki Vilaia AL-7)
	1 2 3 4 5	6 7 8
		20 21 22 23
	24 25 26 27 28 29 30 31 32	33 34 35
	VIT [61]	
	Light blue connector (large) (35)	VITARA
1	co adjusting resistor Supply	GR-R
2	Radio/dome Supply	w
3	Diag pin 1	W-L
4	Cruze control	Gr
5	Diag pin 6	V
6	Tacho	Br
7	CEL lamp	V-Y
8		
9	EFI relay	L
10	co adjusting resistor signal	Gr-B
11	DI Caria O	,,,,,
12	DLC pin 9	V-W
13	DLC pin 7	V-R
14 15	Diag pin 5	W-R
16	A/C controller	P-W
17	A/C controller triple pressure switch	G-B
18	condenser fan high relay	L-0
19	4x4xlamp	О-В
20	12v efi supply	L-B
21	12v efi supply	L-B
22	condenser fan relay	Y-L
23	fuel pump relay (without immobilizer)	
24	co adjusting resistor GND	Gr-Y
25	Cruze control lamp ?	Y-W
26		
27		
28	Fuel light	L-W
29	Diag pin 2	Υ
30	ABS	P-B
31		
32	can	w
33	can	0
34	brake light switch	G-W
35	fuel pump relay (with immobilizer)	W-G
	, , , , , , , , , , , , , , , , , , ,	
		45 46
		56 57
	58 59 60 61 62 63 64 6	95 66
	VIT [51-3]	
	Light blue connector (small) (26)	VITARA
	Light Side confidence (Sinding (20)	V11/11/1

ĺ	71								1		76	
ı	78	79	80	81	82	83	84	85	86	87	88	89
ı	90	91		92	93	94		95	96		97	98

	VIT [51-1]		
	Orange connector (28)	VI	TARA
1			
2			
3			
4	iac b	V-B	
5	iac a	Lg-B	
6			
7			
8			
9			
10			
11			
12	CMP sensor pin 3	Y-G	
13	CMP sensor pin 4	Y-B	
14	VSS speed sensor		
15	evap purge	G-B	
16	iac d	V-Y	
17	iac c	Gr-L	
18			
19			
20			
21			
22			
23			
24	Transmision Range sensor	B-Y	
25	P/S spessure switch	L-0	
26			
27			
28			

Key colo	ours
L	blue
G	Green
W	White
Υ	Yellow
В	Black
BR	Brown
R	Red
0	Orange
LG	Light Green
V	violet
P	Pink
TRP	transparent
SI	silver
SB	Sky Blue
KEY	
E/C	enging control
A/T	Automatic Transmission
I/D	Instrument display
D/C	Diagnostic Connector
N/C	Not connected
A/C	Air Con
E/T	electronic Throttle

	41 42 43	44 45 46	1011102 103104
	47 48 49 50 51 52 53 54	55 56 57	1081091101111121131141151
	58 59 60 61 62 63	64 65 66	121122123 124125 1261
	VIT [51-3]		VIT [51-2]
_	Light blue connector (small) (26)	VITARA	Green connector (30)
1	IAT sensor	Sb	1 Inj 2
2	ECT sensor	G	2 Inj 1
3	Knock sensor	W	3 Free axle motor
4	12v ign	L-B	4 o2 heater 1
5	air flow meter GND	Gr-Y	5 o2 heater 2
6	gnd	B-G	6 Varable inhalation Valve
7	Compressor relay	P	7 GND
8	map sensor supply	R-W	8 Inj 4
9	TPS sig	R-G	9 Inj 3
10	air flow meter sensor	V-W	10 Free axle motor
11	o2 sensor 1	R	11 4x4 switch
12	TPS gnd	G-Y	12 egr step c
13	TPS +v	GR-R	13 egr step d
14	map sensor supply	GR-R	14 egr step b
15	12v ign	L-B	15 egr step a
16			16 o2 heater 3
17	o2 sensor 4	P-W	17 o2 heater 4
18	triple pressure switch	0	18
19			19 ckp sensor signal
20	v batt	B-W	20 ckp sensor supply
21	o2 sensor 2	B-L	21 Inj 6
22	o2 sensor 3	R-B	22 Inj 5
23			23 ig coil 6
24			24 ig coil 5
25	Sensor gnd	Gr-Y	25 ig coil 4
26	CMP sensor GND		26 ig coil 3
			27 ig coil 2
			28 ig coil 1
			29
			30 ckp sensor ground



ol ransmission			
display onnector			
ed			
nrottle			