

54C CIRCUIT DIAGRAMS from Aug 2001 – Starting System

Main
Index

54
Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

BATTERY

IGNITION SWITCH

INHIBITOR SWITCH (A-89)

CRUISE CONTROL MPI SYSTEM

MPI SYSTEM

WIRING CONNECTIONS:

- BATTERY → 20B
- 20B → INHIBITOR SWITCH (A-89) terminal 1
- 20B → IGNITION SWITCH → <F>3B-R
- <F>3B-R → 2 (B-43)
- 2 (B-43) → 2B-Y
- 2B-Y → A/T and M/T
- 2B-Y → <F>2B-Y
- 2B-Y → 1(A-84)
- 1(A-84) → MPI SYSTEM
- 1(A-84) → <F>2B-Y
- 1(A-84) → 1(A-93)
- 1(A-93) → OFF-ON switch
- OFF-ON switch → (A-94) terminal 1
- (A-94) terminal 1 → 20B
- 20B → L, 2, 3, D, N, R terminals of the inhibitor switch box
- 20B → <F>2B-R
- 20B → 9
- 9 → 10
- 10 → 2B-Y
- 2B-Y → A/T and M/T
- A/T and M/T → <F>2B-Y
- <F>2B-Y → 1(A-93)







B-43 A-89

(A-84) (A-94) (A-93)

36TJ078A AA

54C CIRCUIT DIAGRAMS from Aug 2001 – MPI System

MPI SYSTEM <Automatic Transmission Vehicles>



36TJ005D AA

36TJ005D AB

54C CIRCUIT DIAGRAMS from Aug 2001 – MPI System

MPI SYSTEM <Automatic Transmission Vehicles> (CONTINUED)

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E


F

G

H

J

K



36TJ079A BA

36TJ079A BB

54C CIRCUIT DIAGRAMS from Aug 2001 – MPI System

MPI SYSTEM <Automatic Transmission Vehicles> (CONTINUED)

Main Index

54 Index

54C
08/01

A

B

C

D

E

F


G

H

J

K

Main Index



(B-78)	(B-84)	(B-108A)	(B-109A)	(B-110A)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	41 42 43 44 45 46 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98
(B-37)	(B-41)	(B-120)		

(A-70)	(B-105)	(A-72)	(A-88)	(C-04)	(C-03)	(B-108A)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	41 42 43 44 45 46 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20
(B-109A)	(B-110A)		(A-98)	(A-104)	(A-92)	

36TJ005D CA

36TJ005D CB

54 CIRCUIT DIAGRAMS from Aug 2001 — ELC 4 Speed Automatic Transmission <Verada>
ELC 5 Speed Automatic Transmission <Sports>

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G


H

J

K

cardagn.com

ELC 4-SPEED AUTOMATIC TRANSMISSION <VERADA> ELC 5-SPEED AUTOMATIC TRANSMISSION <SPORTS>



(B-78)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18		

(B-84)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18		

(B-109A)

41	42	43	JAE	44	45	46
47	48	49	50	51	52	53
54	55	56	57	58	59	60
61	62	63	64	65	66	67
68	69	70	71	72	73	74

B-59

(A-28)

B-59

(B-41)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

(B-110A)

71	72	73	74	JAE	75	76	77
78	79	80	81	82	83	84	85
86	87	88	89	90	91	92	93
94	95	96	97	98			

B-110A

(B-111A)

10	10	10	10	JAE	105	106	107
108	109	110	111	112	113	114	115
116	117	118	119	120	121	122	123
124	125	126	127	128	129	130	131

B-111A

(B-41)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

B-41

(B-43)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

B-43

(B-18)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

B-18

(B-85)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

B-85

(B-77)

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20

B-77

36TJ080A AA

36TJ080A AB

54 CIRCUIT DIAGRAMS from Aug 2001 - ELC 4 Speed Automatic Transmission<Verada>
ELC 5 Speed Automatic Transmission<Sports>

**ELC 4-SPEED AUTOMATIC TRANSMISSION <VERADA>
ELC 5-SPEED AUTOMATIC TRANSMISSION <SPORTS>
(CONTINUED)**

Main
Index

54
Index

54C
08/01

A

B

C


D

E

1

3

1



(B-105)

B-43 A-89

A-84) (B-110A)
M
12

(B-111A)

106	107
119	120
125	126

(A-88) (C-04)
1 2 3 | 1 2 3 4 |
10 11 12 13 | 9

C-03 ▲

06 (B-99)

54 CIRCUIT DIAGRAMS from Aug 2001 ELC 4 Speed Automatic Transmission<Verada>
- ELC 5 Speed Automatic Transmission<Sports>

**ELC 4-SPEED AUTOMATIC TRANSMISSION <VERADA>
ELC 5-SPEED AUTOMATIC TRANSMISSION <SPORTS>
(CONTINUED)**

Main
Index

54
Index

54C
08/01

A

B

C

D


E

5

2

1

2



54 CIRCUIT DIAGRAMS from Aug 2001 — ELC 4 Speed Automatic Transmission<Verada>
ELC 5 Speed Automatic Transmission<Sports>

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G


H

J

K

cardiagn.com

ELC 4-SPEED AUTOMATIC TRANSMISSION <VERADA> ELC 5-SPEED AUTOMATIC TRANSMISSION <SPORTS> (CONTINUED)




41	42	43	JAB	44	45	46
47	48	49	50	51	52	53
54	55	56	57	58	59	60

21	22	23	24	JAE	75	76	77
78	79	80	81	82	83	84	85
86	87	88	89	90	91	92	93

101	102	103	104	JAB	105	106	107
108	109	110	111	112	113	114	115
116	117	118	119	120	121	122	123

14



109	110	111	112	113	114	115	116	117	118	119	120	121	122	123
124	125	126	127	128	129	130	131	132	133	134	135	136	137	138

1	2	3
4	5	6

54C CIRCUIT DIAGRAMS from Aug 2001 - Tail lamp, Position Lamp and Licence Plate Lamp

Main
Index

54
Index

54C
08/01

A

B

C

D


E

F

3

1

15



54C CIRCUIT DIAGRAMS from Aug 2001 – Fog Lamp

Main
Index

54
Index

54C
08/01

A

B

C

D

E

F

G



H

J

K

FOG LAMP <VERADA AND SPORTS>

Main
Index



(A-18X)	(A-23X)	(A-34)	(A-46)	(B-74)

(C-09)

B-27

(B-77)


B-80

C-04
1 2 3 4 5 6 7 8
9
10 11 12 13 14 15 16 17

C-05
21 22 23 24 25 26 27 28
29
30 31 32 33 34 35 36 37

54C CIRCUIT DIAGRAMS from Aug 2001 – Door Lamp and Foot Lamp**Main Index****54 Index****54C 08/01****A****B****C****D****E****F****G****H****J****K****Main Index****54 Index****54C 08/01****A****B****C****D****E****F****G****H****J****K**

cardiagn.com

DOOR LAMP AND FOOT LAMP

54C CIRCUIT DIAGRAMS from Aug 2001 – Ignition Key Cylinder Lamp

Main
Index

54
index

54C
08/01

A

B

C

D


E

5

3

1

K



B-21	B-76	B-78																																								
	<table border="1" data-bbox="179 1361 348 1367"> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td><input checked="" type="checkbox"/></td><td>7</td><td>8</td><td>9</td><td>10</td></tr> <tr> <td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td></tr> <tr> <td>21</td><td>22</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table>	1	2	3	4	5	<input checked="" type="checkbox"/>	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22									<table border="1" data-bbox="352 1361 392 1367"> <tr> <td>1</td><td>2</td><td><input checked="" type="checkbox"/></td><td></td><td></td></tr> <tr> <td>5</td><td>6</td><td>7</td><td></td><td></td></tr> </table>	1	2	<input checked="" type="checkbox"/>			5	6	7		
1	2	3	4	5	<input checked="" type="checkbox"/>	7	8	9	10																																	
11	12	13	14	15	16	17	18	19	20																																	
21	22																																									
1	2	<input checked="" type="checkbox"/>																																								
5	6	7																																								

(3)	B-84	B-69
		

(B-121)	(B-122)																																
<table border="1"> <tr><td>21</td><td>22</td><td>23</td><td>24</td><td>25</td><td>26</td></tr> <tr><td>27</td><td>28</td><td>29</td><td>30</td><td>31</td><td>32</td></tr> </table>	21	22	23	24	25	26	27	28	29	30	31	32	<table border="1"> <tr><td>41</td><td>42</td><td>43</td><td>44</td><td>45</td><td>46</td><td>47</td><td>48</td><td>49</td><td>50</td></tr> <tr><td>51</td><td>52</td><td>53</td><td>54</td><td>55</td><td>56</td><td>57</td><td>58</td><td>59</td><td>60</td></tr> </table>	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
21	22	23	24	25	26																												
27	28	29	30	31	32																												
41	42	43	44	45	46	47	48	49	50																								
51	52	53	54	55	56	57	58	59	60																								

54C CIRCUIT DIAGRAMS from Aug 2001 – Meters

METER <Standard Meter>

Main
Index

54
Index

54C
08/01

A

B

C

D


E

1

G

4

J



A-90 B-50

3-105)

80

34) 5

(9) C-02

(B-41)

(B-105)

B-43	B-77												
<table border="1"> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>18</td><td>19</td><td>20</td></tr> </table>	7	8	9	18	19	20	<table border="1"> <tr><td>1</td><td></td><td>2</td></tr> <tr><td>3</td><td>4</td><td>5</td></tr> </table>	1		2	3	4	5
7	8	9											
18	19	20											
1		2											
3	4	5											


(B-80)

36TJ083A AA

36TJ083A AB

54C CIRCUIT DIAGRAMS from Aug 2001 – Meter

METER <High Contrast Meter>



(A-90)	(B-50)	(B-105)	(B-80)	(B-84)	(H-09)	(C-02)
1 2 3 4 5 6 7 8 9 10 [] 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20
34 39 40 41 42 43 44 45 46 47 36 39 40 41 42 43 44 45 46 47	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20
48 49 50 51 52 53 54 55 56 57 48 49 50 51 52 53 54 55 56 57						

36TJ084A AA

(B-41)	(B-105)	(B-43)	(B-77)	(B-80)
1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20
33 39 40 41 42 43 44 45 46 47 36 39 40 41 42 43 44 45 46 47	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37
(A-88)	(C-03)	(C-04)	(C-09)	(C-05)
1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 [] 11 12 13 14 15 16 17 18 19 20 21 22	21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37

36TJ084A AB

54C CIRCUIT DIAGRAMS from Aug 2001 – Meter

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G


H

J

K

cardiagn.com

METER <High Contrast Meter> (CONTINUED)

COMBINATION METER
(C-03)

C-03
36 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57

(B-80)

B-80	(B-84)
1 2 3 4 □ 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 □ 5 6 7 8 9 10 11 12 13 14 15 16 17 18

Main
Index

54C CIRCUIT DIAGRAMS from Aug 2001 – Central Door Locking / Keyless Entry

Main
Index

**CENTRAL DOOR LOCKING AND KEYLESS ENTRY
<ALL MODELS EXCEPT VERADA Xi>**

54
Index

54C
08/01

A

B

C

D

E


F

G

H

J

K



(B-20)				
1	2	3	4	5
10	11	12	13	14
22	23	24	25	26

(F-17)			(B-77)	
1	2		1	2
3	4		3	4

	(B-76)																					
9 21 32	<table border="1"> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td><input checked="" type="checkbox"/></td><td>6</td></tr> <tr> <td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td></tr> </table>	1	2	3	4	5	<input checked="" type="checkbox"/>	6	11	12	13	14	15	16	17	18						
1	2	3	4	5	<input checked="" type="checkbox"/>	6																
11	12	13	14	15	16	17	18															
-92	<table border="1"> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td><input checked="" type="checkbox"/></td><td>6</td><td>7</td><td>8</td><td>9</td></tr> <tr> <td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td></tr> </table>	1	2	3	4	5	<input checked="" type="checkbox"/>	6	7	8	9	11	12	13	14	15	16	17	18	19	20	21
1	2	3	4	5	<input checked="" type="checkbox"/>	6	7	8	9													
11	12	13	14	15	16	17	18	19	20	21												

B-80
1 2 3 4
10 11 12 13
14 15 16 17
C-09
1 2 3 4 5
11 12 13 14 15 16 17

(B-55)																					
<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td><input checked="" type="checkbox"/></td><td>5</td><td>6</td></tr> <tr><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td></tr> <tr><td>19</td><td>20</td><td></td><td></td><td></td><td></td><td></td></tr> </table>	1	2	3	4	<input checked="" type="checkbox"/>	5	6	9	10	11	12	13	14	15	19	20					
1	2	3	4	<input checked="" type="checkbox"/>	5	6															
9	10	11	12	13	14	15															
19	20																				

(B-74)														
<table border="1"> <tr><td>7</td><td>8</td><td>9</td><td>10</td><td></td><td></td><td></td></tr> <tr><td>19</td><td>20</td><td>21</td><td>22</td><td></td><td></td><td></td></tr> </table>	7	8	9	10				19	20	21	22			
7	8	9	10											
19	20	21	22											

(B-122)
39 40 41 42 43 44 45 46 47
29 30 31 32 33 34 35 36 37
6 7 8 9 17 18 19 20

(B-120)
9 10 11 12 1 1 2 3 4 5

	B-50
3 8	1 2 <input checked="" type="checkbox"/> 3 4 5 6 7 8 9 10
F-21	F-25
	
B	

	D-12												
	<table border="1"> <tr> <td>1</td><td>M</td><td>2</td><td>3</td></tr> <tr> <td>4</td><td>5</td><td>6</td><td>7</td></tr> <tr> <td>8</td><td>9</td><td>10</td><td></td></tr> </table>	1	M	2	3	4	5	6	7	8	9	10	
1	M	2	3										
4	5	6	7										
8	9	10											

	J-05								
	<table border="1"> <tr> <td>1</td><td>2</td><td>3</td><td>M</td></tr> <tr> <td>7</td><td>8</td><td>9</td><td>10</td></tr> </table>	1	2	3	M	7	8	9	10
1	2	3	M						
7	8	9	10						

(D-25) <WAGON

1	2	3	4	5	6		
9	10	11	12	13	14	15	16

(K-04)

4	5	6
12	13	14

1	2		3	4
5	6	7	8	9
10	11	12	13	14

D-25 <SEDAN>

1	2	3	<input checked="" type="checkbox"/>	4	5	6	
7	8	9	10	11	12	13	14

K-08

1	2
3	4

36TJ027D AA

54C CIRCUIT DIAGRAMS from Aug 2001 – Central Door Locking / Keyless Entry

CENTRAL DOOR LOCKING AND KEYLESS ENTRY
<ALL MODELS EXCEPT VERADA Xi> (CONTINUED)

Main Index

54 Index

54C 08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C 08/01

A

B

C

D

E

F











G

H

J

K

cardiagn.com

TRUNK LID OPENER ACTUATOR
(SEDAN ONLY)

36TJ085A BA

36TJ085A BB

54C CIRCUIT DIAGRAMS from Aug 2001 – Manual Air Conditioning

MANUAL AIR CONDITIONING (CONTINUED)

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F


G

H

J

K

cardiagn.com



54C CIRCUIT DIAGRAMS from Aug 2001 – Full Automatic Air Conditioning

FULL AUTOMATIC AIR CONDITIONING

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E



F


G

H

J

K



54C CIRCUIT DIAGRAMS from Aug 2001 – Full Automatic Air Conditioning**FULL AUTOMATIC AIR CONDITIONING (CONTINUED)**

54C CIRCUIT DIAGRAMS from Aug 2001 – Full Automatic Air Conditioning

FULL AUTOMATIC AIR CONDITIONING (CONTINUED)

Main
Index

54
Index

54C
08/01

A

B

C

D


E

F

G

1

J



54C CIRCUIT DIAGRAMS from Aug 2001 – Audio

AUDIO <6 & 8 SPEAKER SYSTEM>

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

I

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F


G

H

I

J

K



(B-89)
1 2 3 4 M 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19

(B-76)
1 2 3 4 5 M 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22

(B-77)
1 2 M 3 4 5 6 7 8 9 10

(B-78)
1 2 3 4 M 5 6 7 8 9 10 11 12 13 14 15 16 17 18

(B-84)
1 2 3 4 M 5 6 7 8 9 10 11 12 13 14 15 16 17 18

(B-85)
M

(B-66)
1 11 12 13 14 15 16 17 18 19 20 21 22

(B-73)
1 2 3 4 5 6 7 8 9 10

(B-30)
M

(B-66B)
M

(C-18)
1 2 3 4 5 6 7 8 9 10

(C-09)
M

(B-66A)
1 2 3 4 M 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22

(C-16)
M

(C-17)
M

54C CIRCUIT DIAGRAMS from Aug 2001 – Audios

Main
Index

54
Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main
Index

54
Index

54C
08/01

A

B

C

D

E



F

G

H

J

K



54C CIRCUIT DIAGRAMS from Aug 2001 – Traction Control System

Main
Index

54
Index

54C
08/01

A

B

C

D

E

F

G

H

J

IGNITION SWITCH (IG2)

Line 2L-R connects to terminal 2 (B-77) of the J/B (Multi-Purpose Fuse). This line also connects to terminal 9 (B-76) and terminal 2 (B-42).

The J/B contains a 10A multi-purpose fuse.

Line L-R connects to terminal 2 (B-42).

TRACTION CONTROL ECU


Terminal 35 (B-114) is connected to the Traction Control ECU. Terminals 19 and 25 are connected to body ground.

Terminal 2 (B-58) is connected to the body ground.

This diagram shows the wiring connections for the Throttle Position Sensor (A-68) and the Accelerator Pedal Position Sensor (A-69).

- Throttle Position Sensor (A-68):** Located at the top left. It has three terminals: 4 (bottom), 3 (middle), and 1 (top). A resistor is connected between terminals 3 and 1. Terminals 4 and 3 are connected to the **ENGINE CONTROL** unit. Terminal 1 is connected to ground.
- Accelerator Pedal Position Sensor (A-69):** Located at the top right. It has four terminals: 3 (bottom), 4 (middle), 2 (top), and 1 (rightmost). Terminals 3 and 4 are connected to the **ENGINE CONTROL** unit. Terminal 2 is connected to ground. Terminal 1 is connected to the **ACCELERATOR PEDAL POSITION SENSOR**.
- ACCELERATOR PEDAL POSITION SENSOR:** This component is connected to terminals 2 and 1 of the A-69 sensor. It also has a terminal labeled 2 at the top right.
- Idle Switch:** A switch located between terminals 2 and 1 of the A-69 sensor. It has two positions: OFF (top) and ON (bottom).
- Resistors:** There are resistors connected between terminals 3 and 1 of the A-68 sensor, and between terminals 3 and 4 of the A-69 sensor.
- Ground Connections:** Ground connections are shown at the bottom of the A-68 sensor, the bottom of the A-69 sensor, and the bottom of the Accelerator Pedal Position Sensor.
- ECU and Power Sources:** The **ENGINE CONTROL** unit is connected to terminals 46 and 78 (B-110) of the A-68 sensor, and to terminals 79 and 57 (B-109) of the A-69 sensor. The ECU is also connected to a 5V power source. The Accelerator Pedal Position Sensor is connected to a 5V power source and ground.

A-68	A-69	B-42	B-76	(B-77)	(B-109)
					
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6	41 42 43 56 59 60 61 62 63 64 65 66
B-110	(B-113)		(B-114)		(B-58)
					
71 72 73 74 75 76 77 80 81 90 91 95 96 97 98	JAE 75 76 ?? 95 96 97 98	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 38 40 41 42 43 44 45 46	91 92 93 94 95 96 97 98 38 40 41 42 43 44 45 46	1 2 3 4 5 6 7 8 9 10	



54C CIRCUIT DIAGRAMS from Aug 2001 – Traction Control System

Main
Index

54
Index

54C
08/01

A

B

C

D

E

F

G

H

J

Main
Index

54
Index

54C
08/01

A

B

C

D



E

F

G

H

J



54C CIRCUIT DIAGRAMS from Aug 2001 – Traction Control System

TRACTION CONTROL SYSTEM (CONTINUED)

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F


G

H

J

K

cardiagn.com



(B-77)	(B-80)	(B-84)	(B-105)
[1] [2] [3] [4] [5] [6]	[1] [2] [3] [4] [5] [6] [7] [8] [9] [10] [11] [12] [13] [14] [15] [16] [17] [18] [19] [20]	[1] [2] [3] [4] [5] [6] [7] [8] [9] [10] [11] [12] [13] [14] [15] [16] [17] [18]	[1] [2] [3] [4] [5] [6] [7] [8] [9] [10]
(B-110)	(B-113)	(B-114)	(C-08)

71	72	73	74	JAB	75	76	77
76	77	78	79	80	81	82	83
84	85	86	87	88	89	90	91

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

36TJ034D CA

54C CIRCUIT DIAGRAMS from Aug 2001 – Theft Alarm

THEFT ALARM

Main
Index

54
Index

54C
08/01

A

B

C

D


E

F

G

4

J



FRONT DOOR SW				REAR DOOR SW				
(A-08)	(B-75)	(B-76)	(B-78)	(B-84)	(B-89)	(B-92)		
1 M 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10		
11 12 13 14 15 16 17 18 19 20 21 22								
(B-120)	(B-122)	(D-14)	(D-22)	(D-25)	(G-09)	(G-28)	(G-30)	(G-37)
9 10 11 12 13 14 15 16	9 10 11 12 13 14 15 16	9 10 11 12 13 14 15 16						
1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8						
9 10 11 12 13 14 15 16	9 10 11 12 13 14 15 16	9 10 11 12 13 14 15 16						
17 18 19 20 21 22	17 18 19 20 21 22	17 18 19 20 21 22						
(J-04)	(J-13)							
1 2	1 2							

36TJ046D A.

① F-12 (B-122)
②  1 2 3
③ 39 40 41 42 43 44 45 46 47 48

36TJ046D AB

54C CIRCUIT DIAGRAMS from Aug 2001 – Theft Alarm

THEFT ALARM (CONTINUED)

Main Index

54 Index

54C 08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C 08/01

A

B

C

D

E


F

G

H

J

K



(B-20)

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27
28	29	30	31	32	33	34	35	36
37	38	39	40	41	42	43	44	45

(D-25) SEDAN

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(D-25) WAGON

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(B-122)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(B-74)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(B-80)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(B-121)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(B-33)

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40

(C-05)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40

(C-09)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40

36TJ090A BA



36TJ090A BB

54C CIRCUIT DIAGRAMS from Aug 2001 – Sunroof

Main Index**54 Index****54C 08/01****A****B****C****D****E****F****G****H****J****K****Main Index****54 Index****54C 08/01****A****B****C****D****E****F****G****H****J****K**

cardiagn.com

SUNROOF



36TJ091A AA

36TJ091A AB

54C CIRCUIT DIAGRAMS from Aug 2001 – Cigarette Lighter, Ashtray Lamp and Accessory Socket

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

Main Index

54 Index

54C
08/01

A

B

C

D

E

F

G

H

J

K

cardiagn.com

CIGARETTE LIGHTER, ASHTRAY LAMP AND ACCESSORY SOCKET

