TA2System		TDAQmodule	
CmdList[5]	fEXP	fDW	fActualHardID
nputFile	fPCtrlMod	fData	findex
ogFile	fCtrlMod	fMapSize	fType
LogStream	fCtrl	fMaxReq	fBaseIndex
slnit	fEventSendMod	fNreq	fNChannel
sError	fMemMap	fNInitReq	fNScalerChan
sConfigPass	fBaseAddr	fNTestReg	fNBits
alsA	fVirtOffset	fNIRQReg	finitLevel
JISA	fReq	fErrorCode	flsError
	fInitReg	fBus	fglsA
~TA2System	fTestReg	fID	igisA
aselnit	fIRQReg	fHardID	
rintError	IIINGINEG	ITIAIUID	
rintMessage	@~TDAQmodule	DecodelRQ	GetNreg
lap2Key	TDAQmodule	WaitIRQ	GetNInitReg
lap2Key	SetConfig	ResetIRQ	GetNIRQReg
lap2String	PostInit	EnableIRQ	GetNTestReg
etMapKey	InitReg	DisableIRQ	GetErrorCode
etMapString	MapReg	RunTrigCtrl	GetBus
ddCmdList	SetCtrl	EndTrigCtrl	GetID
ileConfig	Read	ResetTrigCtrl	GetHardID
ommandConfig	Write	EnableTrigCtrl	CheckHardID
arseMisc	Read	DisableTrigCtrl	GetIndex
etConfig	Write	Reset	SetID
ostlnit	MultiRead	ResetData	SetIndex
uildName	MultiWrite	GetRegType	GetType
heckName	Read	GetModType	IsType
etInputFile	Write	GetEventID	GetBaseIndex
etLogFile	Read	SendEventID	SetBaseIndex
etLogStream	Write	SetDAQexperiment	GetNChannel
etLogStream	Read	GetPCtrlMod	GetNScChannel
etLogFile	Write	GetCtrlMod	SetNChannel
Init	ADCStore	GetCtrl	GetNBits
Error	ScalerStore	GetMemMap	GetInitLevel
lass	ScalerStore	GetBaseAddr	SetInitLevel
lass_Name	ErrorStore	GetVirtOffset	SetEventSendMo
sA	InitWrite	GetVirtAddr	IsError
howMembers	Test	GetReg	MapSlave
	ReadHeader	GetInitReg	Class
	ReadHeader	GetIRQReg	Class_Name
	AddrS	GetTestReg	IsA
	AddrL	GetDW	ShowMembers
	ReadIRQ	GetData	Streamer
			- 31 0011101
	ReadIRQScaler	GetMapSize	

	TVMEmodule
fl:	M sWrt lardIDReg IIsA
@	~TVMEmodule
-	VMEmodule
	etConfig
-	ostlnit
	itReg
	itReg
	itReg
	ead
	/rite
	ead
	/rite
	/rite
	/rite
	ead
	/rite
C	heckHardID
G	etAM
G	etIsWrt

Class Class\_Name

IsA

ShowMembers Streamer

TVME\_SIS3820

@~TVME\_SIS3820 TVME\_SIS3820 SetConfig **PostInit** SendEventID GetEventID CheckHardID Class Class\_Name

fglsA

IsA

**ShowMembers** Streamer