Rigaku XtaLAB Mini II SC-XRD Operating Instructions

Overview

The XtaLAB Mini II is a desktop single-crystal X-ray diffractometer (SC-XRD) with an enclosed beam that is completely shielded. *Any individual who wishes to use the XRD must:*

- Participate in training that demonstrates all safety issues including possible radiation hazards and biological effects of radiation associated with the instrument.
- Receive training in proper operating procedures for the instrument.
- · Agree to document that training has been completed.
- · Record their time on the log sheet.
- · Operate the instrument only according to the manner specified in the SOP.
- · Never bypass the instrument safety devices.

Emergency Contacts

Contact	Role	Office	Email	Phone
Matt Burleson	**Instrumentation Specialist, CHPH, XRD Authorized User **	AP 346	mburleson@wcu.edu	828-227- 2695
Wes Bintz	Research Operations Manager, Arts & Sciences	AP 221	wwbintz@wcu.edu	828-227- 2270
Jamie Wallen	Department Head, CHPH	AP 112	jamiewallen@wcu.edu	828-227- 3667
Jon Maddy	Director, Safety and Risk Management	-	jmaddy@wcu.edu	828-227- 7442
	Lab Safety Officer, Safety and Risk Management	-		828-227- 7443
Campus Police	Non-emergency/after hours contact	-	-	828-227- 730
Campus Dispatch	Fire/Medical/Police Emergency Response	-	-	828-227- 8911
NC Radiation Protection Section	State Emergency Center	-	-	800-858- 0368