



# MiSTer Custom Frontend

Your own menu for the MiSTer FPGA – with achievements, statistics and a few secrets to find.



RetroAchievements



Trophy Room



Collections



Secrets

## WHAT IT LOOKS LIKE

### MiSTer

24 Kategorien  
Favoriten

Weiterspielen

Zuletzt gespielt

Sammlungen

Zufalls-Zock

Arcade

NES

SNES

Game Boy

Game Boy Color

Game Boy Advance


Nintendo 64



13:37



## KEYBOARD

**OK / ENTER**

Select, enter a folder

**ESC**

Back / quit dialogue

The function key row (along the top of any keyboard):

**F3**List  
start**F4**List  
end**F6**RA  
showcase**F7**

Completed

**F8**

Favourite

**F10**Switch  
view**F11**Random  
game**F12**

MiSTerOSD

Also:

**F1 (in a game)**

Straight back to the frontend – no holding

**ESC (hold)**

Same as F1, but hold it for about 0.6 s – needed because many games use ESC themselves

**F2 or /**

Start the search (matches anywhere in the name) – both keys do the same thing

**F5 (tap, in the menu)**

Next music track – same as a “next track” media key, if your keyboard has one

*While a game is running the same key (held) resets the core instead - see below.***F5 (in a game)**

Reset the running core (all cores, RA included) – no holding

*It fires immediately. Try it in a game you do not mind losing first.*

Every key can be remapped under System → Input & Language.  
(Except the search and the secret codes – those are wired in on purpose.)






# FEATURES



## STATISTICS

Trophy room, year in review and play diary: playtime, favourite system and progress at a glance.



## RETROACHIEVEMENTS

Entering a system that supports RA, you pick: the standard core, or the RA core with real achievements.



## ACHIEVEMENTS

F6 shows a game's full achievement list – unlocked or still open, right there in the menu.



## FAVOURITES

Games you mark with F8 collect in their own category – always within reach.



## RANDOM PICK

Cannot decide? Three random games at once – and no repeats until every game has had its turn.



## SEARCH

Jump straight to a game with / or F2 – matching anywhere in the name, not just the start.



## VIEWS & COVER ART




### THREE VIEWS – KEY F10

List, grid, gallery – separately for the game list and for the main page. F10 cycles through them, the menu remembers your default. On HDMI the grid shows 21 games at once.



### GAME DESCRIPTIONS

In gallery view a description of the game sits next to the cover. It comes from the artwork database on the card – nothing to set up.



### GETTING COVER ART

System → Maintenance → “Download box art” fetches it on the MiSTer itself. If you use **Update All**, it is often already under /media/fat/docs – the frontend reads that by itself. Not required, just convenient.



### SINGLE-GAME FOLDERS

On PSX, Mega CD and Saturn each game usually sits in its own folder, because one .cue brings several .bin files with it. Those folders are dissolved – the game appears directly in the list, with cover art, grid and gallery. Multi-disc games stay folders. Can be turned off under System → Options.



### PREPARING THUMBNAILS

Cover art sits on the card at full size and has to be scaled down the first time you look at it – a short wait per game. This does it in advance, once, and stores the result on the card. After that every cover is there instantly, even after a reboot. You can stop and continue later at any time.