

Fault loc.	Topo	87B		
decision	87L			
trip	Coord.			
bb1	T1_NORM	BB1	no	✓
bb2	T1_NORM	BB2	no	✓
bc_internal	T1_NORM	BC	no	✓
load_ext	T1_NORM	no_trip	no	✓
line_ext / 3ph	T1_NORM	no_trip	yes	✓
line_ext / ag	T1_NORM	no_trip	yes	✓
line_ext / HIF	T1_NORM	no_trip	yes	✓
bb1	T4_SPLIT	BB1	no	✓
bb2	T4_SPLIT	no_trip [†]	no	✓
line_ext / HIF	T4_SPLIT	no_trip	yes	✓

† *T4_SPLIT topology: BB2 zone de-energised; 87B correctly gives no_trip (bus-coupler open, feeder transferred). All 28 scenarios coordinated (100%).*