(" In this example, the bar code data will vary in length. Therefore, the method for receving characters is as follows:

1. Watch the RX Count Register (%F100).

2. When %F100 is nonzer to the unchanged for 250mS, assume the transmission from the bar code reader is complete.

3. When the receive is complete, copy the data into another bank of registers (%R201-%R210), clear the receive buffer (%R101-110) and reset the Receive block.

4. The received characters stored in %R201-210 are displayed on Screen #1 on the OCS. 1) Barcode MJ1/Com Option—PORT 9600—Baud *********** Length, with CR ##### 8 Data Bits (* Characters are received from a barcology Words. When not reset, the Receive Block is enabled, allowing characters to be placed in the Receive buffer starting at register %R101 [Rx_Buf]. The buffer length is 254 characters (one less than the maximum allowed), or 127 words. Note that the [RX Count] parameter is %R100, located one word register before the buffer. So the length of the characters received is contiguous with the characters received.*) 6T00003 254 Byte Rx_But Data -%R00101 RX Count %R00100 ("When not reset, check to see that characters have been received, but RX_Cnt is not changing; this is assumed to be an indication that transmission by the bar code reader is complete. To do this, compare RX_Cnt with RX_Cnt_Prv, which is the value of RX_Cnt from the previous scan. Also check RX_Cnt to see that it is greater than zero, indicating characters have been received. Also, since RX_Cnt is greater than zero it cannot be -1, which would indicate that the port is not open. If those conditions are all true, trigger the timer; if the timer completes, assign a 1 to Rx_Cmplt, indicating the bar code read into the buffer so far is a complete barcode.*) 3 RX_Reset TON %R00001 0.01s 6TOOOO3 %T00002 Rx_Cnt_Prv %R00012—IN2 * When not reset, if the current received count of characters is different than the value from the previous scan., then copy the former to the the latter, for comparison in the previous rung on the next scan.*) 4 -1/I-(* When the Receive is complete, cp[u the count of the received characters and the receive buffer characters to another register buffer, then clear the received buffer count to 0 along with the receive buffer (128 words = 1 word + 254 characters). Then assign a 1 to RX_Reset bit, which makes the next ***ONE*** scan a reset scan, which removes power the Receive Block; the scan after that, the RECV instruction will start a new read. *)