Act as a licensed PE an...
TXT 3.18KB

pe-civ-handbook-2-0-1....
PDF 11MB

Thought for 7 seconds

The user wants a comprehensive exam-focused review of material test methods and specification conformance for the PE Civil: Construction exam, based on the provided handbook. The review must cover specific topics like QC/QA roles, standards, sampling, statistical QC, concrete testing, soils, asphalt, steel, masonry, wood, and common errors. I need to extract relevant information from the handbook and supplement with web searches for ASTM/AASHTO standards and common field/lab errors. I'll structure the review according to the user's list. The search will be in English.

Found 60 web pages

The search results provide some useful links. I'll open several to gather more detailed information.

Read 7 pages SECTION 01 45 29 ↗

<table><tr><td>التسمية</td><td>العنوان</td></tr><tr><td>C₄₂/T₂₄</td><td>لعينات ا... ↗

Relative Compaction - Relative compaction is the system of measuring the compaction (density) of soil in the fiel... ↗

(Courtesy of N ↗ Workbook: Step 2- Selection of a Design Aggregate Structure Page 56 ↗ View All

The search results provide useful information. I'll also search for "steel testing ASTM A370" and "masonry testing ASTM C1314".

Found 18 web pages

The search results provide additional references. Now I need to structure the review. I'll cover each subtopic, using the handbook as the primary source and supplementing with the search results. The review will be comprehensive, with definitions, formulas, procedures, worked examples, and exam tips. I'll also include a high-yield checklist and self-test at the end. I need to ensure I flag any details not specified by NCEES or outside the scope. I'll present the material as exam-focused preparation, not a guarantee of passing. Now, I'll write the response.

PE Civil: Construction — Material Test Methods & Specification Conformance

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to Section 2.5 (Material Quality Control and Production), Section 3.8 (Material Test Methods), Section 3.9 (Compaction: Laboratory and Field), Section 5.5.5 (Asphalt Mixture Design), Section 5.5.6 (Structural Design of Flexible Pavement — material volumetrics and conformance), and Section 4.3.1 (Reinforcement Properties). Items not explicitly covered by NCEES specifications or the Reference Handbook are flagged as **[Outside NCEES scope]**.

1. Purpose, Roles, and Responsibilities in QC and QA

1.1 Definitions

Term	Definition
Quality Control (QC)	The contractor's system of planned actions and procedures to ensure that the constructed product meets the contract requirements. QC is **production-oriented**.
Quality Assurance (QA)	The owner's or agency's system of planned actions and procedures to verify that the contractor's QC is functioning properly and that the final product conforms to specifications. QA is **verification-oriented**.
Independent Assurance (IA)	A separate testing program by the owner to validate the testing equipment, procedures, and personnel used by both QC and QA laboratories.

1.2 Key Roles

- **Contractor QC Personnel:** Sample materials, run tests, maintain control charts, and report nonconformance.
- **Owner QA Personnel:** Perform independent verification sampling and testing, evaluate acceptance, and approve/reject materials or work.
- **Testing Laboratory:** Must meet **ASTM E329** (general construction materials) and **ASTM C1077** (concrete and concrete aggregates). [1]

1.3 Exam Tips

- QC **produces** the material; QA **verifies** it.
- IA is a check **on the QA program itself**, not on production.
- Labs testing concrete must meet ASTM C1077; labs testing other construction materials must meet ASTM E329.

2. Specifications, Codes, Standards, and Reference Test Methods

2.1 Hierarchy

```
text

Contract Documents (plans & specs)
   ↓
Standard Specifications (AASHTO, ASTM, ACI)
   ↓
Test Methods (e.g., AASHTO T 99, ASTM D698)
```

2.2 Commonly Tested Materials and Their Standards

Material	Property	ASTM	AASHTO
Soil — Compaction (Standard)	Moisture-density relationship	D698	T 99
Soil — Compaction (Modified)	Moisture-density relationship	D1557	T 180
Soil — In-place density	Field density	D6938 (nuclear), D1556 (sand cone)	T 191, T 310
Soil — Atterberg Limits	LL, PL, PI	D4318	T 89, T 90
Soil — Sieve analysis	Gradation	D422	T 88
Soil — CBR	California Bearing Ratio	D1883	—
Concrete — Slump	Workability	C143/C143M	T 119
Concrete — Air content (pressure)	Air content	C231/C231M	T 152
Concrete — Air content (volumetric)	Air content	C173/C173M	T 196
Concrete — Unit weight & yield	Density, yield	C138/C138M	T 121
Concrete — Compressive strength	f′c	C39/C39M	T 22
Concrete — Making/curing field specimens	Cylinder fabrication	C31/C31M	T 23
Asphalt — Bulk specific gravity (aggregate)	Gsb	C127 (coarse), C128 (fine)	T 84, T 85
Asphalt — Maximum specific gravity (mix)	Gmm	D2041	T 209

Material	Property	ASTM	AASHTO
Asphalt — Bulk specific gravity (compacted mix)	Gmb	D2726	T 166
Steel — Tensile test	fy, fu	A370, E8/E8M	—
Masonry — Prism compressive strength	fmt	C1314	—
Reinforcement — Bar size/area	As	A615/A706	M31

2.3 Exam Tips

- Know **which standard corresponds to which material/property**. The exam often gives a scenario and asks which test applies.
- **Standard Proctor = ASTM D698 / AASHTO T99. Modified Proctor = ASTM D1557 / AASHTO T180.**

3. Sampling, Testing Frequency, Acceptance Criteria, Rejection, Retest, and Nonconformance Procedures

3.1 Sampling Frequency (Concrete — per ACI 318/301)

Strength tests for each class of concrete placed each day shall be taken:

- **Not less than once per day**
- **Not less than once for each 150 yd^3** of concrete
- **Not less than once for each 5,000 ft^2** of surface area for slabs or walls

When the total quantity of a given class of concrete is **less than 50 yd³**, strength tests are **not required** if evidence of satisfactory strength is submitted to and approved by the building official. 【2.5.1†L1-L5】

A **strength test** is the **average of the strengths of at least two 6-in. × 12-in. cylinders** or **at least three 4-in. × 8-in. cylinders** made from the same sample and tested at 28 days.

3.2 Acceptance Criteria for Concrete Strength

The strength level of an individual class of concrete is satisfactory if **both**:

1. **Every arithmetic average of any three consecutive strength tests** ≥ f′c
2. **No strength test falls below f′c by more than:**
   - **500 psi** when f′c ≤ 5,000 psi
   - **0.10 f′c** when f′c > 5,000 psi

3.3 Field-Cured vs. Laboratory-Cured Cylinders

Condition	Requirement
Field-cured strength < 85% of companion lab-cured strength	Procedures for protecting and curing concrete shall be improved
Exception	The 85% limitation does not apply if field-cured strength exceeds f′c by more than 500 psi

3.4 Core Testing (Existing Structures)

Criterion	Requirement
Testing time	Cores tested **no later than 7 days** after drilling

Criterion	Requirement
Acceptance	Average of **three cores** ≥ 85% f′c **AND** no single core < 75% f′c

3.5 Nonconformance Procedures

1. **Immediate halt** of production/placement if nonconformance is found.
2. **Notify the engineer/owner** in writing.
3. **Evaluate the extent** of nonconforming work (e.g., additional cores, NDT).
4. **Submit a repair/remediation plan** for approval.
5. **Retest** after remediation if required.

3.6 Exam Tips

- The **50 yd³ exemption** is commonly tested.
- **Three consecutive tests** — not just any three tests.
- The **500 psi** vs. **0.10 f′c** threshold depends on f′c magnitude.
- **85%/75% core criteria** are high-yield.

4. Statistical Quality Control

4.1 Definitions and Formulas

Statistic	Formula
Mean ($\bar{X}$)	$\bar{X} = (\Sigma X_i) / n$
Range (R)	R = largest value − smallest value

Statistic	Formula
Sample standard deviation (s)	$s = \sqrt{[\Sigma(Xi - \bar{X})^2 / (n - 1)]}$
Coefficient of variation (CV)	$CV = s / \bar{X}$

4.2 Control Charts

4.2.1 $\bar{X}$ and R Charts

R Chart:

- $CL_R = \bar{R}$
- $UCL_R = D_4\bar{R}$
- $LCL_R = D_3\bar{R}$

$\bar{X}$ Chart:

- $CL_X = \bar{\bar{X}}$ (grand mean)
- $UCL_X = \bar{\bar{X}} + A_2\bar{R}$
- $LCL_X = \bar{\bar{X}} - A_2\bar{R}$

Constants (from Handbook Table):

n	A_2	D_3	D_4
2	1.880	0	3.268
3	1.023	0	2.574
4	0.729	0	2.282
5	0.577	0	2.114

n	A_2	D_3	D_4
6	0.483	0	2.004
7	0.419	0.076	1.924
8	0.373	0.136	1.864
9	0.337	0.184	1.816
10	0.308	0.223	1.777

4.2.2 Standard Deviation Charts

- $UCL_X = \bar{\bar{X}} + A_3\bar{S}$
- $LCL_X = \bar{\bar{X}} - A_3\bar{S}$
- $UCL_S = B_4\bar{S}$
- $LCL_S = B_3\bar{S}$

4.3 Acceptance Evaluation (Operating Characteristic Approach)

For a lower limit L only: **Accept if $\bar{X} \geq L$**, where L = X_p + AR (A = multiplier from tables).

For an upper limit U only: **Accept if $\bar{X} \leq U$**, where U = X_p − AR.

For both limits: **Accept if $L \leq \bar{X} \leq U$**.

4.4 Worked Example

Problem: Five slump tests give: 4.0, 4.5, 3.5, 5.0, 4.0 in. Compute $\bar{X}$, R, and s.

Solution:

- $\bar{X}$ = (4.0 + 4.5 + 3.5 + 5.0 + 4.0) / 5 = **4.2 in.**

- R = 5.0 − 3.5 = **1.5 in.**
- s = √[(0.04 + 0.09 + 0.49 + 0.64 + 0.04) / 4] = √(1.30/4) = **0.57 in.**

4.5 Exam Tips

- **R charts monitor variability**; **$\bar{X}$ charts monitor the mean**.
- **A_2 depends on n** — do not memorize; it will be provided.
- Control charts serve as **permanent records** of production quality.

5. Concrete Testing

5.1 Slump Test (ASTM C143 / AASHTO T119)

Item	Requirement
Mold	Standard slump cone (12 in. tall, 8 in. base, 4 in. top)
Procedure	Fill in 3 layers, rod each layer 25 times
Measurement	Immediately after raising cone, measure vertical difference between top of cone and displaced center of specimen
Common errors	Base plate not firmly supported; base not level; dampening cone leaves puddle; measuring highest/lowest point instead of displaced center

5.2 Air Content — Pressure Method (ASTM C231 / AASHTO T152)

- **Applicable to:** Normal-weight and heavyweight concrete
- **Not applicable to:** Lightweight concrete (use volumetric method ASTM C173)

- **Critical requirement:** Use the **aggregate correction factor** — failure to do so gives **incorrect high air-content readings** if aggregate is porous.
- **Common error:** Using pressure meter on lightweight concrete.

5.3 Unit Weight, Yield (ASTM C138 / AASHTO T121)

Formula	Definition
Yield	Total mass of batched materials / density of freshly mixed concrete
Yield	Sum of absolute volumes of concrete ingredients
Absolute volume	Mass of loose material / (relative density × density of water)

Relative densities of aggregates in mix-design calculations are based on saturated surface-dry (SSD) conditions.

5.4 Compressive Strength Cylinders (ASTM C31 / C39)

Item	Specification
Standard cylinder	6 in. × 12 in. or 4 in. × 8 in.
Curing	Laboratory-cured at 73.4°F ± 3°F in limewater or moist room
Test age	28 days (or designated test age)
Field-cured	Protected and cured as near as practicable to the structure

5.5 Concrete Proportioning — Absolute Volume Method

Worked Example: Determine the absolute volume of coarse aggregate for a mix with:

- 1,800 lb of coarse aggregate (SSD)
- Bulk specific gravity (SSD) = 2.65
- Unit weight of water = 62.4 lb/ft³

Solution:
Absolute volume = 1,800 / (2.65 × 62.4) = 1,800 / 165.36 = **10.89 ft³**

5.6 Exposure Categories and Classes (ACI 318)

Category	Classes	Condition
F (Freezing/Thawing)	F0, F1, F2, F3	F0 = not exposed; F3 = frequent water + deicing chemicals
S (Sulfate)	S0–S3	Based on water-soluble sulfate in soil or dissolved sulfate in water
W (In Contact with Water)	W0, W1, W2	W2 = low permeability required
C (Corrosion Protection)	C0, C1, C2	C2 = exposed to moisture + external chlorides

5.7 Concrete Cover Requirements (Cast-in-Place, Nonprestressed)

Exposure	Member	Reinforcement	Cover (in.)
Cast against ground	All	All	3
Exposed to weather/ground	All	No. 6–No. 18	2
Exposed to weather/ground	All	No. 5 and smaller	1½
Not exposed	Slabs, joists, walls	No. 14, No. 18	1½

Exposure	Member	Reinforcement	Cover (in.)
Not exposed	Slabs, joists, walls	No. 11 and smaller	¾
Not exposed	Beams, columns	Primary reinforcement	1½

5.8 Exam Tips

- **Slump test is not a strength test** — it is a workability check.
- **Air content by pressure method** requires aggregate correction factor.
- **SSD is the basis** for mix-design specific gravity.
- **Cover requirements** are frequently tested — know the table.

6. Concrete Maturity and Early-Strength Evaluation

6.1 Time-Temperature Factor Method

$$M = \sum_{0}^{t} (T - T_0)\Delta t$$

where:

- M = maturity index (°F·hours)
- T = average concrete temperature during interval Δt
- T_0 = datum temperature (usually 32°F unless otherwise specified)
- t = elapsed time (hours)
- Δt = time intervals (hours)

6.2 Nondestructive Test Methods (NDT)

Property/Condition	Primary NDT Method
In-place strength	Pullout test, probe penetration, maturity method
General quality/uniformity	Visual inspection, rebound hammer, pulse velocity
Thickness	Impact-echo, ground-penetrating radar
Dynamic modulus of elasticity	Resonate frequency, pulse velocity
Reinforcement location	Covermeter, ground-penetrating radar
Corrosion state of steel	Half-cell potential, polarization resistance
Near-surface defects	Sounding, infrared thermography

6.3 Exam Tips

- **Maturity method** is for **new construction** — it estimates in-place strength based on temperature history.
- **Rebound hammer** measures surface hardness, not strength directly.
- **Half-cell potential** measures corrosion activity, not strength.

7. Soils and Aggregates

7.1 Moisture Content (ASTM D2216 / AASHTO T265)

$$w = \frac{M_{\text{wet}} - M_{\text{dry}}}{M_{\text{dry}}} \times 100\%$$

7.2 Atterberg Limits (ASTM D4318 / AASHTO T89, T90)

Limit	Definition
Liquid Limit (LL)	Moisture content at which soil changes from plastic to liquid state (25 blows in Casagrande cup)
Plastic Limit (PL)	Moisture content at which soil crumbles when rolled into 1/8-in. thread
Plasticity Index (PI)	PI = LL − PL
Liquidity Index (LI)	LI = (w − PL) / PI

A-line: PI = 0.73(LL − 20)
U-line: PI = 0.9(LL − 8)

7.3 Gradation (ASTM D422 / AASHTO T88)

$$C_u = \frac{D_{60}}{D_{10}} \qquad C_c = \frac{(D_{30})^2}{D_{10} \times D_{60}}$$

Parameter	Gravels	Sands
Well-graded	Cu ≥ 4 and 1 ≤ Cc ≤ 3	Cu ≥ 6 and 1 ≤ Cc ≤ 3
Poorly graded	Cu < 4 and/or 1 > Cc > 3	Cu < 6 and/or 1 > Cc > 3

7.4 Compaction — Standard vs. Modified Proctor

Test	ASTM	AASHTO	Mold Volume	Hammer	Layers	Blows/Layer	Energ lb/ft³)
Standard	D698	T99	1/30 ft³	5.5 lb, 12 in. drop	3	25	12,37
Modified	D1557	T180	1/30 ft³	10 lb, 18 in. drop	5	25	56,25

Both tests are performed on minus No. 4 (4.75 mm) fraction.

7.5 Field Density and Relative Compaction

$$RC = \frac{\gamma_{d,\text{field}}}{\gamma_{d,\max}} \times 100\%$$

7.6 CBR (ASTM D1883)

Typical CBR values:

USCS Class	Field CBR
GW	60–80
GP	35–60
GM	40–80
SW	20–40
SP	15–25
ML	5–15

USCS Class	Field CBR
CL	5–15
CH	3–5

7.7 Permeability — Constant Head (ASTM D2434)

$$k = \frac{QL}{tAh}$$

7.8 Permeability — Falling Head

$$k = \frac{aL}{A(t_1 - t_2)} \ln\left(\frac{h_1}{h_2}\right)$$

7.9 SPT Correlations

N_{60} (Sands)	Relative Density
0–4	Very loose
5–10	Loose
11–30	Medium dense
31–50	Dense
> 50	Very dense

N_{60} (Silts/Clays)	Consistency
< 2	Very soft

N_{60} (Silts/Clays)	Consistency
2–4	Soft
5–8	Medium
9–15	Stiff
16–30	Very stiff
> 30	Hard

7.10 Exam Tips

- **Standard Proctor = 12,375 ft-lb/ft³; Modified = 56,250 ft-lb/ft³.**
- **Relative compaction** is the field dry unit weight divided by the lab maximum dry unit weight.
- **CBR** is a bearing ratio test, not a strength test in the traditional sense.
- **SPT N-values** are reliable for sands but unreliable for clays.

8. Asphalt Materials

8.1 Aggregate Specific Gravity

Property	Formula
Apparent specific gravity	A / (A − C)
Bulk specific gravity	A / (B − C)
Bulk specific gravity (SSD)	B / (B − C)

Property	Formula
Water absorption	(B − A) / A × 100%

where:

- A = weight of oven-dry sample in air
- B = weight of saturated surface-dry sample in air
- C = weight of saturated sample in water

8.2 Mix Volumetrics

Term	Formula
Effective specific gravity of aggregate (Gse)	(100 − Pb) / (100/Gmm − Pb/Gb)
Maximum specific gravity (Gmm)	(100) / (Ps/Gse + Pb/Gb)
Asphalt absorption (Pba)	100 × (Gse − Gsb) / (Gsb × Gse) × Gb
Effective asphalt content (Pbe)	Pb − Pba × Ps / 100
Voids in mineral aggregate (VMA)	100 − (Gsb × 100 / Gmb)
Air voids (Pa)	100 × (Gmm − Gmb) / Gmm
VFA	100 × (VMA − Pa) / VMA

8.3 Superpave Design Criteria

Parameter	Requirement
Design air voids	4.0% at N_design

Parameter	Requirement
VMA	Minimum values depend on nominal maximum aggregate size
VFA	Range depends on traffic level
Dust-to-effective asphalt ratio	0.6–1.2

8.4 Exam Tips

- **Gmm is the maximum specific gravity** (no air voids).
- **Gmb is the bulk specific gravity** of the compacted mix.
- **VMA includes air voids and effective asphalt volume.**
- **VFA = (VMA − Pa) / VMA × 100.**
- **Superpave design air voids = 4.0%.**

9. Steel, Masonry, and Wood — Test Methods

9.1 Steel — Tensile Test (ASTM A370 / E8)

Property	Definition
Yield strength (fy)	Stress at which steel begins to deform plastically (0.2% offset for most steels)
Tensile strength (fu)	Maximum stress the steel can withstand before breaking
Elongation	Percent increase in length at fracture

9.2 Reinforcement Properties (ASTM A615/A706)

Bar Size	Diameter (in.)	Area (in^2)	Weight (lb/ft)
#3	0.375	0.11	0.376
#4	0.500	0.20	0.668
#5	0.625	0.31	1.043
#6	0.750	0.44	1.502
#7	0.875	0.60	2.044
#8	1.000	0.79	2.670
#9	1.128	1.00	3.400
#10	1.270	1.27	4.303
#11	1.410	1.56	5.313

9.3 Masonry — Prism Compressive Strength (ASTM C1314)

- Prisms are constructed from masonry units and mortar.
- Tested to determine **fm′** (masonry compressive strength).
- Provides a means of evaluating **in-place masonry construction**.

9.4 Wood — [Outside NCEES scope for detailed test methods]

The NCEES PE Civil: Construction exam does not include detailed wood material test methods in the Reference Handbook. Wood design is covered in the Structural depth, but material testing is not

a primary focus of the Construction depth. Flag any question requiring specific wood test standards (e.g., ASTM D143) as potentially outside the provided reference material.

9.5 Exam Tips

- **Steel tensile test** determines fy and fu — the 0.2% offset method is standard.
- **Reinforcement bar areas** are frequently used in concrete design problems.
- **Masonry prism test** is for fm′ — not for mortar or unit strength individually.

10. Specification Conformance, Documentation, QC/QA Plans

10.1 QC/QA Plan Components

1. **Organization chart** with responsibilities.
2. **Sampling and testing frequencies.**
3. **Test methods and standards** to be used.
4. **Control charts** for key parameters.
5. **Nonconformance procedures.**
6. **Documentation and reporting requirements.**
7. **Personnel qualifications** (e.g., ACI certification).

10.2 Documentation Requirements

- **Daily QC reports** with test results.
- **Control charts** updated in real time.
- **Nonconformance reports** with disposition.
- **As-built records** of all tests.

10.3 Common Field/Laboratory Errors

Test	Common Error	Effect
Slump	Base not firmly supported	Specimen may fall over
Slump	Measuring highest/lowest point	Incorrect slump value
Air content (pressure)	No aggregate correction factor	Incorrect high reading
Air content	Using pressure meter on lightweight concrete	Highly variable, inaccurate
Cylinder fabrication	Improper curing (e.g., left in sun)	Low 28-day breaks
Sampling	Sampling from form instead of truck	Non-representative sample
Sampling	Excessive prewetting of container	Adds water, increases slump, reduces strength
Compaction	Not remixing sample before test	Erroneous slump, air, strength
Yield	Not adjusting for air content change	Over-yield or under-yield

10.4 Exam Tips

- **Documentation is critical** — if it isn't documented, it didn't happen.
- **Nonconformance = stop work** until resolved.
- **Control charts** are required for aggregate gradation, slump, and air content.

11. High-Yield Checklist

□ **Concrete strength acceptance:** Every average of 3 consecutive tests ≥ f′c; no individual test < f′c by more than 500 psi (≤5,000 psi) or 0.10 f′c (>5,000 psi).

□ **Core acceptance:** Average of 3 cores ≥ 85% f′c; no single core < 75% f′c.

□ **Field-cured vs. lab-cured:** Field-cured < 85% of lab-cured → improve curing.

□ **Sampling frequency:** ≥ 1/day, ≥ 1/150 yd^3, ≥ 1/5,000 ft^2; exempt if < 50 yd^3.

□ **Standard Proctor:** ASTM D698 / AASHTO T99; **Modified Proctor:** D1557 / T180.

□ **Relative compaction:** RC = ($\gamma_{d,field}$ / $\gamma_{d,max}$) × 100%.

□ **CBR:** D1883; typical values by USCS.

□ **Atterberg:** PI = LL − PL; LI = (w − PL)/PI.

□ **Gradation:** Cu = D60/D10; Cc = $(D30)^2$/(D10 × D60).

□ **Asphalt volumetrics:** Gmm, Gmb, VMA, Pa, VFA; Superpave design air voids = 4.0%.

□ **Aggregate specific gravity:** Apparent, bulk, SSD; absorption = (B − A)/A × 100.

□ **Concrete cover:** Know the table for cast-in-place nonprestressed members.

□ **Exposure categories:** F, S, W, C classes.

□ **Maturity:** M = $\Sigma(T - T_0)\Delta t$.

□ **Statistical QC:** $\bar{X}$, R, s, control chart formulas.

□ **Common errors:** Slump base support, air content aggregate correction, cylinder curing, sampling from form.

12. Self-Test

1. A concrete mix has f′c = 4,000 psi. The last three consecutive strength tests averaged 3,600 psi. Is the concrete acceptable per ACI 318?

Answer: No. The average of three consecutive tests (3,600 psi) is less than f′c (4,000 psi). This violates the first acceptance criterion.

2. A soil sample has LL = 45 and PL = 22. Compute PI and classify the soil using the A-line.

Answer: PI = 45 − 22 = 23. A-line PI at LL = 45 is 0.73(45 − 20) = 18.25. Since 23 > 18.25, the soil plots above the A-line and is **CL** (lean clay).

3. An asphalt mix has Gmm = 2.450, Gmb = 2.350, and Gsb = 2.650. Compute air voids (Pa), VMA, and VFA.

Answer:

- Pa = 100 × (2.450 − 2.350) / 2.450 = **4.08%**
- VMA = 100 − (2.650 × 100 / 2.350) = 100 − 112.77 = **−12.77%** → **Error in calculation** (check units/approach). Correct: VMA = 100 − (Gsb × 100 / Gmb) = 100 − 112.77 = negative, which indicates an error. **VMA cannot be negative.** The correct formula for VMA (percent of bulk volume) is: VMA = 100 − (Gsb / Gmb) × Ps, where Ps = 100 − Pb. If Pb is not given, VMA cannot be computed directly. This is a **common exam trap** — you need Pb (asphalt content) to compute VMA.

4. A field density test gives γd = 118 pcf. The lab Modified Proctor gives γd,max = 125 pcf. Compute relative compaction.

Answer: RC = (118 / 125) × 100 = **94.4%**.

5. A slump test is run on concrete. The technician does not firmly support the base plate. What is the likely effect?

Answer: The base plate may shake or move, causing the specimen to fall over or distort, resulting in an **erroneous (likely higher) slump reading**.

13. Final Exam Tips

1. **Know the standard numbers** — ASTM and AASHTO designations are frequently tested.

2. **Memorize the concrete acceptance criteria** — this is high-yield.
3. **Practice the volumetric formulas** for asphalt — VMA, VFA, Pa.
4. **Understand the difference between QC and QA** — don't confuse the roles.
5. **Common errors are testable** — know why a test result is wrong.
6. **Control charts are not just for statistics** — they are a QC tool.
7. **Always check units** — pcf vs. kg/m³, psi vs. MPa.
8. **If a detail is not in the Reference Handbook, it may be outside the exam scope** — flag it and move on.

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.

78 web pages

> generate exams questions that cover only this topic under the Material, Production, and Execution Quality Control

Thought for 3 seconds

> The user wants me to generate exam questions covering only the topic of "Material Test Methods and Specification Conformance" under the Material, Production, and Execution Quality Control area of the NCEES PE Civil: Construction exam. I need to create a comprehensive set of practice exam questions that cover all the subtopics I reviewed:
>
> 1. Purpose, roles, and responsibilities in QC and QA
> 2. Specifications, codes, standards, and reference test methods
> 3. Sampling, testing frequency, acceptance criteria, rejection, retest, and nonconformance procedures
> 4. Statistical quality control
> 5. Concrete testing (slump, air content, unit weight, yield, temperature, compressive strength cylinders, field-cured vs. laboratory-cured, core testing)

6. Concrete proportioning and placement (absolute volume, SSD, yield, exposure categories, cover)
7. Concrete maturity and early-strength evaluation
8. Soils and aggregates (moisture content, gradation, Atterberg limits, compaction, field density, relative compaction, CBR, permeability, SPT)
9. Asphalt materials (aggregate specific gravity, mix volumetrics, VMA, air voids, VFA, absorption)
10. Steel, masonry, wood test methods
11. Specification conformance, documentation, QC/QA plans, common field/laboratory errors
12. Common errors, assumptions, and exam traps

I'll generate a variety of question types:

- Multiple choice (4 options)
- Fill-in-the-blank / calculation problems
- Scenario-based questions
- True/False
- Matching

Let me create a comprehensive set of questions with detailed solutions. I'll organize them by subtopic and make them exam-focused. I'll aim for around 40-50 questions to provide thorough coverage.

Let me structure this carefully:

Section A: QC/QA Roles and Responsibilities (3-4 questions)
Section B: Standards and Test Methods (4-5 questions)
Section C: Sampling, Frequency, Acceptance/Rejection (5-6 questions)
Section D: Statistical Quality Control (5-6 questions)
Section E: Concrete Testing (6-7 questions)
Section F: Concrete Proportioning and Placement (4-5 questions)
Section G: Concrete Maturity and Early Strength (3-4 questions)
Section H: Soils and Aggregates (6-7 questions)
Section I: Asphalt Materials (5-6 questions)
Section J: Steel, Masonry, and Other Materials (3-4 questions)
Section K: Specification Conformance and Documentation (3-4 questions)
Section L: Common Errors and Exam Traps (4-5 questions)

Total: ~50 questions

> Let me write them with detailed solutions.

PE Civil: Construction — Material Test Methods & Specification Conformance

Practice Exam Questions

Instructions: Answer all questions. Detailed solutions follow each question. Questions are aligned with the NCEES PE Civil: Construction exam specifications and the PE Civil Reference Handbook, Version 2.0.

Section A: QC/QA Roles and Responsibilities

Question A-1

A contractor is performing quality control testing on a concrete pavement project. The owner's representative arrives on site and performs an independent slump test on the same truck. Which of the following best describes the owner's action?

A) Quality Control (QC)
B) Quality Assurance (QA)
C) Independent Assurance (IA)
D) Acceptance Testing

Answer: B

Solution: Quality Assurance (QA) is the owner's or agency's system of planned actions and procedures to verify that the contractor's QC is functioning properly and that the final product conforms to specifications. The owner's independent verification testing is a QA function. QC is the contractor's production-oriented system. IA is a separate testing program to validate testing equipment, procedures, and personnel — not the same as routine verification testing.

Question A-2

Which of the following is the primary responsibility of the contractor's QC personnel?

A) Verify that the QA laboratory meets ASTM C1077
B) Produce a product that meets the contract requirements
C) Approve nonconformance remediation plans
D) Perform independent assurance testing on the QA laboratory

Answer: B

Solution: QC is production-oriented. The contractor's QC personnel are responsible for producing a product that meets the contract requirements through sampling, testing, control charts, and nonconformance reporting. Verifying the QA lab (A) is an owner function. Approving remediation plans (C) is typically an owner/engineer function. IA testing (D) is a separate owner function.

Question A-3

A testing laboratory performing concrete compressive strength tests must meet which standard?

A) ASTM E329
B) ASTM C1077
C) ASTM D3740
D) ASTM C1314

Answer: B

Solution: ASTM C1077 is the standard practice for agencies testing concrete and concrete aggregates for use in construction. ASTM E329 is for agencies testing construction materials in general (not concrete-specific). ASTM D3740 is for agencies testing soil and rock. ASTM C1314 is the masonry prism compressive strength test method.

Section B: Standards and Test Methods

Question B-1

Which pair of standards correctly matches the Standard Proctor and Modified Proctor compaction tests?

	Standard Proctor	Modified Proctor
A)	ASTM D698 / AASHTO T99	ASTM D1557 / AASHTO T180
B)	ASTM D1557 / AASHTO T180	ASTM D698 / AASHTO T99
C)	ASTM D698 / AASHTO T180	ASTM D1557 / AASHTO T99
D)	ASTM D1557 / AASHTO T99	ASTM D698 / AASHTO T180

Answer: A

Solution: Standard Proctor = ASTM D698 / AASHTO T99 (12,375 ft-lb/ft^3 energy). Modified Proctor = ASTM D1557 / AASHTO T180 (56,250 ft-lb/ft^3 energy). This is high-yield exam content.

Question B-2

A technician is testing a soil sample to determine its liquid limit and plastic limit. Which ASTM standard applies?

A) ASTM D422
B) ASTM D4318
C) ASTM D2216
D) ASTM D1883

Answer: B

Solution: ASTM D4318 is the standard test method for liquid limit, plastic limit, and plasticity index of soils (AASHTO T89 and T90). ASTM D422 is particle-size analysis (gradation). ASTM D2216 is moisture content. ASTM D1883 is CBR.

Question B-3

Which test method is used to determine the bulk specific gravity of a compacted asphalt mixture?

A) ASTM C127
B) ASTM D2041
C) ASTM D2726
D) ASTM C128

Answer: C

Solution: ASTM D2726 is the test method for bulk specific gravity (Gmb) and density of compacted asphalt mixtures. ASTM C127 is for coarse aggregate specific gravity. ASTM D2041 is for maximum specific gravity (Gmm) of asphalt mixtures. ASTM C128 is for fine aggregate specific gravity.

Question B-4

Which AASHTO test designation corresponds to the Standard Proctor compaction test?

A) T180
B) T99
C) T89
D) T88

Answer: B

Solution: AASHTO T99 is Standard Proctor (ASTM D698). AASHTO T180 is Modified Proctor (ASTM D1557). AASHTO T89 is liquid limit. AASHTO T88 is particle-size analysis.

Question B-5

A masonry prism test is performed to determine:

A) Mortar compressive strength
B) Masonry unit compressive strength
C) Masonry assemblage compressive strength (fm′)
D) Grout compressive strength

Answer: C

Solution: ASTM C1314 is the standard test method for compressive strength of masonry prisms. It determines fm′ — the compressive strength of the masonry assemblage (units + mortar). It is not a test of the unit alone (B) or mortar alone (A).

Section C: Sampling, Frequency, Acceptance/Rejection

Question C-1

A concrete project requires 220 yd^3 of a given class of concrete. According to ACI 318, what is the minimum number of strength tests required?

A) 1
B) 2
C) 3
D) 4

Answer: B

Solution: ACI 318 requires strength tests not less than once per day, nor less than once for each 150 yd^3, nor less than once for each 5,000 ft^2 of surface area. For 220 yd^3: 220 / 150 = 1.47 → round up to **2 tests**. Also check daily requirement — if placed in one day, at least 1 test. The 150 yd^3 requirement controls: **2 tests**.

Question C-2

A concrete mix has f′c = 6,000 psi. A single strength test result is 5,300 psi. Is the concrete acceptable?

A) Yes, because 5,300 > 5,000
B) No, because it falls below f′c by more than 500 psi
C) Yes, because it falls below f′c by less than 0.10 f′c
D) No, because it falls below f′c by more than 0.10 f′c

Answer: D

Solution: When f′c > 5,000 psi, no strength test shall fall below f′c by more than 0.10 f′c. 0.10 × 6,000 = 600 psi. 6,000 − 5,300 = 700 psi > 600 psi. Therefore, the test **fails** the acceptance criterion. Note: The 500 psi threshold applies only when f′c ≤ 5,000 psi.

Question C-3

A concrete pour is 45 yd^3 of a single class of concrete. The contractor has historical evidence of satisfactory strength. Is strength testing required?

A) Yes, always required
B) No, if evidence of satisfactory strength is submitted and approved

C) Yes, but only one test is required
D) No, because the quantity is less than 50 yd^3

Answer: B

Solution: Per ACI 318, when the total quantity of a given class of concrete is less than 50 yd^3, strength tests are not required **when evidence of satisfactory strength is submitted to and approved by the building official**. The exemption is conditional on approval.

Question C-4

A concrete core test program is conducted on an existing structure. Three cores give results of 82%, 78%, and 88% of f′c. Is the concrete structurally adequate?

A) Yes, because the average exceeds 85%
B) No, because one core is below 75%
C) Yes, because no core is below 75%
D) No, because the average is below 85%

Answer: A

Solution: The concrete in an area represented by core tests is considered structurally adequate if the **average of three cores is equal to at least 85% of f′c** AND **no single core is less than 75% of f′c**. Average = (82 + 78 + 88) / 3 = 82.7% ≥ 85%? **No** — 82.7% < 85%. Therefore, **not adequate**. Wait — let me recalculate: (82 + 78 + 88) / 3 = 248 / 3 = 82.67%. This is **less than 85%**. So the correct answer should be **D**. Let me re-check: The question states "82%, 78%, and 88%" — average = 82.67% < 85%. So **D is correct**.

Corrected Answer: D

Solution: Average = (82 + 78 + 88) / 3 = 82.67% < 85%. Therefore, the concrete is **not** structurally adequate per the core acceptance criteria. No single core is below 75% (78% > 75%), but the

average fails.

Question C-5

A field-cured cylinder breaks at 3,800 psi. A companion laboratory-cured cylinder breaks at 4,500 psi. f′c = 4,000 psi. What action is required?

A) No action — field-cured exceeds f′c
B) Improve curing procedures — field-cured is less than 85% of lab-cured
C) No action — the 85% limitation does not apply
D) Reject the concrete — field-cured is below f′c

Answer: B

Solution: Field-cured strength (3,800 psi) / Lab-cured strength (4,500 psi) = 84.4% < 85%. Therefore, procedures for protecting and curing concrete shall be improved. The exception (C) applies only if field-cured strength exceeds f′c by more than 500 psi — here it does not (3,800 < 4,000 + 500 = 4,500; actually 3,800 < 4,500, so the exception does not apply).

Question C-6

A concrete mix has f′c = 3,500 psi. The last three consecutive strength tests averaged 3,600 psi. A single test result was 2,900 psi. Is the concrete acceptable?

A) Yes — average of three consecutive tests exceeds f′c, and no test is below f′c by more than 500 psi
B) No — the single test is too low
C) Yes — the average is the only criterion
D) No — the average is insufficient

Answer: A

Solution: Check both criteria:

1. Every arithmetic average of any three consecutive tests ≥ f′c: 3,600 ≥ 3,500 ✓
2. No strength test falls below f′c by more than 500 psi: 3,500 − 2,900 = 600 psi > 500 psi ✗

Wait — 600 psi > 500 psi, so criterion 2 **fails**. Therefore, the concrete is **not acceptable**. Let me re-check: f′c = 3,500 psi. 500 psi threshold applies. 3,500 − 2,900 = 600 psi > 500 psi. So the single test falls below f′c by more than 500 psi. **Answer should be B**.

Corrected Answer: B

Solution: Although the average of three consecutive tests (3,600 psi) exceeds f′c, the single test result of 2,900 psi falls below f′c by 600 psi, which exceeds the 500 psi threshold. Both criteria must be met. Therefore, the concrete is **not acceptable**.

Question C-7

A concrete pour is 180 yd^3. According to ACI 318, what is the minimum number of strength tests required?

A) 1
B) 2
C) 3
D) 4

Answer: B

Solution: 180 yd^3 / 150 yd^3 per test = 1.2 → round up to **2 tests**. Also check: not less than once per day, not less than once per 5,000 ft^2. The 150 yd^3 criterion controls: 2 tests.

Question C-8

A contractor pours concrete on a project requiring 60 yd^3. The concrete is placed in one day. How many strength tests are required?

A) 0
B) 1
C) 2
D) 3

Answer: B

Solution: 60 yd^3 > 50 yd^3, so the exemption does not apply. Not less than once per day = **1 test**. Not less than once per 150 yd^3 = 60/150 < 1 → 1 test. Therefore, **1 test** is required.

Section D: Statistical Quality Control

Question D-1

Given the following five slump test results: 3.5, 4.0, 4.5, 4.0, 5.0 in. Compute the sample standard deviation.

A) 0.50 in.
B) 0.57 in.
C) 0.65 in.
D) 0.71 in.

Answer: B

Solution:

- Mean = (3.5 + 4.0 + 4.5 + 4.0 + 5.0) / 5 = 21.0 / 5 = 4.2 in.
- Deviations: −0.7, −0.2, +0.3, −0.2, +0.8
- Squared deviations: 0.49, 0.04, 0.09, 0.04, 0.64

- Sum = 1.30
- s = √(1.30 / 4) = √0.325 = **0.57 in.**

Question D-2

For an $\bar{X}$-R control chart with n = 4, the grand mean is 4.2 in. and the average range is 1.0 in. What is the upper control limit for the $\bar{X}$ chart?

A) 4.93 in.
B) 5.20 in.
C) 4.93 in.
D) 5.15 in.

Answer: A

Solution: UCL_X = $\bar{\bar{X}} + A_2\bar{R}$. For n = 4, A_2 = 0.729. UCL_X = 4.2 + (0.729)(1.0) = 4.2 + 0.729 = **4.93 in.**

Question D-3

For an R chart with n = 5 and $\bar{R}$ = 2.0, what is the lower control limit?

A) 0
B) 0.42
C) 0.84
D) 1.00

Answer: A

Solution: LCL_R = $D_3\bar{R}$. For n = 5, D_3 = 0. LCL_R = 0 × 2.0 = **0**. The R chart LCL is zero for sample sizes less than 7.

Question D-4

A concrete producer wants to monitor the variability of slump between trucks. Which control chart is most appropriate?

A) $\bar{X}$ chart
B) R chart
C) p chart
D) c chart

Answer: B

Solution: The R chart monitors **range (variability)** within subgroups. The $\bar{X}$ chart monitors the **mean**. For monitoring variability, the R chart (or S chart for larger sample sizes) is appropriate.

Question D-5

An $\bar{X}$-R chart has been established with $\bar{\bar{X}}$ = 4.0 in. and $\bar{R}$ = 1.2 in. for n = 5. A new sample of 5 slump tests gives a mean of 5.1 in. Is the process in control?

A) Yes, because 5.1 > 4.0
B) No, because 5.1 exceeds the UCL
C) Yes, because 5.1 is within 2 standard deviations
D) Cannot determine without the standard deviation

Answer: B

Solution: $UCL_X = \bar{\bar{X}} + A_2\bar{R}$. For n = 5, $A_2 = 0.577$. $UCL_X = 4.0 + (0.577)(1.2) = 4.0 + 0.692 = 4.692$ in. The new sample mean (5.1 in.) exceeds the UCL (4.692 in.). Therefore, the process is **out of control**.

Question D-6

The coefficient of variation (CV) for a set of concrete strength tests is 8%. The mean strength is 4,500 psi. What is the sample standard deviation?

A) 360 psi
B) 450 psi
C) 540 psi
D) 800 psi

Answer: A

Solution: CV = s / $\bar{X}$ → s = CV × $\bar{X}$ = 0.08 × 4,500 = **360 psi**.

Section E: Concrete Testing

Question E-1

A concrete slump test is performed. The technician does not firmly support the base plate. What is the most likely effect on the slump reading?

A) The slump reading will be lower than actual
B) The slump reading will be higher than actual
C) The slump reading will be unaffected
D) The concrete will segregate

Answer: B

Solution: If the base plate is not firmly supported, the concrete may spread outward at the base, causing the specimen to fall or distort. This typically results in a **higher** (erroneous) slump reading. The base plate must be firmly supported and level.

Question E-2

A pressure meter is used to determine the air content of a lightweight concrete sample. What is the primary concern?

A) The pressure meter is not applicable to lightweight concrete
B) The pressure meter will read too low
C) The pressure meter will read too high
D) The pressure meter requires a larger sample

Answer: A

Solution: The pressure method (ASTM C231) is **not applicable to lightweight concrete** because the porous aggregate affects the pressure reading. For lightweight concrete, the volumetric method (ASTM C173) must be used.

Question E-3

A concrete mix has a specified slump of 4 in. ± 1 in. A slump test gives 6.5 in. What is the appropriate action?

A) Accept the concrete — it is within tolerance
B) Reject the concrete — it exceeds the upper tolerance
C) Add water to increase workability
D) Accept with a penalty

Answer: B

Solution: The specified range is 3 in. to 5 in. A slump of 6.5 in. exceeds the upper tolerance (5 in.). The concrete should be **rejected** or evaluated for acceptance per the specifications. Adding water (C) would only make it worse.

Question E-4

A concrete cylinder is tested for compressive strength. The cylinder is 6 in. × 12 in. The failure load is 112,000 lb. What is the compressive strength?

A) 3,500 psi
B) 3,960 psi
C) 4,000 psi
D) 4,500 psi

Answer: B

Solution: Area = π × (6 in.)² / 4 = 28.27 in². f′c = 112,000 lb / 28.27 in² = **3,962 psi** ≈ 3,960 psi.

Question E-5

A concrete mix has a specified air content of 6% ± 1.5%. A pressure meter reading gives 4.0% air. Is the concrete acceptable?

A) Yes — it is within tolerance
B) No — it is below the lower tolerance
C) Yes — air content is not critical
D) No — it is above the upper tolerance

Answer: B

Solution: The specified range is 4.5% to 7.5%. A reading of 4.0% is **below** the lower tolerance (4.5%). The concrete is **not acceptable** and should be rejected or evaluated.

Question E-6

A concrete mix has a unit weight of 145 pcf. The yield is calculated to be 27.5 ft³ per batch. What is the total mass of the batch?

A) 3,988 lb
B) 4,000 lb
C) 4,125 lb
D) 4,250 lb

Answer: A

Solution: Total mass = unit weight × yield = 145 pcf × 27.5 ft³ = **3,987.5 lb** ≈ 3,988 lb.

Question E-7

A slump test is performed on concrete from a truck. The specified slump is 4 in. ± 1 in. The result is 5.5 in. The contractor's QC manager decides to add water to increase workability. What is the likely effect on compressive strength?

A) Compressive strength will increase
B) Compressive strength will decrease
C) Compressive strength will remain unchanged
D) Compressive strength will increase then decrease

Answer: B

Solution: Adding water to concrete increases the water-cement ratio, which **decreases** compressive strength. The slump is already above the upper tolerance (5 in.), so adding water is the wrong action. The concrete should be rejected or evaluated.

Question E-8

A concrete mix has a specified slump of 3 in. ± 1 in. A slump test gives 3.5 in. Is the concrete acceptable?

A) Yes — it is within tolerance
B) No — it is below the lower tolerance
C) Yes — slump is not a strength test
D) No — it is above the upper tolerance

Answer: A

Solution: The specified range is 2 in. to 4 in. A slump of 3.5 in. is **within** the tolerance. The concrete is acceptable with respect to slump.

Section F: Concrete Proportioning and Placement

Question F-1

A concrete mix design uses the absolute volume method. The coarse aggregate has a bulk specific gravity (SSD) of 2.65 and a mass of 1,850 lb. What is the absolute volume of the coarse aggregate?

A) 10.5 ft^3
B) 11.2 ft^3
C) 11.8 ft^3
D) 12.0 ft^3

Answer: B

Solution: Absolute volume = Mass / (Specific Gravity × Unit Weight of Water) = 1,850 / (2.65 × 62.4) = 1,850 / 165.36 = **11.19 ft^3** ≈ 11.2 ft^3.

Question F-2

In concrete mix design, the relative densities of aggregates are based on which condition?

A) Oven-dry
B) Air-dry
C) Saturated surface-dry (SSD)
D) Saturated

Answer: C

Solution: Relative densities of aggregates in mix-design calculations are based on **saturated surface-dry (SSD)** conditions. This accounts for the water absorbed into the aggregate pores while ensuring the aggregate surface is dry.

Question F-3

A concrete mix has a specified compressive strength of 5,000 psi. The exposure category is F2 (freezing and thawing with frequent exposure to water). What is the maximum water-cementitious materials ratio typically required?

A) 0.45
B) 0.50
C) 0.55
D) 0.60

Answer: A

Solution: For F2 exposure (frequent exposure to water), ACI 318 typically requires a maximum w/cm of **0.45** for normal-weight concrete. For F1 (limited exposure), 0.50 is often acceptable. For F3 (deicing chemicals), 0.45 is also typical. The exact value depends on the specific ACI 318 table, but 0.45 is the high-yield answer for F2.

Question F-4

A cast-in-place concrete beam is not exposed to weather or in contact with ground. The primary reinforcement is No. 8 bars. What is the minimum specified concrete cover?

A) ¾ in.
B) 1 in.
C) 1½ in.
D) 2 in.

Answer: C

Solution: Per ACI 318, for beams not exposed to weather or in contact with ground, the specified cover for primary reinforcement (stirrups, ties, spirals, and hoops) is **1½ in.** For slabs, joists, and walls (not exposed), the cover for No. 11 and smaller bars is ¾ in. For No. 14 and No. 18 bars, it is 1½ in.

Question F-5

A concrete mix has a specified slump of 4 in. ± 1 in. The batch plant adds water to the mix to increase the slump from 3 in. to 5 in. What is the effect on the yield?

A) Yield increases
B) Yield decreases
C) Yield remains unchanged
D) Cannot determine

Answer: A

Solution: Adding water increases the total volume of the batch, which **increases** the yield (volume of fresh concrete produced per batch). The yield is calculated as total mass of batched materials

divided by density of freshly mixed concrete.

Question F-6

A concrete mix has a specified air content of 5% ± 1%. The actual air content is 6.5%. What is the effect on the yield?

A) Yield increases
B) Yield decreases
C) Yield remains unchanged
D) Cannot determine

Answer: B

Solution: If the actual air content is higher than specified, the concrete is more porous, which means the same mass of materials occupies a larger volume. However, the yield is calculated as the total mass divided by the density of freshly mixed concrete. Higher air content typically **decreases** the density, which would **increase** the yield for a given mass. Wait — let me reconsider: Yield = total mass / density. If air content increases, density decreases, so yield (volume) increases for the same mass. But in practice, mix designs are adjusted to maintain yield. The question asks about the effect on yield — higher air content → lower density → **higher yield** (more volume per unit mass). So the answer should be A, not B.

Corrected Answer: A

Solution: Higher air content reduces the density of the freshly mixed concrete. Since yield = total mass / density, a lower density results in a **higher yield** (greater volume per batch). This is why air content must be controlled to maintain the specified yield.

Section G: Concrete Maturity and Early-Strength Evaluation

Question G-1

A concrete element has a maturity index of 4,000 °F·hours. The datum temperature is 32°F. If the average concrete temperature was 72°F, how many hours did it take to reach this maturity?

A) 50 hours
B) 80 hours
C) 100 hours
D) 125 hours

Answer: C

Solution: $M = \Sigma(T - T_0)\Delta t$. $4{,}000 = (72 - 32) \times t = 40t$. $t = 4{,}000 / 40 =$ **100 hours**.

Question G-2

Which nondestructive test method is most appropriate for determining the in-place strength of new concrete?

A) Rebound hammer
B) Maturity method
C) Half-cell potential
D) Ground-penetrating radar

Answer: B

Solution: The **maturity method** is specifically used for determining in-place strength of new construction by monitoring the temperature history of the concrete. The rebound hammer (A) measures surface hardness, not strength directly. Half-cell potential (C) measures corrosion activity. GPR (D) is used for locating reinforcement or defects.

Question G-3

A concrete maturity calibration curve gives the following relationship: M = 3,500 °F·hours corresponds to 3,000 psi. If the concrete temperature is maintained at 60°F, how long will it take to reach 3,000 psi? (Datum temperature = 32°F)

A) 100 hours
B) 125 hours
C) 150 hours
D) 175 hours

Answer: B

Solution: $M = (T - T_0) \times t$. $3{,}500 = (60 - 32) \times t = 28t$. $t = 3{,}500 / 28 =$ **125 hours**.

Question G-4

Which of the following is NOT a nondestructive test method for concrete?

A) Pulse velocity
B) Impact-echo
C) Compressive strength cylinder test
D) Rebound hammer

Answer: C

Solution: The compressive strength cylinder test (ASTM C39) is a **destructive** test — the cylinder is loaded to failure. Pulse velocity (A), impact-echo (B), and rebound hammer (D) are all nondestructive test methods.

Question G-5

A concrete element has a maturity index of 2,800 °F·hours. The datum temperature is 32°F. If the concrete temperature was 52°F for the first 50 hours and 72°F for the next 50 hours, what is the total maturity?

A) 2,000 °F·hours
B) 2,800 °F·hours
C) 3,000 °F·hours
D) 3,200 °F·hours

Answer: B

Solution:

- First 50 hours: (52 − 32) × 50 = 20 × 50 = 1,000 °F·hours
- Next 50 hours: (72 − 32) × 50 = 40 × 50 = 2,000 °F·hours
- Total = 1,000 + 2,000 = **3,000 °F·hours**

Wait — the question states "maturity index of 2,800" but the calculation gives 3,000. The question is asking for the total maturity based on the given temperatures. Let me re-read: "A concrete element has a maturity index of 2,800 °F·hours... If the concrete temperature was 52°F for the first 50 hours and 72°F for the next 50 hours, what is the total maturity?" The calculation gives 3,000, not 2,800. The correct answer should be C (3,000). The question may have a typo. I'll correct the answer to C.

Corrected Answer: C

Solution: Total maturity = (52 − 32) × 50 + (72 − 32) × 50 = 1,000 + 2,000 = **3,000 °F·hours**.

Section H: Soils and Aggregates

Question H-1

A soil sample has a liquid limit of 45 and a plastic limit of 22. What is the plasticity index?

A) 18
B) 23
C) 45
D) 67

Answer: B

Solution: PI = LL − PL = 45 − 22 = **23**.

Question H-2

A soil sample has the following gradation: D_{10} = 0.15 mm, D_{30} = 0.45 mm, D_{60} = 1.20 mm. Compute the coefficient of uniformity (Cu).

A) 3.0
B) 6.0
C) 8.0
D) 12.0

Answer: C

Solution: Cu = D_{60} / D_{10} = 1.20 / 0.15 = **8.0**.

Question H-3

Using the data from Question H-2, compute the coefficient of curvature (Cc).

A) 0.89
B) 1.13

C) 2.25
D) 3.00

Answer: B

Solution: $Cc = (D_{30})^2 / (D_{10} \times D_{60}) = (0.45)^2 / (0.15 \times 1.20) = 0.2025 / 0.18 = \mathbf{1.125} \approx 1.13$.

Question H-4

A soil is classified as GW per the Unified Soil Classification System. This means:

A) Well-graded gravel
B) Poorly graded gravel
C) Well-graded sand
D) Poorly graded sand

Answer: A

Solution: GW = Well-graded gravel. GP = Poorly graded gravel. SW = Well-graded sand. SP = Poorly graded sand.

Question H-5

A Standard Proctor compaction test gives a maximum dry unit weight of 115 pcf at an optimum moisture content of 14%. A field density test gives a dry unit weight of 108 pcf. What is the relative compaction?

A) 91.5%
B) 93.9%
C) 95.0%
D) 96.5%

Answer: B

Solution: RC = (γd,field / γd,max) × 100 = (108 / 115) × 100 = **93.9%**.

Question H-6

A Modified Proctor compaction test is performed on a soil sample. Which of the following correctly describes the test?

A) 3 layers, 25 blows per layer, 5.5 lb hammer
B) 5 layers, 25 blows per layer, 10 lb hammer
C) 3 layers, 25 blows per layer, 10 lb hammer
D) 5 layers, 25 blows per layer, 5.5 lb hammer

Answer: B

Solution: Modified Proctor (ASTM D1557 / AASHTO T180): 5 layers, 25 blows per layer, 10 lb hammer, 18 in. drop, 56,250 ft-lb/ft³ energy. Standard Proctor (D698 / T99): 3 layers, 25 blows per layer, 5.5 lb hammer, 12 in. drop, 12,375 ft-lb/ft³ energy.

Question H-7

A soil sample has a moisture content of 18% and a plastic limit of 15%. The plasticity index is 12. What is the liquidity index?

A) 0.25
B) 0.50
C) 0.75
D) 1.00

Answer: A

Solution: LI = (w − PL) / PI = (18 − 15) / 12 = 3 / 12 = **0.25**.

Question H-8

A CBR test is performed on a soil sample. The results are: penetration = 0.1 in., load = 1,200 lb. The standard load for 0.1 in. penetration is 3,000 lb. What is the CBR?

A) 30%
B) 40%
C) 50%
D) 60%

Answer: B

Solution: CBR = (Test load / Standard load) × 100 = (1,200 / 3,000) × 100 = **40%**.

Question H-9

A constant head permeability test is performed. The following data are obtained:

- Q = 150 cm^3
- L = 15 cm
- t = 60 sec
- A = 50 cm^2
- h = 30 cm

What is the coefficient of permeability?

A) 0.025 cm/s
B) 0.050 cm/s

C) 0.075 cm/s
D) 0.100 cm/s

Answer: A

Solution: k = QL / (tAh) = (150 × 15) / (60 × 50 × 30) = 2,250 / 90,000 = **0.025 cm/s**.

Question H-10

An SPT test gives N_{60} = 25 in a sand deposit. What is the relative density of the sand?

A) Very loose
B) Loose
C) Medium dense
D) Dense

Answer: C

Solution: Per the SPT correlation table for sands:

- 0–4: Very loose
- 5–10: Loose
- 11–30: Medium dense
- 31–50: Dense
- > 50: Very dense

N_{60} = 25 falls in the **medium dense** range (11–30).

Section I: Asphalt Materials

Question I-1

An aggregate sample has the following weights:

- A (oven-dry in air) = 500 g
- B (SSD in air) = 510 g
- C (saturated in water) = 310 g

What is the bulk specific gravity (SSD)?

A) 2.50
B) 2.55
C) 2.60
D) 2.65

Answer: B

Solution: Bulk specific gravity (SSD) = B / (B − C) = 510 / (510 − 310) = 510 / 200 = **2.55**.

Question I-2

Using the data from Question I-1, what is the apparent specific gravity?

A) 2.50
B) 2.55
C) 2.63
D) 2.70

Answer: C

Solution: Apparent specific gravity = A / (A − C) = 500 / (500 − 310) = 500 / 190 = **2.63**.

Question I-3

Using the data from Question I-1, what is the water absorption?

A) 1.0%
B) 2.0%
C) 3.0%
D) 4.0%

Answer: B

Solution: Absorption = (B − A) / A × 100 = (510 − 500) / 500 × 100 = 10 / 500 × 100 = **2.0%**.

Question I-4

An asphalt mix has the following properties:

- Gmm = 2.450
- Gmb = 2.350
- Gsb = 2.650
- Pb = 5.5%

Compute the air voids (Pa).

A) 3.5%
B) 4.1%
C) 4.5%
D) 5.0%

Answer: B

Solution: Pa = 100 × (Gmm − Gmb) / Gmm = 100 × (2.450 − 2.350) / 2.450 = 100 × 0.100 / 2.450 = **4.08%** ≈ 4.1%.

Question I-5

Using the data from Question I-4, compute the VMA.

A) 14.5%
B) 15.2%
C) 16.0%
D) 17.5%

Answer: B

Solution: VMA = 100 − (Gsb × (100 − Pb) / Gmb) = 100 − (2.650 × 94.5 / 2.350) = 100 − (250.425 / 2.350) = 100 − 106.56 = **−6.56%** — this is negative, which is impossible. Let me re-check the formula.

The correct formula for VMA is: VMA = 100 − (Gsb / Gmb) × Ps, where Ps = 100 − Pb.

VMA = 100 − (2.650 / 2.350) × 94.5 = 100 − (1.1277 × 94.5) = 100 − 106.56 = **−6.56%** — still negative. This indicates an error in the given data or formula. Let me check the standard formula:

VMA = 100 − (Gsb × Ps / Gmb) — wait, that's what I did. The issue is that Gsb (2.650) > Gmb (2.350), which is unusual. Typically, Gsb < Gmb for a compacted mix. If Gsb > Gmb, the VMA calculation would be negative, which is physically impossible. This suggests the data may be inconsistent.

Let me use the alternative formula: VMA = 100 − (Gsb / Gmb) × (100 − Pb). If Gsb = 2.650, Gmb = 2.350, Pb = 5.5:

VMA = 100 − (2.650/2.350) × 94.5 = 100 − 1.1277 × 94.5 = 100 − 106.56 = negative.

This is a problem. Perhaps the given Gsb should be less than Gmb. Let me adjust: If Gsb = 2.550 instead of 2.650:

VMA = 100 − (2.550/2.350) × 94.5 = 100 − 1.0851 × 94.5 = 100 − 102.54 = negative. Still negative.

The issue is that for a typical asphalt mix, Gsb is around 2.60–2.70, and Gmb is around 2.35–2.45. The formula VMA = 100 − (Gsb/Gmb) × (100 − Pb) can indeed give negative values if Gsb > Gmb, which is common. Wait — that can't be right. Let me reconsider.

Actually, the correct formula for VMA is:

VMA = 100 − (Gsb × (100 − Pb) / Gmb)

Wait — that's what I used. But let me verify with typical values:

Gsb = 2.650, Gmb = 2.350, Pb = 5.5

VMA = 100 − (2.650 × 94.5 / 2.350) = 100 − (250.425 / 2.350) = 100 − 106.56 = −6.56%

This is clearly wrong. The issue is that the formula should be:

VMA = 100 − (Gsb × Ps / Gmb) where Ps = 100 − Pb

But wait — the bulk specific gravity of the aggregate (Gsb) is typically around 2.65, and the bulk specific gravity of the mix (Gmb) is typically around 2.35. So Gsb / Gmb ≈ 1.13, and (Gsb / Gmb) × Ps ≈ 1.13 × 94.5 = 106.8, which is > 100. This gives a negative VMA, which is impossible.

I think the correct formula is:

VMA = 100 − (Gsb × Ps / Gmb)

But this should be: VMA = 100 − (Gsb / Gmb) × Ps

Where Ps = 100 − Pb.

Actually, the correct formula is: VMA = 100 − (Gsb × (100 − Pb) / Gmb)

But this gives negative values. Let me check the standard Asphalt Institute formula:

VMA = 100 − (Gsb / Gmb) × (100 − Pb)

This is the same. The issue is that Gsb is the bulk specific gravity of the aggregate, and Gmb is the bulk specific gravity of the compacted mix. For a typical mix:

- Gsb = 2.650
- Gmb = 2.350
- Pb = 5.5%

VMA = 100 – (2.650 / 2.350) × 94.5 = 100 – 1.1277 × 94.5 = 100 – 106.56 = –6.56%

This is impossible. The error must be in the formula. The correct formula for VMA is:

VMA = 100 – (Gsb × (100 – Pb) / Gmb) — but this is the same.

Wait — I think the issue is that the formula should be:

VMA = 100 – (Gsb / Gmb) × (100 – Pb) — but this assumes that the volume of aggregate is Gsb/Gmb times the volume of the mix. Actually, the volume of aggregate per unit volume of mix is:

Volume of aggregate = (Mass of aggregate) / (Gsb × ρw)

Mass of aggregate = (100 – Pb)% of total mass

Volume of mix = Total mass / (Gmb × ρw)

So VMA = 100 – (Volume of aggregate / Volume of mix) × 100

= 100 – [(100 – Pb) / Gsb] / [100 / Gmb] × 100

= 100 – (100 – Pb) × Gmb / (Gsb × 100) × 100

= 100 – (100 – Pb) × Gmb / Gsb

Let me try this: VMA = 100 – (94.5 × 2.350) / 2.650 = 100 – 222.075 / 2.650 = 100 – 83.80 = **16.20%**

This is more reasonable! So the correct formula is:

VMA = 100 − (Ps × Gmb) / Gsb

where Ps = 100 − Pb.

Let me verify: VMA = 100 − (94.5 × 2.350) / 2.650 = 100 − 83.80 = **16.20%** ≈ 16.2%.

So the answer is approximately **16.2%**, which rounds to **16.0%** (Option C).

Corrected Answer: C

Solution: VMA = 100 − (Ps × Gmb) / Gsb = 100 − (94.5 × 2.350) / 2.650 = 100 − 83.80 = **16.20%** ≈ 16.0%.

Question I-6

Using the data from Questions I-4 and I-5, compute the VFA.

A) 65.0%
B) 70.0%
C) 74.8%
D) 80.0%

Answer: C

Solution: VFA = 100 × (VMA − Pa) / VMA = 100 × (16.20 − 4.08) / 16.20 = 100 × 12.12 / 16.20 = **74.8%**.

Question I-7

In Superpave mix design, what is the target design air void content?

A) 3.0%
B) 4.0%
C) 5.0%
D) 6.0%

Answer: B

Solution: Superpave mix design targets **4.0% air voids** at the design number of gyrations (N_design). This is a high-yield fact.

Question I-8

An asphalt mix has a VMA of 15.5% and air voids of 4.0%. What is the VFA?

A) 68.5%
B) 72.5%
C) 74.2%
D) 78.0%

Answer: C

Solution: VFA = 100 × (VMA − Pa) / VMA = 100 × (15.5 − 4.0) / 15.5 = 100 × 11.5 / 15.5 = **74.2%**.

Section J: Steel, Masonry, and Other Materials

Question J-1

A No. 8 reinforcing bar has a nominal diameter of 1.000 in. What is its nominal area?

A) 0.60 in²
B) 0.79 in²

C) 1.00 in²
D) 1.27 in²

Answer: B

Solution: Per ASTM A615, a No. 8 bar has a nominal area of **0.79 in²**. (No. 7 = 0.60 in², No. 9 = 1.00 in², No. 10 = 1.27 in².)

Question J-2

A steel tensile test is performed on a specimen. The yield strength is determined using which method?

A) 0.2% offset method
B) 0.5% offset method
C) Proportional limit method
D) Ultimate strength method

Answer: A

Solution: The yield strength of steel is typically determined using the **0.2% offset method** (ASTM A370 / E8). A line is drawn parallel to the elastic portion of the stress-strain curve, offset by 0.2% strain. The intersection with the curve defines the yield strength.

Question J-3

A masonry prism test is conducted to determine:

A) Mortar compressive strength
B) Masonry unit compressive strength

C) Masonry assemblage compressive strength (fm′)
D) Grout compressive strength

Answer: C

Solution: ASTM C1314 determines the compressive strength of masonry prisms (fm′), which represents the masonry assemblage (units + mortar). It is not a test of the unit alone or mortar alone.

Question J-4

A No. 5 reinforcing bar has a nominal area of 0.31 in². If the yield strength is 60,000 psi, what is the yield force?

A) 15,500 lb
B) 18,600 lb
C) 20,000 lb
D) 22,500 lb

Answer: B

Solution: Yield force = fy × As = 60,000 psi × 0.31 in² = **18,600 lb**.

Question J-5

Which of the following is NOT a standard test method for steel reinforcement?

A) ASTM A615
B) ASTM A706
C) ASTM C1314
D) ASTM A370

Answer: C

Solution: ASTM C1314 is the masonry prism compressive strength test — not a steel reinforcement test. ASTM A615 (carbon-steel bars), ASTM A706 (low-alloy steel bars), and ASTM A370 (mechanical testing of steel products) are all steel-related standards.

Section K: Specification Conformance and Documentation

Question K-1

A QC/QA plan for a construction project should include all of the following EXCEPT:

A) Sampling and testing frequencies
B) Organization chart with responsibilities
C) Guaranteed passing score on all tests
D) Nonconformance procedures

Answer: C

Solution: A QC/QA plan includes organization, sampling frequencies, test methods, control charts, nonconformance procedures, documentation requirements, and personnel qualifications. It does **not** guarantee passing scores — it is a system to ensure conformance.

Question K-2

A nonconformance is discovered during concrete placement. What is the first action?

A) Continue placement and evaluate later
B) Halt production/placement and notify the engineer

C) Add water to the mix
D) Ignore it if it is minor

Answer: B

Solution: When a nonconformance is discovered, the first action is to **halt production/placement** and **notify the engineer/owner** in writing. Continuing (A) or ignoring (D) is improper. Adding water (C) is not a corrective action for nonconformance.

Question K-3

Which of the following is a common field error in concrete sampling?

A) Sampling from the middle of the truck
B) Sampling from the form
C) Sampling after remixing
D) Sampling from the discharge stream

Answer: B

Solution: Sampling concrete from the **form** (rather than from the truck discharge) is a common error. The sample must be representative of the batch being placed. Sampling from the discharge stream (D) is correct. Remixing before sampling (C) is also correct.

Question K-4

A concrete cylinder is left in the sun after fabrication. What is the likely effect on the 28-day compressive strength?

A) Strength will increase
B) Strength will decrease

C) Strength will remain unchanged
D) Strength will be unaffected

Answer: B

Solution: Leaving a cylinder in the sun causes rapid moisture loss and improper curing, which **decreases** the 28-day compressive strength. Proper curing (ASTM C31) requires protection from the elements and controlled temperature/moisture conditions.

Question K-5

A slump test is performed on concrete from a truck. The technician does not remix the sample before testing. What is the likely effect?

A) Slump will be higher than actual
B) Slump will be lower than actual
C) Slump will be unaffected
D) The sample will segregate

Answer: A

Solution: If the sample is not remixed before testing, the concrete may have segregated during transport, with water rising to the top. This can result in a **higher** slump reading than the actual representative slump. The sample must be remixed before testing.

Section L: Common Errors and Exam Traps

Question L-1

A concrete mix has f′c = 4,500 psi. A single strength test gives 3,900 psi. Is the concrete acceptable?

A) Yes — it is within 500 psi of f′c
B) No — it falls below f′c by more than 500 psi
C) Yes — it is within 0.10 f′c
D) No — it falls below f′c by more than 0.10 f′c

Answer: A

Solution: f′c = 4,500 psi ≤ 5,000 psi, so the 500 psi threshold applies. 4,500 − 3,900 = 600 psi > 500 psi. Therefore, the test **fails** the acceptance criterion. The correct answer is **B**, not A.

Wait — 600 > 500, so it fails. The answer should be B.

Corrected Answer: B

Solution: f′c = 4,500 psi. The 500 psi threshold applies. 4,500 − 3,900 = 600 psi > 500 psi. The single test falls below f′c by more than 500 psi. Therefore, the concrete is **not acceptable** based on this individual test (even though the average of three consecutive tests must also be checked).

Question L-2

A pressure meter is used to determine the air content of a lightweight concrete sample. What is the primary concern?

A) The pressure meter is not applicable to lightweight concrete
B) The pressure meter will read too low
C) The pressure meter will read too high
D) The pressure meter requires a larger sample

Answer: A

Solution: The pressure method (ASTM C231) is **not applicable to lightweight concrete** because the porous aggregate affects the pressure reading. The volumetric method (ASTM C173) must be used for lightweight concrete.

Question L-3

A concrete mix has a specified slump of 4 in. ± 1 in. The actual slump is 5.5 in. The contractor adds water to increase workability. What is the effect on the water-cement ratio?

A) Water-cement ratio increases
B) Water-cement ratio decreases
C) Water-cement ratio remains unchanged
D) Cannot determine

Answer: A

Solution: Adding water increases the water-cement ratio, which **decreases** compressive strength. The slump is already above the upper tolerance (5 in.), so adding water is the wrong action. The concrete should be rejected or evaluated.

Question L-4

A field density test gives a dry unit weight of 120 pcf. The lab Standard Proctor gives a maximum dry unit weight of 125 pcf. What is the relative compaction?

A) 92%
B) 94%
C) 96%
D) 98%

Answer: C

Solution: RC = (120 / 125) × 100 = **96%**.

Question L-5

A soil sample has a liquid limit of 55 and a plastic limit of 25. What is the plasticity index?

A) 20
B) 25
C) 30
D) 35

Answer: C

Solution: PI = LL − PL = 55 − 25 = **30**.

Question L-6

A concrete mix has a specified air content of 6% ± 1.5%. A pressure meter reading gives 7.8% air. Is the concrete acceptable?

A) Yes — it is within tolerance
B) No — it is below the lower tolerance
C) Yes — air content is not critical
D) No — it is above the upper tolerance

Answer: D

Solution: The specified range is 4.5% to 7.5%. A reading of 7.8% is **above** the upper tolerance (7.5%). The concrete is **not acceptable**.

Question L-7

A concrete cylinder is tested for compressive strength. The cylinder is 4 in. × 8 in. The failure load is 50,000 lb. What is the compressive strength?

A) 3,500 psi
B) 3,980 psi
C) 4,200 psi
D) 4,500 psi

Answer: B

Solution: Area = $\pi \times (4\text{ in.})^2 / 4 = 12.57\text{ in}^2$. $f'c = 50{,}000\text{ lb} / 12.57\text{ in}^2 =$ **3,978 psi** ≈ 3,980 psi.

Question L-8

A concrete mix has a specified slump of 3 in. ± 1 in. A slump test gives 2.5 in. Is the concrete acceptable?

A) Yes — it is within tolerance
B) No — it is below the lower tolerance
C) Yes — slump is not a strength test
D) No — it is above the upper tolerance

Answer: A

Solution: The specified range is 2 in. to 4 in. A slump of 2.5 in. is **within** the tolerance. The concrete is acceptable with respect to slump.

Question L-9

An $\bar{\bar{X}}$-R control chart has been established with $\bar{\bar{X}}$ = 4.0 in. and $\bar{R}$ = 1.2 in. for n = 5. A new sample of 5 slump tests gives a mean of 4.8 in. Is the process in control?

A) Yes, because 4.8 > 4.0
B) No, because 4.8 exceeds the UCL
C) Yes, because 4.8 is within 2 standard deviations
D) Cannot determine without the standard deviation

Answer: B

Solution: UCL_X = $\bar{\bar{X}}$ + $A_2\bar{R}$. For n = 5, A_2 = 0.577. UCL_X = 4.0 + (0.577)(1.2) = 4.0 + 0.692 = 4.692 in. The new sample mean (4.8 in.) exceeds the UCL (4.692 in.). Therefore, the process is **out of control**.

Question L-10

A concrete mix has f′c = 5,000 psi. A single strength test gives 4,400 psi. Is the concrete acceptable?

A) Yes — it is within 500 psi of f′c
B) No — it falls below f′c by more than 500 psi
C) Yes — it is within 0.10 f′c
D) No — it falls below f′c by more than 0.10 f′c

Answer: B

Solution: f′c = 5,000 psi ≤ 5,000 psi, so the 500 psi threshold applies. 5,000 − 4,400 = 600 psi > 500 psi. Therefore, the test **fails** the acceptance criterion. The correct answer is **B**.

Answer Key Summary

Question	Answer	Question	Answer
A-1	B	E-8	A
A-2	B	F-1	B
A-3	B	F-2	C
B-1	A	F-3	A
B-2	B	F-4	C
B-3	C	F-5	A
B-4	B	F-6	A
B-5	C	G-1	C
C-1	B	G-2	B
C-2	D	G-3	B
C-3	B	G-4	C
C-4	D	G-5	C
C-5	B	H-1	B
C-6	B	H-2	C
C-7	B	H-3	B
C-8	B	H-4	A
D-1	B	H-5	B

Question	Answer	Question	Answer
D-2	A	H-6	B
D-3	A	H-7	A
D-4	B	H-8	B
D-5	B	H-9	A
D-6	A	H-10	C
E-1	B	I-1	B
E-2	A	I-2	C
E-3	B	I-3	B
E-4	B	I-4	B
E-5	B	I-5	C
E-6	A	I-6	C
E-7	B	I-7	B
		I-8	C
		J-1	B
		J-2	A
		J-3	C
		J-4	B

Question	Answer	Question	Answer
		J-5	C
		K-1	C
		K-2	B
		K-3	B
		K-4	B
		K-5	A
		L-1	B
		L-2	A
		L-3	A
		L-4	C
		L-5	C
		L-6	D
		L-7	B
		L-8	A
		L-9	B
		L-10	B

Note: These questions are designed to simulate the NCEES PE Civil: Construction exam content under Material Test Methods and Specification Conformance. They do not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.

Act as a licensed PE an...
TXT 3.06KB

Thought for 6 seconds

用户要求我以持证PE和NCEES PE Civil: Construction考试讲师的身份，提供一份关于"焊接和螺栓安装"的全面复习资料。我需要严格遵循PE Civil Reference Handbook v2.0（特别是Section 4.2.1, 4.2.3）以及AISC和RCSC规范的相关规定。复习内容需要涵盖焊接工艺、焊缝类型、焊接符号、焊缝尺寸与承载力、焊接检验、螺栓类型与等级、螺栓连接类型、安装方法、预拉力、孔径类型、间距要求、螺栓承载力、紧固件群分析以及QC/QA等所有子主题。我需要提供定义、公式、步骤、示例、考试技巧，并包含练习题、高收益检查清单和自测题。为了全面获取所需信息，我将进行多项搜索，涵盖焊接工艺、焊缝符号、螺栓安装、RCSC规范、AISC规范、测试标准、质量控制以及考试准备资源等方面。

Found 76 web pages

搜索结果显示了一些相关页面。为了全面获取信息，我们需要同时打开这些页面。

Read 6 pages

Master Steel Connections: Bolted Shear/tension and Welded Fillet/groove (AISC) on the PE Exam (Civil) ↗

Free PE Construction Cheat Sheet 2026: Exam Quick Reference | OpenExamPrep ↗

Welded Steel Connections — Free Study Guide 2026 ↗

Approved Methods of Tensioning High- Strength Bolted Connections ↗

\[k_{ds} = 1.0 + 0.0350 + 0.2950^2 \tag{3.46}\] ↗ View All

这些资料提供了关于焊接和螺栓安装的详细信息。为了更全面地覆盖用户要求的各个子主题，我们需要同时进行多项搜索。

Found 73 web pages

这些搜索结果提供了关于焊接符号、螺栓孔类型、边距要求、螺栓强度、焊接缺陷、QC/QA角色、螺栓群分析以及考试技巧的详细信息。现在我需要组织一份全面的复习资料。我的回答将严格围绕用户要求的焊接和螺栓安装主题，并引

> 用PE Civil Reference Handbook、AISC和RCSC规范。我会确保内容涵盖所有子主题，并提供定义、公式、步骤、示例、考试技巧和练习题。为了全面获取所需信息，我将同时进行多项搜索，以填补任何可能存在的知识空白。

Found 58 web pages

> 现在需要组织一份全面的复习资料。我将按照用户要求的格式来组织内容，包括焊接和螺栓安装两大部分，涵盖定义、公式、步骤、示例、考试技巧和练习题。我会引用PE Civil Reference Handbook、AISC和RCSC规范。现在开始撰写。

PE Civil: Construction — Weld and Bolt Installation

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to Weld and Bolt Installation under Section 2.5 (Material Quality Control and Production) of the NCEES PE Civil: Construction exam. Content is aligned with PE Civil Reference Handbook v2.0 Sections 4.2.1 (Fastener Groups in Shear) and 4.2.3 (Basic Welding Symbols), and related AISC/RCSC provisions referenced therein. Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**.

PART 1: WELDING

1. Welding Processes

Process	Full Name	Key Characteristics	Common Electrodes
SMAW	Shielded Metal Arc Welding	"Stick" welding; flux-coated electrode; slag shield; all positions; most common for field welding	E60XX, E70XX

Process	Full Name	Key Characteristics	Common Electrodes
GMAW	Gas Metal Arc Welding	"MIG" welding; continuous wire electrode; external shielding gas; high deposition rate	ER70S-6
FCAW	Flux-Cored Arc Welding	Tubular wire with flux core; may or may not require shielding gas; high deposition rate; good for field	E70T-1, E71T-1
SAW	Submerged Arc Welding	Granular flux blanket; high current; deep penetration; flat position only; shop welding	F7A2-EM12K

Exam Tip: SMAW and FCAW are most common for field welding. SAW is shop-only (flat position). E70XX indicates 70 ksi tensile strength electrode.

2. Weld Types and Joints

Weld Type	Symbol	Description	Effective Throat
Fillet	△	Triangular cross-section; joins two surfaces at angle	0.707 × leg size (equal-leg, 90°)
Groove — V	V	Beveled edges form V groove	Depends on CJP or PJP
Groove — Bevel	／	One beveled edge	Depends on CJP or PJP
Groove — J	J	J-shaped edge preparation	Depends on CJP or PJP
Groove — U	U	U-shaped edge preparation	Depends on CJP or PJP
Groove — Square	‖	Square edges, no bevel	Full thickness (CJP)
Plug	⊙	Circular hole filled with weld	Plug area


Weld Type	Symbol	Description	Effective Throat
Slot	▭	Elongated hole filled with weld	Slot area
Flare V	╲╱	Formed by two curved surfaces	Per AISC Table J2.1
Flare Bevel	╱	Formed by curved and flat surface	Per AISC Table J2.1

Key Distinctions:

- **CJP (Complete Joint Penetration):** Weld extends through full thickness; strength matches base metal
- **PJP (Partial Joint Penetration):** Weld extends through specified depth; effective throat from AISC Table J2.1 [1]

3. Basic Welding Symbols (Per Handbook Section 4.2.3)

text



Element	Location	Meaning
Reference Line	Horizontal line	Always required; weld symbol sits on it
Arrow	Connects reference line to joint	Points to member to be welded
Tail	Left end of reference line	Process/specification reference (omitted if not used)
Size	Left of weld symbol	Leg size (fillet) or groove depth
Length	Right of weld symbol	Length of weld in inches
Pitch	Right of length	Center-to-center spacing of intermittent welds
All-Around	Circle at reference line-arrow junction	Weld continues around entire joint
Field Weld	Flag at reference line-arrow junction	Weld made in field, not shop
Contour	Line above weld symbol	Finish contour (flush, convex, concave)
Finish	Letter above contour symbol	Finishing method (G = grinding, M = machining)

Reading the Symbol (order): Size → Weld Symbol → Length → Pitch

Example: `¼ △ 6-12` means: ¼-in. fillet weld, 6-in. length, 12-in. pitch (intermittent).

Critical Rule: The perpendicular leg of the fillet symbol must be on the left. Dimensions must read left to right in that order.

4. Weld Sizing

4.1 Fillet Weld Effective Throat

$$t_e = 0.707 \times w$$

where:

- t_e = effective throat (in.)
- w = fillet weld leg size (in.)
- 0.707 = cos 45° (for equal-leg 90° fillet)

Effective Area:

$$A_{we} = t_e \times L_e$$

where L_e = effective length (in.).

4.2 Minimum Fillet Weld Size (AISC Table J2.4)

Thickness of Thinner Part Joined (in.)	Minimum Fillet Weld Size (in.)
≤ ¼	⅛
> ¼ to ½	3⁄16
> ½ to ¾	¼
> ¾	5⁄16

4.3 Maximum Fillet Weld Size

- For material < ¼ in. thick: weld size = material thickness
- For material ≥ ¼ in. thick: weld size = material thickness – 1⁄16 in. (unless specifically approved)

4.4 Effective Length

- Minimum effective length: 4 × weld size
- If end returns are used, they may be counted in effective length
- If a problem states effective length, do not subtract end correction again [13]

5. Weld Capacity

5.1 Fillet Weld Strength (AISC 360 Chapter J)

$$\phi R_n = \phi(0.60F_{EXX})A_{we}$$

where:

- $\phi = 0.75$ (LRFD)
- F_{EXX} = electrode classification strength (e.g., 70 ksi for E70XX)
- $A_{we} = 0.707 \times w \times L_e$

Simplified per inch of weld:

$$\phi r_n = 0.75 \times 0.60 \times F_{EXX} \times 0.707 \times w$$

For E70XX, ¼-in. fillet, per inch:

$$\phi r_n = 0.75 \times 0.60 \times 70 \times 0.707 \times 0.25 = 5.57 \text{ kips/in.}$$

5.2 Groove Weld Strength

Weld Type	Tension	Shear
CJP	Same as base metal ($\phi F_y A_g$)	Same as base metal
PJP	$\phi(0.60F_{EXX})A_{we}$	$\phi(0.60F_{EXX})A_{we}$

For PJP, effective throat from AISC Table J2.1 — depends on groove angle and depth.

5.3 Base Metal Strength

Must also check connected material:

- **Yielding:** $\phi R_n = \phi F_y A_g$ ($\phi = 0.90$)
- **Rupture:** $\phi R_n = \phi F_u A_e$ ($\phi = 0.75$)

Critical: A strong weld on a thin plate can move failure into the plate.

6. Welding Positions (AWS)

Position	AWS Designation	Description	Difficulty
Flat	1G / 1F	Weld axis horizontal; welder above joint	Easiest
Horizontal	2G / 2F	Weld axis horizontal; out-of-position	Moderate
Vertical	3G / 3F	Weld axis vertical	Difficult
Overhead	4G / 4F	Welder below joint	Most difficult

Exam Tip: Flat is easiest; overhead is most difficult. Field welding is often vertical or overhead.

7. Prequalified Joints, WPS, PQR, Welder Qualification

Document	Purpose	Key Content
WPS (Welding Procedure Specification)	Written procedure for production welding	Process, electrode, current, voltage, travel speed, joint details

Document	Purpose	Key Content
PQR (Procedure Qualification Record)	Record of test welding to qualify WPS	Test results, mechanical properties
WPQ (Welder Performance Qualification)	Certifies individual welder	Position, process, thickness range

Prequalified Joints: AWS D1.1 prequalified joints do not require PQR testing if WPS meets all prequalified conditions.

8. Weld Inspection and NDT

Method	Abbreviation	Detects	Surface/Internal
Visual	VT	Surface defects, size, profile	Surface
Liquid Penetrant	PT	Surface-breaking defects	Surface
Magnetic Particle	MT	Surface and near-surface defects	Surface/near-surface
Ultrasonic	UT	Internal defects, planar flaws	Internal
Radiographic	RT	Internal defects, volumetric flaws	Internal

Acceptance Criteria: Per AWS D1.1 — cracks, lack of fusion, and incomplete penetration are generally unacceptable.

9. Common Welding Defects

Defect	Description	Cause	Criticality
Porosity	Gas voids in weld metal	Moisture, contamination, wrong current	Volumetric
Slag Inclusion	Non-metallic slag trapped in weld	Improper cleaning between passes	Volumetric
Incomplete Fusion	Weld metal not fused to base metal	Low current, wrong angle, fast travel	Planar (critical)
Incomplete Penetration	Weld does not extend through joint	Insufficient current, wrong joint prep	Planar (critical)
Undercut	Groove melted into base metal along weld toe	Excessive current, wrong angle	Planar (critical)
Cracks	Fracture in weld or HAZ	Hydrogen, restraint, rapid cooling	Most critical

Exam Tip: Planar defects (cracks, incomplete fusion, incomplete penetration, undercut) are more critical than volumetric defects (porosity, slag).

PART 2: BOLTING

10. Bolt Types and Grades

Grade	Specification	Min. Tensile Strength	Typical Use
A307	ASTM A307	60 ksi	Low-strength; light connections
A325	ASTM A325 / F3125	120 ksi (½–1 in.)	High-strength; most common
A490	ASTM A490 / F3125	150 ksi	High-strength; larger diameter

Grade	Specification	Min. Tensile Strength	Typical Use
F1554	ASTM F1554	36/55/105 ksi	Anchor bolts

Key Distinction: A325 and A490 are high-strength bolts requiring pretensioning for slip-critical connections.

11. Bolted Connection Types

Type	Load Transfer	Pretension Required?	Faying Surface Condition
Bearing	Shear on bolt + bearing on plate	No (snug-tight acceptable)	Any
Slip-Critical	Friction between faying surfaces	Yes	Clean, specified slip coefficient
Tension	Axial tension on bolt	No (but often pretensioned)	Any
Combined Shear + Tension	Interaction	Per specification	Any

12. Bolt Installation Methods (RCSC Specification)

Method	How It Works	Key Requirement
Turn-of-Nut	Snug tight + specified rotation	Match-marking required; rotation depends on bolt length/diameter [20]
Calibrated Wrench	Wrench calibrated to stall at required torque	Must be set to 5% above minimum tension; daily calibration required
Twist-Off	Splined end shears at specified torque	Tension-control bolts; visual verification

Method	How It Works	Key Requirement
DTI	Compressible washer indicates tension	Feeler gauge check of gap; gap must be ≤ calibrated value

Turn-of-Nut Rotation (RCSC Table 2.4):

Bolt Length	Rotation
≤ 4 × diameter	⅓ turn
> 4 × diameter but ≤ 8 × diameter	½ turn
> 8 × diameter	⅔ turn

13. Bolt Pretensioning

Minimum Bolt Pretension (RCSC Table J3.1 / Table 5.2):

Bolt Size (in.)	A325 (kips)	A490 (kips)
½	12	15
⅝	19	24
¾	28	35
⅞	39	49
1	51	64

Target pretension ≈ 70% of bolt ultimate tensile strength.

14. Bolt Hole Types (AISC Table J3.3)

Hole Type	Description	Washer Required?
Standard	d + 1/16 in.	No
Oversized	d + 1/8 in. (for d ≤ 1 in.)	Yes
Short-Slotted	(d + 1/16) × (d + 1/4)	Yes
Long-Slotted	(d + 1/16) × (d + 2.5)	Yes

Slip Resistance: Oversized and short-slotted holes have the same slip resistance as standard holes when washers are used per RCSC.

15. Bolt Spacing and Edge Distance (AISC Section J3.4/J3.5)

Parameter	Requirement
Minimum spacing	2⅔ × d (preferred: 3 × d)
Maximum spacing	12 × t (thickness of thinner plate), ≤ 6 in.
Minimum edge distance	Per AISC Table J3.4 (varies by bolt diameter and edge condition)
Maximum edge distance	12 × t, ≤ 6 in.

Typical Minimum Edge Distances (sheared edges):

Bolt Diameter (in.)	Min. Edge Distance (in.)
½	⅞
⅝	1⅛
¾	1¼
⅞	1½
1	1¾

16. Bolt Strength (AISC Table J3.2)

16.1 Bolt Shear

$$\phi R_n = \phi F_{nv} A_b$$

where:

- $\phi = 0.75$ (LRFD)
- F_{nv} = nominal shear stress from AISC Table J3.2
- A_b = nominal bolt area

Shear Stress Values (AISC Table J3.2):

Bolt Grade	Threads Included in Shear Plane	Threads Excluded from Shear Plane
A325	54 ksi	68 ksi
A490	68 ksi	84 ksi

16.2 Bolt Tension

$$\phi R_n = \phi F_{nt} A_b$$

where F_{nt} = nominal tensile stress from AISC Table J3.2.

Bolt Grade	F_{nt} (ksi)
A325	90
A490	113

16.3 Bearing and Tearout (AISC Section J3.10)

Bearing:

$$\phi R_n = \phi(2.4 d t F_u)$$

$$\phi = 0.75$$

Tearout:

$$\phi R_n = \phi(1.2 L_c t F_u)$$

$$L_c = \text{clear distance} = \text{edge distance} - \frac{d + 1/16}{2}$$

Governing: The smaller of bearing and tearout controls.

16.4 Combined Shear and Tension

$$\left(\frac{T_u}{\phi R_{nt}}\right)^2 + \left(\frac{V_u}{\phi R_{nv}}\right)^2 \leq 1.0$$

17. Fastener Group Analysis (Handbook Section 4.2.1)

17.1 Centroid of Bolt Group

$$\bar{x} = \frac{\sum A_i x_i}{\sum A_i}, \quad \bar{y} = \frac{\sum A_i y_i}{\sum A_i}$$

For equal bolt areas: $\bar{x} = \frac{\sum x_i}{n}, \bar{y} = \frac{\sum y_i}{n}$

17.2 Direct Shear Force

$$F_{direct} = \frac{P}{n}$$

where P = applied load, n = number of bolts. Acts in same direction as P.

17.3 Moment-Induced Shear Force

$$F_{moment,i} = \frac{M r_i}{\sum r_i^2}$$

where:

- $M = P \times e$ (eccentricity)
- r_i = distance from centroid to bolt i
- Acts perpendicular to line from centroid to bolt

17.4 Total Shear Force

$$F_{total,i} = \sqrt{F_{direct}^2 + F_{moment,i}^2 + 2F_{direct}F_{moment,i}\cos\theta}$$

Vector addition required. Critical bolt is typically the one farthest from centroid and oriented unfavorably relative to direct shear direction.

18. Special Inspection Requirements

Connection Type	Inspection Required
Snug-tight bearing	Visual inspection
Pretensioned	Pre-installation verification + visual + torque/tension check
Slip-critical	Pre-installation verification + visual + 10% torque inspection

Pre-installation Verification: Three bolts of each diameter, length, grade, and lot must be tested in a Skidmore-Wilhelm calibrator to verify that the installation method develops ≥ 1.05 × required pretension. [60]

19. Common Bolting Defects

Defect	Cause	Consequence
Loose bolts	Inadequate pretensioning	Slip-critical failure
Incorrect torque	Wrench not calibrated	Insufficient clamping force
Improper hole alignment	Misaligned members	Forced fit, bolt bending
Threads in shear plane	Wrong bolt length	Reduced shear strength
Inadequate edge distance	Layout error	Tearout failure
Unfilled holes	Missing bolts	Load redistribution

PART 3: QUALITY CONTROL AND CONFORMANCE

20. QC/QA Roles and Responsibilities

Role	Responsibility
Contractor QC	Sampling, testing, control charts, nonconformance reporting
Owner QA	Independent verification testing, acceptance evaluation
Special Inspector	Continuous or periodic inspection of welding/bolting per IBC
Weld Inspector	Visual and NDT inspection per AWS D1.1

21. Documentation and Submittals

- **WPS/PQR/WPQ** submittals for welding
- **Bolt installation procedure** for bolting
- **Pre-installation verification reports**
- **NDT reports** (UT, RT, MT, PT)
- **Daily inspection reports**
- **Nonconformance reports (NCRs)**

22. Common Errors, Assumptions, and Exam Traps

Trap	Correct Approach
Using bolt gross area instead of nominal area	Use A_b from AISC Table 7-1
Forgetting bearing/tearout check	Always check both; smallest controls
Using wrong F_{nv} for threads in shear plane	Threads included: 54 ksi (A325); excluded: 68 ksi
Adding direct and moment shear algebraically	Must use vector addition

Trap	Correct Approach
Assuming CJP groove weld needs strength check	CJP matches base metal; no weld strength check needed
Forgetting minimum fillet weld size	Check AISC Table J2.4
Using leg size as effective throat	$t_e = 0.707 \times w$
Ignoring edge distance for tearout	$L_c = L_e - (d + 1/16)/2$
Using wrong rotation for turn-of-nut	Depends on bolt length relative to diameter

PART 4: PRACTICE PROBLEMS

Problem 1 — Fillet Weld Strength

A ¼-in. fillet weld using E70XX electrode is applied on both sides of a plate. Each weld is 8 in. long. Determine the LRFD design strength of the weld group.

Solution:

- Effective throat: $t_e = 0.707 \times 0.25 = 0.1768$ in.
- Total effective length: $L_e = 2 \times 8 = 16$ in.
- Effective area: $A_{we} = 0.1768 \times 16 = 2.829$ in²
- Nominal strength: $R_n = 0.60 \times 70 \times 2.829 = 118.8$ kips
- Design strength: $\phi R_n = 0.75 \times 118.8 = \mathbf{89.1}$ kips

Problem 2 — Bolt Shear and Bearing

A connection uses three ⅞-in. A325-N bolts (threads included in shear plane) in standard holes. Plate thickness = ½ in., $F_u = 58$ ksi. Edge distance = 1½ in., spacing = 3 in. Determine the controlling LRFD design strength.

Solution:

Bolt Shear (per bolt):

- $A_b = 0.6013$ in² (AISC Table 7-1)
- $\phi R_n = 0.75 \times 54 \times 0.6013 = 24.35$ kips/bolt
- Total: $3 \times 24.35 = \mathbf{73.1}$ kips

Bearing (interior bolt):

- $\phi R_n = 0.75 \times 2.4 \times 0.875 \times 0.50 \times 58 = 45.7$ kips

Tearout (end bolt):

- $L_c = 1.5 - (0.875 + 0.0625)/2 = 1.031$ in.
- $\phi R_n = 0.75 \times 1.2 \times 1.031 \times 0.50 \times 58 = 26.9$ kips


Controlling: Bolt shear governs: **73.1 kips** [1]

Problem 3 — Reading a Welding Symbol

Interpret the following welding symbol:

```
text

        ┌──────────────────────────┐
        │  ¼  △  6-12              │
        │  REFERENCE LINE          │
```



Answer:

- ¼-in. fillet weld
- 6-in. length
- 12-in. pitch (intermittent)
- SMAW process
- Arrow side weld (symbol below reference line)

Problem 4 — Bolt Group Eccentric Shear

A bracket is bolted with four ¾-in. A325 bolts in a rectangular pattern: (0,0), (3,0), (0,4), (3,4). An eccentric load $P = 20$ kips acts at a distance $e = 6$ in. from the centroid. Determine the maximum bolt force.

Solution:

Centroid: $\bar{x} = 1.5$ in., $\bar{y} = 2.0$ in.

Direct shear: $F_{direct} = 20/4 = 5.0$ kips

Moment: $M = 20 \times 6 = 120$ kip-in.

$\sum r_i^2$:

- Bolt 1: $(1.5)^2 + (2.0)^2 = 6.25$
- Bolt 2: $(1.5)^2 + (2.0)^2 = 6.25$
- Bolt 3: $(1.5)^2 + (2.0)^2 = 6.25$

- Bolt 4: $(1.5)^2 + (2.0)^2 = 6.25$
- $\sum r_i^2 = 25.0$

Moment force on critical bolt (max r = 2.5 in.):

$$F_{moment} = \frac{120 \times 2.5}{25.0} = 12.0 \text{ kips}$$

Total force (vector addition): Depends on direction. Conservative estimate:

$$F_{total} = 5.0 + 12.0 = \mathbf{17.0} \text{ kips}$$

Problem 5 — Minimum Fillet Weld Size

A fillet weld is applied to a plate with thickness $t = ⅜$ in. What is the minimum fillet weld size required by AISC Table J2.4?

Answer: For $t >$ ¼ to ½ in., minimum weld size = **3⁄16 in.**

Problem 6 — Pretension Verification

A slip-critical connection uses ¾-in. A325 bolts. What is the minimum required pretension, and what must the pre-installation verification demonstrate?

Answer:

- Minimum pretension: **28 kips** (RCSC Table J3.1)
- Pre-installation verification must demonstrate ≥ **1.05 × 28 = 29.4 kips** using three representative bolts in a Skidmore-Wilhelm calibrator.

Problem 7 — Weld Defect Identification

A UT inspection reveals a planar indication in a CJP groove weld. Which of the following is the most likely defect?

A) Porosity
B) Slag inclusion
C) Incomplete fusion
D) Undercut

Answer: C

Solution: UT detects planar flaws well. Incomplete fusion is a planar defect. Porosity and slag are volumetric (more readily detected by RT). Undercut is surface (VT/MT/PT).

Problem 8 — Bolt Bearing vs. Tearout

A ¾-in. bolt is placed 1¼ in. from the edge of a ⅜-in. plate ($F_u = 58$ ksi). Which limit state controls: bearing or tearout?

Solution:

Bearing:

$$\phi R_n = 0.75 \times 2.4 \times 0.75 \times 0.375 \times 58 = 29.4 \text{ kips}$$

Tearout:

$$L_c = 1.25 - (0.75 + 0.0625)/2 = 0.844 \text{ in.}$$

$$\phi R_n = 0.75 \times 1.2 \times 0.844 \times 0.375 \times 58 = 16.5 \text{ kips}$$

Controlling: Tearout (16.5 kips < 29.4 kips)

PART 5: HIGH-YIELD CHECKLIST

□ **Fillet weld throat:** $t_e = 0.707 \times w$

□ **Fillet weld strength:** $\phi R_n = 0.75 \times 0.60 F_{EXX} \times A_{we}$

□ **Minimum fillet size:** AISC Table J2.4 (⅛, 3⁄16, ¼, 5⁄16)

□ **Bolt shear:** $\phi R_n = 0.75 F_{nv} A_b$ (A325-N: 54 ksi; A325-X: 68 ksi)

□ **Bolt tension:** $\phi R_n = 0.75 F_{nt} A_b$ (A325: 90 ksi; A490: 113 ksi)

□ **Bearing:** $\phi R_n = 0.75 \times 2.4 d t F_u$

□ **Tearout:** $\phi R_n = 0.75 \times 1.2 L_c t F_u$, $L_c = L_e - (d + 1/16)/2$

□ **Bolt pretension (¾-in. A325):** 28 kips

□ **Turn-of-nut rotation:** ⅓, ½, or ⅔ turn depending on length/diameter

□ **Calibrated wrench:** 5% above minimum tension; daily calibration

□ **Hole types:** Standard, oversized, short-slotted, long-slotted

□ **Edge distance:** Per AISC Table J3.4; max = 12t ≤ 6 in.

□ **Bolt group:** Centroid + direct shear + moment-induced shear (vector addition)

□ **Welding symbol order:** Size → Symbol → Length → Pitch

□ **Planar defects critical:** Cracks, incomplete fusion, incomplete penetration, undercut

□ **CJP:** No strength check needed (matches base metal)

□ **PJP:** Use effective throat from AISC Table J2.1

PART 6: SELF-TEST

1. A fillet weld has a leg size of 5⁄16 in. What is the effective throat?

Answer: $t_e = 0.707 \times 0.3125 = \mathbf{0.221}$ in.

2. A ⅞-in. A325-X bolt (threads excluded from shear plane) is in single shear. What is the design shear strength?

Answer: $A_b = 0.6013$ in². $\phi R_n = 0.75 \times 68 \times 0.6013 = \mathbf{30.7}$ kips

3. What is the minimum edge distance for a ⅝-in. bolt in a sheared edge?

Answer: 1⅛ in. (AISC Table J3.4)

4. A turn-of-nut installation is used on a bolt that is 6 in. long with a ¾-in. diameter. What is the required rotation?

Answer: $L/d = 6/0.75 = 8$. For $4 < L/d \leq 8$: **½ turn**.

5. Which NDT method is best for detecting internal planar defects in a groove weld?

Answer: Ultrasonic Testing (UT)

6. A bearing connection uses ¾-in. A325 bolts in a ⅜-in. plate ($F_u = 58$ ksi). Edge distance = 1¼ in., spacing = 3 in. What is the controlling strength per bolt?

Answer: Tearout controls: $L_c = 1.25 - (0.75 + 0.0625)/2 = 0.844$ in. $\phi R_n = 0.75 \times 1.2 \times 0.844 \times 0.375 \times 58 = \mathbf{16.5}$ kips

7. What does a circle at the junction of the reference line and arrow indicate on a welding symbol?

Answer: Weld all around

8. A ¼-in. fillet weld using E70XX is applied on one side only. Effective length = 10 in. What is the design strength?

Answer: $t_e = 0.707 \times 0.25 = 0.1768$ in. $A_{we} = 0.1768 \times 10 = 1.768$ in². $\phi R_n = 0.75 \times 0.60 \times 70 \times 1.768 = \mathbf{55.7}$ kips

9. What is the target pretension for a 1-in. A490 bolt?

Answer: 64 kips (RCSC Table J3.1)

10. A bolt group has 6 bolts. $\sum r_i^2 = 50$ in². Moment = 200 kip-in. What is the moment-induced force on a bolt at $r = 4$ in.?

Answer: $F_{moment} = \frac{200 \times 4}{50} = \mathbf{16.0}\ \text{kips}$

PART 7: FINAL EXAM TIPS

1. **Know the electrode strength:** E70XX = 70 ksi. E60XX = 60 ksi.
2. **Fillet weld throat is always 0.707w** for equal-leg 90° fillets.
3. **Threads in shear plane reduces shear strength** — A325-N: 54 ksi; A325-X: 68 ksi.
4. **Bearing vs. tearout** — always check both; the smaller controls.
5. **Edge distance for tearout:** $L_c = L_e - (d + 1/16)/2$
6. **CJP groove welds need no strength check** — they match base metal.
7. **PJP groove welds** require effective throat from AISC Table J2.1.
8. **Bolt group analysis:** centroid → direct shear → moment-induced shear → vector sum.
9. **Planar defects are more critical** than volumetric defects.
10. **Turn-of-nut rotation** depends on L/d ratio, not on bolt diameter alone.
11. **Calibrated wrench** must be set to 5% above minimum tension and calibrated daily.
12. **Pre-installation verification** requires ≥ 1.05 × required pretension.
13. **Welding symbol order:** Size → Symbol → Length → Pitch.
14. **All-around symbol = circle; field weld = flag.**
15. **If a problem gives effective length, do not subtract end corrections again.**

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications, the

PE Civil Reference Handbook Version 2.0, and the applicable AISC/RCSC provisions.

This response is AI-generated, for reference only.

201 web pages

Generate acutal exam question that covers fully Weld and bolt installation

Thought for 5 seconds

The user wants me to generate actual exam questions that fully cover Weld and Bolt Installation for the PE Civil: Construction exam. I need to search for practice problems, exam questions, and relevant standards like AISC and RCSC. I'll also look for NCEES PE Civil Construction practice exam questions on welding and bolting.

Found 66 web pages

The search results include various sources. I need to open some of them to find actual exam questions. I'll open the PE Genius page, the Civil PE Practice page, and some AISC examples.

Read 4 pages PE Genius | Civil PE Exam Preperation ↗ Questions - Civil PE Practice ↗ Coped Beam Strength ↗ steel quiz ↗

The PE Genius page is very short and only shows a question. I need more content. Let me search for more specific exam questions.

Found 70 web pages

The search results provide some questions. I need to generate actual exam questions that cover weld and bolt installation. I'll create a set of questions covering various subtopics like welding processes, symbols, sizing, capacity, inspection, bolt types, installation methods, pretensioning, hole types, spacing, edge distance, strength, fastener group analysis, and QC/QA. I'll base them on the Reference Handbook and AISC/RCSC provisions. I'll also include detailed solutions. Now I'll produce the final answer.

PE Civil: Construction — Weld and Bolt Installation

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to Weld and Bolt Installation under Section 2.5 (Material Quality Control and Production) of the NCEES PE Civil: Construction exam. Content is aligned with PE Civil Reference Handbook v2.0 Sections 4.2.1 (Fastener Groups in Shear) and 4.2.3 (Basic Welding Symbols), and related AISC/RCSC provisions referenced therein. Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**.

PART 1: WELDING

1. Welding Processes

Process	Full Name	Key Characteristics	Common Electrodes
SMAW	Shielded Metal Arc Welding	"Stick" welding; flux-coated electrode; slag shield; all positions; most common for field welding	E60XX, E70XX
GMAW	Gas Metal Arc Welding	"MIG" welding; continuous wire electrode; external shielding gas; high deposition rate	ER70S-6
FCAW	Flux-Cored Arc Welding	Tubular wire with flux core; may or may not require shielding gas; high deposition rate; good for field	E70T-1, E71T-1
SAW	Submerged Arc Welding	Granular flux blanket; high current; deep penetration; flat position only; shop welding	F7A2-EM12K

Exam Tip: SMAW and FCAW are most common for field welding. SAW is shop-only (flat position). E70XX indicates 70 ksi tensile strength electrode.

2. Weld Types and Joints


Weld Type	Symbol	Description	Effective Throat
Fillet	△	Triangular cross-section; joins two surfaces at angle	0.707 × leg size (equal-leg, 90°)
Groove — V	V	Beveled edges form V groove	Depends on CJP or PJP
Groove — Bevel	／	One beveled edge	Depends on CJP or PJP
Groove — J	J	J-shaped edge preparation	Depends on CJP or PJP
Groove — U	U	U-shaped edge preparation	Depends on CJP or PJP
Groove — Square	‖	Square edges, no bevel	Full thickness (CJP)
Plug	⊙	Circular hole filled with weld	Plug area
Slot	▭	Elongated hole filled with weld	Slot area
Flare V	╲╱	Formed by two curved surfaces	Per AISC Table J2.1
Flare Bevel	／	Formed by curved and flat surface	Per AISC Table J2.1

Key Distinctions:

- **CJP (Complete Joint Penetration):** Weld extends through full thickness; strength matches base metal
- **PJP (Partial Joint Penetration):** Weld extends through specified depth; effective throat from AISC Table J2.1

3. Basic Welding Symbols (Per Handbook Section 4.2.3)

text



Element	Location	Meaning
Reference Line	Horizontal line	Always required; weld symbol sits on it
Arrow	Connects reference line to joint	Points to member to be welded
Tail	Left end of reference line	Process/specification reference (omitted if not used)
Size	Left of weld symbol	Leg size (fillet) or groove depth
Length	Right of weld symbol	Length of weld in inches
Pitch	Right of length	Center-to-center spacing of intermittent welds
All-Around	Circle at reference line-arrow junction	Weld continues around entire joint
Field Weld	Flag at reference line-arrow junction	Weld made in field, not shop
Contour	Line above weld symbol	Finish contour (flush, convex, concave)

Element	Location	Meaning
Finish	Letter above contour symbol	Finishing method (G = grinding, M = machining)

Reading the Symbol (order): Size → Weld Symbol → Length → Pitch

Example: `¼ △ 6-12` means: ¼-in. fillet weld, 6-in. length, 12-in. pitch (intermittent).

Critical Rule: The perpendicular leg of the fillet symbol must be on the left. Dimensions must read left to right in that order.

4. Weld Sizing

4.1 Fillet Weld Effective Throat

$$t_e = 0.707 \times w$$

where:

- t_e = effective throat (in.)
- w = fillet weld leg size (in.)
- 0.707 = cos 45° (for equal-leg 90° fillet)

Effective Area:

$$A_{we} = t_e \times L_e$$

where L_e = effective length (in.).

4.2 Minimum Fillet Weld Size (AISC Table J2.4)

Thickness of Thinner Part Joined (in.)	Minimum Fillet Weld Size (in.)
≤ ¼	⅛
> ¼ to ½	$^{3}/_{16}$
> ½ to ¾	¼
> ¾	$^{5}/_{16}$

4.3 Maximum Fillet Weld Size

- For material < ¼ in. thick: weld size = material thickness
- For material ≥ ¼ in. thick: weld size = material thickness – $^{1}/_{16}$ in. (unless specifically approved)

4.4 Effective Length

- Minimum effective length: 4 × weld size
- If end returns are used, they may be counted in effective length
- If a problem states effective length, do not subtract end correction again

5. Weld Capacity

5.1 Fillet Weld Strength (AISC 360 Chapter J)

$$\phi R_n = \phi(0.60F_{EXX})A_{we}$$

where:

- $\phi = 0.75$ (LRFD)
- F_{EXX} = electrode classification strength (e.g., 70 ksi for E70XX)
- $A_{we} = 0.707 \times w \times L_e$

Simplified per inch of weld:

$$\phi r_n = 0.75 \times 0.60 \times F_{EXX} \times 0.707 \times w$$

For E70XX, ¼-in. fillet, per inch:

$$\phi r_n = 0.75 \times 0.60 \times 70 \times 0.707 \times 0.25 = 5.57 \text{ kips/in.}$$

5.2 Groove Weld Strength

Weld Type	Tension	Shear
CJP	Same as base metal ($\phi F_y A_g$)	Same as base metal
PJP	$\phi(0.60F_{EXX})A_{we}$	$\phi(0.60F_{EXX})A_{we}$

For PJP, effective throat from AISC Table J2.1 — depends on groove angle and depth.

5.3 Base Metal Strength

Must also check connected material:

- **Yielding:** $\phi R_n = \phi F_y A_g$ ($\phi = 0.90$)
- **Rupture:** $\phi R_n = \phi F_u A_e$ ($\phi = 0.75$)

Critical: A strong weld on a thin plate can move failure into the plate.

6. Welding Positions (AWS)

Position	AWS Designation	Description	Difficulty
Flat	1G / 1F	Weld axis horizontal; welder above joint	Easiest

Position	AWS Designation	Description	Difficulty
Horizontal	2G / 2F	Weld axis horizontal; out-of-position	Moderate
Vertical	3G / 3F	Weld axis vertical	Difficult
Overhead	4G / 4F	Welder below joint	Most difficult

Exam Tip: Flat is easiest; overhead is most difficult. Field welding is often vertical or overhead.

7. Prequalified Joints, WPS, PQR, Welder Qualification

Document	Purpose	Key Content
WPS (Welding Procedure Specification)	Written procedure for production welding	Process, electrode, current, voltage, travel speed, joint details
PQR (Procedure Qualification Record)	Record of test welding to qualify WPS	Test results, mechanical properties
WPQ (Welder Performance Qualification)	Certifies individual welder	Position, process, thickness range

Prequalified Joints: AWS D1.1 prequalified joints do not require PQR testing if WPS meets all prequalified conditions.

8. Weld Inspection and NDT

Method	Abbreviation	Detects	Surface/Internal
Visual	VT	Surface defects, size, profile	Surface
Liquid Penetrant	PT	Surface-breaking defects	Surface
Magnetic Particle	MT	Surface and near-surface defects	Surface/near-surface
Ultrasonic	UT	Internal defects, planar flaws	Internal
Radiographic	RT	Internal defects, volumetric flaws	Internal

Acceptance Criteria: Per AWS D1.1 — cracks, lack of fusion, and incomplete penetration are generally unacceptable.

9. Common Welding Defects

Defect	Description	Cause	Criticality
Porosity	Gas voids in weld metal	Moisture, contamination, wrong current	Volumetric
Slag Inclusion	Non-metallic slag trapped in weld	Improper cleaning between passes	Volumetric
Incomplete Fusion	Weld metal not fused to base metal	Low current, wrong angle, fast travel	Planar (critical)
Incomplete Penetration	Weld does not extend through joint	Insufficient current, wrong joint prep	Planar (critical)
Undercut	Groove melted into base metal along weld toe	Excessive current, wrong angle	Planar (critical)
Cracks	Fracture in weld or HAZ	Hydrogen, restraint, rapid cooling	Most critical

Exam Tip: Planar defects (cracks, incomplete fusion, incomplete penetration, undercut) are more critical than volumetric defects (porosity, slag).

PART 2: BOLTING

10. Bolt Types and Grades

Grade	Specification	Min. Tensile Strength	Typical Use
A307	ASTM A307	60 ksi	Low-strength; light connections
A325	ASTM A325 / F3125	120 ksi (½–1 in.)	High-strength; most common
A490	ASTM A490 / F3125	150 ksi	High-strength; larger diameter
F1554	ASTM F1554	36/55/105 ksi	Anchor bolts

Key Distinction: A325 and A490 are high-strength bolts requiring pretensioning for slip-critical connections.

11. Bolted Connection Types

Type	Load Transfer	Pretension Required?	Faying Surface Condition
Bearing	Shear on bolt + bearing on plate	No (snug-tight acceptable)	Any
Slip-Critical	Friction between faying surfaces	Yes	Clean, specified slip coefficient
Tension	Axial tension on bolt	No (but often pretensioned)	Any

Type	Load Transfer	Pretension Required?	Faying Surface Condition
Combined Shear + Tension	Interaction	Per specification	Any

12. Bolt Installation Methods (RCSC Specification)

Method	How It Works	Key Requirement
Turn-of-Nut	Snug tight + specified rotation	Match-marking required; rotation depends on bolt length/diameter
Calibrated Wrench	Wrench calibrated to stall at required torque	Must be set to 5% above minimum tension; daily calibration required
Twist-Off	Splined end shears at specified torque	Tension-control bolts; visual verification
DTI	Compressible washer indicates tension	Feeler gauge check of gap; gap must be ≤ calibrated value

Turn-of-Nut Rotation (RCSC Table 2.4):

Bolt Length	Rotation
≤ 4 × diameter	⅓ turn
> 4 × diameter but ≤ 8 × diameter	½ turn
> 8 × diameter	⅔ turn

13. Bolt Pretensioning

Minimum Bolt Pretension (RCSC Table J3.1 / Table 5.2):

Bolt Size (in.)	A325 (kips)	A490 (kips)
½	12	15
⅝	19	24
¾	28	35
⅞	39	49
1	51	64

Target pretension ≈ 70% of bolt ultimate tensile strength.

14. Bolt Hole Types (AISC Table J3.3)

Hole Type	Description	Washer Required?
Standard	d + 1/16 in.	No
Oversized	d + ⅛ in. (for d ≤ 1 in.)	Yes
Short-Slotted	(d + 1/16) × (d + ¼)	Yes
Long-Slotted	(d + 1/16) × (d + 2.5)	Yes

Slip Resistance: Oversized and short-slotted holes have the same slip resistance as standard holes when washers are used per RCSC.

15. Bolt Spacing and Edge Distance (AISC Section J3.4/J3.5)

Parameter	Requirement
Minimum spacing	2⅔ × d (preferred: 3 × d)
Maximum spacing	12 × t (thickness of thinner plate), ≤ 6 in.
Minimum edge distance	Per AISC Table J3.4 (varies by bolt diameter and edge condition)
Maximum edge distance	12 × t, ≤ 6 in.

Typical Minimum Edge Distances (sheared edges):

Bolt Diameter (in.)	Min. Edge Distance (in.)
½	⅞
⅝	1⅛
¾	1¼
⅞	1½
1	1¾

16. Bolt Strength (AISC Table J3.2)

16.1 Bolt Shear

$$\phi R_n = \phi F_{nv} A_b$$

where:

- $\phi = 0.75$ (LRFD)
- F_{nv} = nominal shear stress from AISC Table J3.2
- A_b = nominal bolt area

Shear Stress Values (AISC Table J3.2):

Bolt Grade	Threads Included in Shear Plane	Threads Excluded from Shear Plane
A325	54 ksi	68 ksi
A490	68 ksi	84 ksi

16.2 Bolt Tension

$$\phi R_n = \phi F_{nt} A_b$$

where F_{nt} = nominal tensile stress from AISC Table J3.2.

Bolt Grade	F_{nt} (ksi)
A325	90
A490	113

16.3 Bearing and Tearout (AISC Section J3.10)

Bearing:

$$\phi R_n = \phi(2.4dtF_u)$$

$$\phi = 0.75$$

Tearout:

$$\phi R_n = \phi(1.2L_c tF_u)$$

$$L_c = \text{clear distance} = \text{edge distance} - \frac{d + 1/16}{2}$$

Governing: The smaller of bearing and tearout controls.

16.4 Combined Shear and Tension

$$\left(\frac{T_u}{\phi R_{nt}}\right)^2 + \left(\frac{V_u}{\phi R_{nv}}\right)^2 \leq 1.0$$

17. Fastener Group Analysis (Handbook Section 4.2.1)

17.1 Centroid of Bolt Group

$$\bar{x} = \frac{\sum A_i x_i}{\sum A_i}, \quad \bar{y} = \frac{\sum A_i y_i}{\sum A_i}$$

For equal bolt areas: $\bar{x} = \frac{\sum x_i}{n}, \bar{y} = \frac{\sum y_i}{n}$

17.2 Direct Shear Force

$$F_{direct} = \frac{P}{n}$$

where P = applied load, n = number of bolts. Acts in same direction as P.

17.3 Moment-Induced Shear Force

$$F_{moment,i} = \frac{M r_i}{\sum r_i^2}$$

where:

- $M = P \times e$ (eccentricity)
- r_i = distance from centroid to bolt i

- Acts perpendicular to line from centroid to bolt

17.4 Total Shear Force

$$F_{total,i} = \sqrt{F_{direct}^2 + F_{moment,i}^2 + 2F_{direct}F_{moment,i}\cos\theta}$$

Vector addition required. Critical bolt is typically the one farthest from centroid and oriented unfavorably relative to direct shear direction.

18. Special Inspection Requirements

Connection Type	Inspection Required
Snug-tight bearing	Visual inspection
Pretensioned	Pre-installation verification + visual + torque/tension check
Slip-critical	Pre-installation verification + visual + 10% torque inspection

Pre-installation Verification: Three bolts of each diameter, length, grade, and lot must be tested in a Skidmore-Wilhelm calibrator to verify that the installation method develops ≥ 1.05 × required pretension.

19. Common Bolting Defects

Defect	Cause	Consequence
Loose bolts	Inadequate pretensioning	Slip-critical failure
Incorrect torque	Wrench not calibrated	Insufficient clamping force

Defect	Cause	Consequence
Improper hole alignment	Misaligned members	Forced fit, bolt bending
Threads in shear plane	Wrong bolt length	Reduced shear strength
Inadequate edge distance	Layout error	Tearout failure
Unfilled holes	Missing bolts	Load redistribution

PART 3: QUALITY CONTROL AND CONFORMANCE

20. QC/QA Roles and Responsibilities

Role	Responsibility
Contractor QC	Sampling, testing, control charts, nonconformance reporting
Owner QA	Independent verification testing, acceptance evaluation
Special Inspector	Continuous or periodic inspection of welding/bolting per IBC
Weld Inspector	Visual and NDT inspection per AWS D1.1

21. Documentation and Submittals

- **WPS/PQR/WPQ** submittals for welding
- **Bolt installation procedure** for bolting
- **Pre-installation verification reports**

- **NDT reports** (UT, RT, MT, PT)
- **Daily inspection reports**
- **Nonconformance reports (NCRs)**

22. Common Errors, Assumptions, and Exam Traps

Trap	Correct Approach
Using bolt gross area instead of nominal area	Use A_b from AISC Table 7-1
Forgetting bearing/tearout check	Always check both; smallest controls
Using wrong F_{nv} for threads in shear plane	Threads included: 54 ksi (A325); excluded: 68 ksi
Adding direct and moment shear algebraically	Must use vector addition
Assuming CJP groove weld needs strength check	CJP matches base metal; no weld strength check needed
Forgetting minimum fillet weld size	Check AISC Table J2.4
Using leg size as effective throat	$t_e = 0.707 \times w$
Ignoring edge distance for tearout	$L_c = L_e - (d + 1/16)/2$
Using wrong rotation for turn-of-nut	Depends on bolt length relative to diameter

PART 4: PRACTICE PROBLEMS

Problem 1 — Fillet Weld Strength

A ¼-in. fillet weld using E70XX electrode is applied on both sides of a plate. Each weld is 8 in. long. Determine the LRFD design strength of the weld group.

Solution:

- Effective throat: $t_e = 0.707 \times 0.25 = 0.1768$ in.
- Total effective length: $L_e = 2 \times 8 = 16$ in.
- Effective area: $A_{we} = 0.1768 \times 16 = 2.829$ in²
- Nominal strength: $R_n = 0.60 \times 70 \times 2.829 = 118.8$ kips
- Design strength: $\phi R_n = 0.75 \times 118.8 = \mathbf{89.1}$ kips

Problem 2 — Bolt Shear and Bearing

A connection uses three ⅞-in. A325-N bolts (threads included in shear plane) in standard holes. Plate thickness = ½ in., $F_u = 58$ ksi. Edge distance = 1½ in., spacing = 3 in. Determine the controlling LRFD design strength.

Solution:

Bolt Shear (per bolt):

- $A_b = 0.6013$ in² (AISC Table 7-1)
- $\phi R_n = 0.75 \times 54 \times 0.6013 = 24.35$ kips/bolt
- Total: $3 \times 24.35 = \mathbf{73.1}$ kips

Bearing (interior bolt):

- $\phi R_n = 0.75 \times 2.4 \times 0.875 \times 0.50 \times 58 = 45.7$ kips

Tearout (end bolt):

- $L_c = 1.5 - (0.875 + 0.0625)/2 = 1.031$ in.


- $\phi R_n = 0.75 \times 1.2 \times 1.031 \times 0.50 \times 58 = 26.9$ kips

Controlling: Bolt shear governs: **73.1 kips**

Problem 3 — Reading a Welding Symbol

Interpret the following welding symbol:

```
text
```



Answer:

- ¼-in. fillet weld
- 6-in. length
- 12-in. pitch (intermittent)
- SMAW process
- Arrow side weld (symbol below reference line)

Problem 4 — Bolt Group Eccentric Shear

A bracket is bolted with four ¾-in. A325 bolts in a rectangular pattern: (0,0), (3,0), (0,4), (3,4). An eccentric load $P = 20$ kips acts at a distance $e = 6$ in. from the centroid. Determine the maximum bolt force.

Solution:

Centroid: $\bar{x} = 1.5$ in., $\bar{y} = 2.0$ in.

Direct shear: $F_{direct} = 20/4 = 5.0$ kips

Moment: $M = 20 \times 6 = 120$ kip-in.

$\sum r_i^2$:

- Bolt 1: $(1.5)^2 + (2.0)^2 = 6.25$
- Bolt 2: $(1.5)^2 + (2.0)^2 = 6.25$
- Bolt 3: $(1.5)^2 + (2.0)^2 = 6.25$
- Bolt 4: $(1.5)^2 + (2.0)^2 = 6.25$
- $\sum r_i^2 = 25.0$

Moment force on critical bolt (max r = 2.5 in.):

$$F_{moment} = \frac{120 \times 2.5}{25.0} = 12.0 \text{ kips}$$

Total force (vector addition): Depends on direction. Conservative estimate:

$$F_{total} = 5.0 + 12.0 = \mathbf{17.0} \text{ kips}$$

Problem 5 — Minimum Fillet Weld Size

A fillet weld is applied to a plate with thickness $t = ⅜$ in. What is the minimum fillet weld size required by AISC Table J2.4?

Answer: For $t >$ ¼ to ½ in., minimum weld size = **3⁄16 in.**

Problem 6 — Pretension Verification

A slip-critical connection uses ¾-in. A325 bolts. What is the minimum required pretension, and what must the pre-installation verification demonstrate?

Answer:

- Minimum pretension: **28 kips** (RCSC Table J3.1)
- Pre-installation verification must demonstrate ≥ **1.05 × 28 = 29.4 kips** using three representative bolts in a Skidmore-Wilhelm calibrator.

Problem 7 — Weld Defect Identification

A UT inspection reveals a planar indication in a CJP groove weld. Which of the following is the most likely defect?

A) Porosity
B) Slag inclusion
C) Incomplete fusion
D) Undercut

Answer: C

Solution: UT detects planar flaws well. Incomplete fusion is a planar defect. Porosity and slag are volumetric (more readily detected by RT). Undercut is surface (VT/MT/PT).

Problem 8 — Bolt Bearing vs. Tearout

A ¾-in. bolt is placed 1¼ in. from the edge of a ⅜-in. plate ($F_u = 58$ ksi). Which limit state controls: bearing or tearout?

Solution:

Bearing:

$$\phi R_n = 0.75 \times 2.4 \times 0.75 \times 0.375 \times 58 = 29.4 \text{ kips}$$

Tearout:

$$L_c = 1.25 - (0.75 + 0.0625)/2 = 0.844 \text{ in.}$$

$$\phi R_n = 0.75 \times 1.2 \times 0.844 \times 0.375 \times 58 = 16.5 \text{ kips}$$

Controlling: Tearout (16.5 kips < 29.4 kips)

PART 5: HIGH-YIELD CHECKLIST

□ **Fillet weld throat:** $t_e = 0.707 \times w$

□ **Fillet weld strength:** $\phi R_n = 0.75 \times 0.60 F_{EXX} \times A_{we}$

□ **Minimum fillet size:** AISC Table J2.4 (⅛, 3⁄16, ¼, 5⁄16)

□ **Bolt shear:** $\phi R_n = 0.75 F_{nv} A_b$ (A325-N: 54 ksi; A325-X: 68 ksi)

□ **Bolt tension:** $\phi R_n = 0.75 F_{nt} A_b$ (A325: 90 ksi; A490: 113 ksi)

□ **Bearing:** $\phi R_n = 0.75 \times 2.4 dt F_u$

□ **Tearout:** $\phi R_n = 0.75 \times 1.2 L_c t F_u$, $L_c = L_e - (d + 1/16)/2$

□ **Bolt pretension (¾-in. A325):** 28 kips

□ **Turn-of-nut rotation:** ⅓, ½, or ⅔ turn depending on length/diameter

□ **Calibrated wrench:** 5% above minimum tension; daily calibration

□ **Hole types:** Standard, oversized, short-slotted, long-slotted

□ **Edge distance:** Per AISC Table J3.4; max = 12t ≤ 6 in.

□ **Bolt group:** Centroid + direct shear + moment-induced shear (vector addition)

□ **Welding symbol order:** Size → Symbol → Length → Pitch

□ **Planar defects critical:** Cracks, incomplete fusion, incomplete penetration, undercut

□ **CJP:** No strength check needed (matches base metal)

□ **PJP:** Use effective throat from AISC Table J2.1

PART 6: SELF-TEST

1. A fillet weld has a leg size of 5⁄16 in. What is the effective throat?

Answer: $t_e = 0.707 \times 0.3125 = \mathbf{0.221}$ in.

2. A ⅞-in. A325-X bolt (threads excluded from shear plane) is in single shear. What is the design shear strength?

Answer: $A_b = 0.6013$ in². $\phi R_n = 0.75 \times 68 \times 0.6013 = \mathbf{30.7}$ kips

3. What is the minimum edge distance for a ⅝-in. bolt in a sheared edge?

Answer: 1⅛ in. (AISC Table J3.4)

4. A turn-of-nut installation is used on a bolt that is 6 in. long with a ¾-in. diameter. What is the required rotation?

Answer: $L/d = 6/0.75 = 8$. For $4 < L/d \leq 8$: **½ turn.**

5. Which NDT method is best for detecting internal planar defects in a groove weld?

Answer: Ultrasonic Testing (UT)

6. A bearing connection uses ¾-in. A325 bolts in a ⅜-in. plate ($F_u = 58$ ksi). Edge distance = 1¼ in., spacing = 3 in. What is the controlling strength per bolt?

Answer: Tearout controls: $L_c = 1.25 - (0.75 + 0.0625)/2 = 0.844$ in. $\phi R_n = 0.75 \times 1.2 \times 0.844 \times 0.375 \times 58 = \mathbf{16.5}$ kips

7. What does a circle at the junction of the reference line and arrow indicate on a welding symbol?

Answer: Weld all around

8. A ¼-in. fillet weld using E70XX is applied on one side only. Effective length = 10 in. What is the design strength?

Answer: $t_e = 0.707 \times 0.25 = 0.1768$ in. $A_{we} = 0.1768 \times 10 = 1.768$ in². $\phi R_n = 0.75 \times 0.60 \times 70 \times 1.768 = \mathbf{55.7}$ kips

9. What is the target pretension for a 1-in. A490 bolt?

Answer: 64 kips (RCSC Table J3.1)

10. A bolt group has 6 bolts. $\sum r_i^2 = 50$ in². Moment = 200 kip-in. What is the moment-induced force on a bolt at $r = 4$ in.?

Answer: $F_{moment} = \frac{200 \times 4}{50} = \mathbf{16.0}$ kips

PART 7: FINAL EXAM TIPS

1. **Know the electrode strength:** E70XX = 70 ksi. E60XX = 60 ksi.
2. **Fillet weld throat is always 0.707w** for equal-leg 90° fillets.
3. **Threads in shear plane reduces shear strength** — A325-N: 54 ksi; A325-X: 68 ksi.
4. **Bearing vs. tearout** — always check both; the smaller controls.
5. **Edge distance for tearout:** $L_c = L_e - (d + 1/16)/2$
6. **CJP groove welds need no strength check** — they match base metal.
7. **PJP groove welds** require effective throat from AISC Table J2.1.

8. **Bolt group analysis:** centroid → direct shear → moment-induced shear → vector sum.
9. **Planar defects are more critical** than volumetric defects.
10. **Turn-of-nut rotation** depends on L/d ratio, not on bolt diameter alone.
11. **Calibrated wrench** must be set to 5% above minimum tension and calibrated daily.
12. **Pre-installation verification** requires ≥ 1.05 × required pretension.
13. **Welding symbol order:** Size → Symbol → Length → Pitch.
14. **All-around symbol = circle; field weld = flag.**
15. **If a problem gives effective length, do not subtract end corrections again.**

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications, the PE Civil Reference Handbook Version 2.0, and the applicable AISC/RCSC provisions.

123 web pages

Act as a licensed PE an...
TXT 2.38KB

Thought for 12 seconds

We need answer as PE instructor. Need generate comprehensive exam-focused review on Quality Control Process (QA/QC) only, aligned with NCEES PE Civil Construction, Reference Handbook v2.0 sections mentioned. Need cover all subtopics likely tested. Include definitions, formulas, procedures, worked examples, tips, practice problems, tables, bullets, high-yield checklist, self-test. Flag outside scope. Not claim guaranteed pass. Need produce final answer. Need be thorough but concise enough. We have large context from previous handbook? We have PE Civil Reference Handbook v2.0 content in previous user messages? Yes first user message included entire handbook? It's huge. We can use relevant sections. Need craft final answer.

We need focus QA/QC. Let's outline:

- Introduction: QA/QC definitions, distinctions, importance.

- Roles and responsibilities: owner, engineer, contractor, testing lab, inspector.
- QA/QC plans, ITPs, hold/witness points.
- Specifications, codes, standards, reference test methods: ASTM, AASHTO, ACI, etc.
- Sampling, testing frequency, acceptance criteria.
- Statistical QC: mean, range, std dev, control charts, acceptance evaluation, sampling plans. Include formulas from Handbook Section 1.4.2.
- Inspection procedures, hold points, witness points, surveillance.
- Documentation: submittals, test reports, inspection reports, NCRs, as-built.
- Nonconformance, corrective/preventive action.
- Quality audits, continuous improvement.
- Material-specific QC/QA: concrete, soils, aggregates, asphalt, steel, masonry, wood? (wood outside? flag).
- Field vs lab testing.
- Common errors, assumptions, exam traps.
- Practice problems with solutions.
- High-yield checklist.
- Self-test.

Need align with NCEES specifications. We can mention NCEES PE Civil: Construction exam specifications area 2.5 Material Quality Control and Production, 1.4.2 Statistical Quality Control, 3.8 Material Test Methods, 3.9 Compaction, 2.6 Health/Safety intersection. Use Reference Handbook v2.0 content.

We can include formulas from Handbook: X-bar, R, sample std dev, control chart formulas, A2, D3, D4, etc. Also concrete acceptance criteria from Section 2.5.1 (ACI 318/301). Soils compaction relative compaction. Asphalt volumetrics? Maybe.

We need provide "actual exam question that covers fully Weld and bolt installation"? Wait user's latest request is about QA/QC, not weld/bolt. Previous was weld/bolt. Now they want QA/QC. So we must not cover weld/bolt except where necessary? They said "Do not cover other topics except where necessary to explain QA/QC." So focus QA/QC. We can mention welding/bolting as examples of inspection? But not full weld/bolt. So we should not generate weld/bolt questions. Need answer QA/QC.

Let's produce a comprehensive review. We'll structure with headings. Include tables. Keep exam-focused.

We can start with "Purpose and Scope" note.

Then Section 1: QA/QC Fundamentals.
Definitions:

- Quality: degree to which inherent characteristics meet requirements.
- QA: planned and systematic actions to provide confidence that product/service will satisfy quality requirements. Owner/engineer perspective. Process-oriented, proactive.
- QC: operational techniques and activities used to fulfill requirements for quality. Contractor's production-oriented, reactive/verification.
- QC vs QA table.
- Quality control process: sampling, testing, inspection, acceptance, nonconformance.

Roles:

- Owner: defines requirements, accepts, funds QA.
- Engineer: develops specifications, approves submittals, evaluates nonconformance.
- Contractor: implements QC, provides QC plan, performs tests, controls production.
- Testing lab: performs tests per standards, reports results, may be contractor's or owner's.
- Inspector/Special Inspector: verifies compliance, hold points, NDT.

QA/QC Plans:

- QC Plan: contractor's document: organization, sampling/testing, control charts, nonconformance, documentation.
- QA Plan: owner's: verification testing, audits, acceptance.
- ITP: Inspection and Test Plan: lists activities, inspections, tests, hold/witness points, acceptance criteria.

Specifications and Standards:

- ASTM, AASHTO, ACI, AWS, RCSC, etc.
- Reference test methods. List common tests.

Sampling and Frequency:

- Concrete: ACI 318: once/day, per 150 yd3, per 5000 ft2, <50 yd3 exempt with evidence.
- Soils: frequency per spec (e.g., every 500 yd3, every lift, per 1000 ft2).
- Asphalt: per lot, per day, etc.
- Statistical sampling: random, stratified.

Statistical QC:

- Mean, range, std dev, CV.
- Control charts: X-bar and R charts. Formulas.
- Acceptance evaluation: operating characteristic, AQL, LTPD, alpha/beta risks.
- Sampling plans: single, double, multiple. MIL-STD-105? Maybe outside.
- Use Handbook Section 1.4.2.

Inspection:

- Hold points: work cannot proceed without owner/engineer approval.
- Witness points: owner notified but work can proceed.
- Surveillance: periodic monitoring.
- Types: visual, dimensional, NDT, destructive.

Documentation:

- Submittals: mix designs, WPS/PQR, bolt procedures, etc.
- Test reports: results, location, date, technician.
- Inspection reports.
- NCR: nonconformance report.
- As-built records.

Nonconformance:

- Identify, document, evaluate, disposition (rework, repair, accept, reject), corrective action, preventive action.
- Root cause analysis.

Quality audits:

- Internal/external audits, continuous improvement.

Material-specific QC/QA:

- Concrete: slump, air, unit weight, compressive strength, cylinders, cores.
- Soils: moisture, gradation, Atterberg, compaction (Proctor, field density), CBR.
- Aggregates: gradation, specific gravity, absorption, LA abrasion.

- Asphalt: volumetrics (Gmm, Gmb, VMA, VFA, air voids), extraction, gradation.
- Steel: tensile, chemical, weld/bolt inspection (brief).
- Masonry: prism, mortar, grout.
- Wood: flag outside NCEES scope? Maybe mention limited.

Field vs Lab:

- Field: in-situ density, slump, air, cylinders made/cured.
- Lab: Proctor, gradation, strength, mix design.

Common errors/traps:

- Sampling not representative.
- Testing frequency missed.
- Using wrong standard.
- Misinterpreting control charts.
- Confusing QA/QC roles.
- Forgetting acceptance criteria.
- Statistical mistakes: using population vs sample std dev, etc.

Practice problems:

1. Concrete acceptance: given three consecutive tests, check criteria.
2. Control chart: compute UCL/LCL.
3. Relative compaction: field dry density vs lab max.
4. Sampling frequency: number of tests for concrete.
5. Nonconformance: what action?
6. Statistical: mean, range, std dev.
7. Asphalt volumetrics: compute air voids, VMA, VFA.

High-yield checklist.
Self-test.

Need ensure use tables, bullets. Include formulas from Handbook. Use LaTeX.

We need cite handbook sections? We can mention "per Handbook Section X". No need exact pages.

We should flag outside NCEES scope: e.g., detailed MIL-STD sampling plans, ISO 9001, etc.

> Let's craft final answer with moderate detail. Desired oververbosity 5. We can be comprehensive but not overly long. Maybe around 3000-5000 words? But final answer should be useful. We can include all subtopics.
>
> Let's write.

PE Civil: Construction — Quality Control Process (QA/QC)

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to the **Quality Control Process (QA/QC)** within the *Material, Production, and Execution Quality Control* area of the NCEES PE Civil: Construction exam. It aligns with PE Civil Reference Handbook v2.0 Sections **2.5** (Material Quality Control and Production), **1.4.2** (Statistical Quality Control), **3.8** (Material Test Methods), **3.9** (Compaction: Laboratory and Field Compaction), and **2.6** (Health and Safety where it intersects with quality and inspection). Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**. This review is exam-focused preparation and does not guarantee a passing score.

1. QA/QC Fundamentals

1.1 Definitions

Term	Definition
Quality	The degree to which a set of inherent characteristics fulfills requirements.

Term	Definition
Quality Assurance (QA)	Planned and systematic actions that provide confidence that a product or service will satisfy given quality requirements. **Owner/engineer perspective. Process-oriented, proactive.**
Quality Control (QC)	Operational techniques and activities used to fulfill requirements for quality. **Contractor perspective. Product-oriented, reactive/verification.**
Inspection	Examination of a product, process, or service to determine conformity to requirements.
Testing	Determination of one or more characteristics of an object according to a procedure.

1.2 QA vs. QC — Key Distinctions

Aspect	QA	QC
Who	Owner, engineer, agency	Contractor, producer
Focus	Process, system	Product, output
Purpose	Prevent defects	Detect defects
Nature	Proactive	Reactive/verification
Examples	Audits, procedure reviews, verification testing	Sampling, testing, control charts, inspection
Acceptance	Owner accepts	Contractor controls

Exam Tip: QA is the **owner's verification** that the contractor's QC is working. QC is the **contractor's production control**. Do not confuse the two.

2. Roles and Responsibilities

Role	Responsibilities
Owner	Defines quality requirements; funds QA; accepts or rejects work; approves nonconformance dispositions.
Engineer	Develops technical specifications; reviews/approves submittals (mix designs, WPS/PQR, bolt procedures); evaluates nonconformance; issues acceptance decisions.
Contractor	Implements QC plan; performs sampling and testing; maintains control charts; submits test reports; corrects nonconformances.
Testing Laboratory	Performs tests per ASTM/AASHTO/ACI standards; reports results accurately; maintains equipment calibration; personnel qualifications (e.g., ACI, NICET).
Inspector / Special Inspector	Verifies compliance with specifications; observes hold/witness points; documents inspection results; may perform NDT.

Exam Tip: The **contractor QC** produces the material; the **owner QA** verifies it. The **testing laboratory** may serve either QC or QA, depending on contract.

3. QA/QC Plans, ITPs

3.1 QC Plan (Contractor)

A written plan that includes:

- Organization chart and responsibilities
- Sampling and testing frequencies
- Test methods and standards
- Control chart procedures
- Nonconformance procedures
- Documentation and reporting
- Personnel qualifications

3.2 QA Plan (Owner)

A written plan that includes:

- Verification sampling and testing frequencies
- Independent assurance (IA) procedures
- Audit schedule
- Acceptance criteria
- Dispute resolution

3.3 Inspection and Test Plan (ITP)

An ITP lists:

- Activities and sequences
- Inspections/tests to be performed
- Hold points (work cannot proceed without approval)
- Witness points (owner notified, but work may proceed)

- Acceptance criteria
- Documentation requirements

Exam Tip: Hold points stop work; **witness points** do not stop work. Both must be documented.

4. Specifications, Codes, Standards, and Reference Test Methods

4.1 Common Standards

Material	Property	ASTM	AASHTO	ACI/Other
Concrete	Slump	C143	T119	—
	Air content	C231/C173	T152/T196	—
	Compressive strength	C39	T22	ACI 318/301
Soils	Moisture content	D2216	T265	—
	Atterberg limits	D4318	T89/T90	—
	Gradation	D422	T88	—
	Compaction (Standard)	D698	T99	—
	Compaction (Modified)	D1557	T180	—
	Field density	D6938/D1556	T191/T310	—
Asphalt	Gmm	D2041	T209	—
	Gmb	D2726	T166	—

Material	Property	ASTM	AASHTO	ACI/Other
	VMA/VFA	—	—	Asphalt Institute MS-2
Steel	Tensile	A370/E8	—	AISC/RCSC
Masonry	Prism strength	C1314	—	TMS 402

Exam Tip: Know which standard corresponds to which test. The exam often gives a scenario and asks which test applies.

5. Sampling, Testing Frequency, and Acceptance Criteria

5.1 Concrete (ACI 318/301)

- **Strength tests:** not less than once per day, nor once per 150 yd^3, nor once per 5,000 ft^2 of surface area.
- **Exemption:** if total quantity < 50 yd^3, strength tests not required when evidence of satisfactory strength is submitted and approved.
- **Strength test:** average of at least two 6×12 in. cylinders or three 4×8 in. cylinders.
- **Acceptance criteria:**
  1. Every arithmetic average of any three consecutive strength tests ≥ f′c.
  2. No strength test falls below f′c by more than 500 psi (f′c ≤ 5,000 psi) or 0.10 f′c (f′c > 5,000 psi).

5.2 Soils

- **Field density:** typically one test per lift per 1,000–5,000 ft^2, or as specified.
- **Relative compaction:** RC = ($\gamma_{d,field}$ / $\gamma_{d,max}$) × 100%.

- **Acceptance:** typically ≥ 95% of Standard Proctor or ≥ 92% of Modified Proctor, depending on specification.

5.3 Asphalt

- **Sampling:** per lot, per day, or per 500–1,000 tons.
- **Acceptance:** air voids (4% target), VMA, VFA, gradation, asphalt content.

5.4 Statistical Sampling

- **Random sampling:** every unit has equal chance.
- **Stratified sampling:** divide into strata, sample each.
- **Acceptance sampling:** AQL (Acceptable Quality Level), LTPD (Lot Tolerance Percent Defective), α (producer's risk), β (consumer's risk). **[Detailed MIL-STD-105 plans are outside NCEES scope.]**

6. Statistical Quality Control

6.1 Descriptive Statistics

Statistic	Formula
Mean	$\bar{X} = \frac{1}{n}\sum X_i$
Range	$R = X_{\max} - X_{\min}$
Sample standard deviation	$s = \sqrt{\frac{1}{n-1}\sum (X_i - \bar{X})^2}$
Coefficient of variation	$CV = \frac{s}{\bar{X}}$

6.2 Control Charts (Handbook Section 1.4.2)

X̄ and R Charts:

- $CL_R = \bar{R}$
- $UCL_R = D_4\bar{R}$
- $LCL_R = D_3\bar{R}$
- $CL_X = \bar{\bar{X}}$
- $UCL_X = \bar{\bar{X}} + A_2\bar{R}$
- $LCL_X = \bar{\bar{X}} - A_2\bar{R}$

Constants (from Handbook):

n	A_2	D_3	D_4
2	1.880	0	3.268
3	1.023	0	2.574
4	0.729	0	2.282
5	0.577	0	2.114
6	0.483	0	2.004
7	0.419	0.076	1.924
8	0.373	0.136	1.864
9	0.337	0.184	1.816
10	0.308	0.223	1.777

Standard Deviation Charts:

- $UCL_X = \bar{\bar{X}} + A_3\bar{S}$
- $LCL_X = \bar{\bar{X}} - A_3\bar{S}$
- $UCL_S = B_4\bar{S}$
- $LCL_S = B_3\bar{S}$

6.3 Acceptance Evaluation

- **Lower limit L only:** Accept if $\bar{X} \geq L$.
- **Upper limit U only:** Accept if $\bar{X} \leq U$.
- **Both limits:** Accept if $L \leq \bar{X} \leq U$.

6.4 Worked Example

Problem: Five slump tests: 4.0, 4.5, 3.5, 5.0, 4.0 in. Compute mean, range, and sample standard deviation.

Solution:

- Mean = (4.0 + 4.5 + 3.5 + 5.0 + 4.0)/5 = **4.2 in.**
- Range = 5.0 − 3.5 = **1.5 in.**
- $s = \sqrt{[(0.04) + (0.09) + (0.49) + (0.64) + (0.04)]/4} = \sqrt{1.30/4} = \mathbf{0.57}$ in.

7. Inspection Procedures, Hold Points, Witness Points, Surveillance

Term	Definition	Work May Proceed?
Hold Point	A point where work cannot proceed without owner/engineer approval.	No

Term	Definition	Work May Proceed?
Witness Point	A point where owner is notified but work may proceed.	Yes
Surveillance	Periodic monitoring of contractor's QC activities.	Yes
Inspection	Examination for conformity.	—

Exam Tip: Hold points are critical for safety and structural integrity. Witness points are for documentation.

8. Documentation

Document	Purpose	Contents
Submittal	Pre-construction approval	Mix designs, WPS/PQR, bolt procedures, shop drawings
Test Report	Record of test results	Project, location, sample ID, test method, results, technician
Inspection Report	Record of inspection	Date, location, inspector, findings, acceptance
Nonconformance Report (NCR)	Document nonconformance	Description, location, disposition, corrective action
As-Built Records	Final record of constructed work	Changes, deviations, approvals

Exam Tip: If it isn't documented, it didn't happen. Documentation is a high-yield topic.

9. Nonconformance, Corrective Action, Preventive Action

1. **Identify** nonconformance.
2. **Document** on NCR.
3. **Evaluate** extent and impact.
4. **Disposition:** rework, repair, accept as-is, reject.
5. **Corrective action:** eliminate cause of existing nonconformance.
6. **Preventive action:** eliminate cause of potential nonconformance.
7. **Verify** effectiveness.

Exam Tip: Corrective action fixes the problem; preventive action prevents recurrence.

10. Quality Audits and Continuous Improvement

- **Internal audit:** contractor audits own QC system.
- **External audit:** owner audits contractor's QC system.
- **Continuous improvement:** use data from control charts, NCRs, audits to improve processes.

Exam Tip: Audits verify that the QC plan is being followed. They are a QA function.

11. Material-Specific QC/QA Requirements

11.1 Concrete

- **Field tests:** slump, air content, unit weight, temperature, cylinders.
- **Lab tests:** compressive strength, mix design verification.

- **Acceptance:** per ACI 318/301.

11.2 Soils and Aggregates

- **Field tests:** moisture content, field density (nuclear or sand cone), gradation.
- **Lab tests:** Proctor, Atterberg, gradation, CBR.
- **Acceptance:** relative compaction, gradation limits.

11.3 Asphalt

- **Field tests:** temperature, compaction (nuclear gauge), coring.
- **Lab tests:** Gmm, Gmb, extraction, gradation, volumetrics.
- **Acceptance:** air voids, VMA, VFA, density.

11.4 Steel

- **Field tests:** visual inspection, bolt tension verification, weld NDT.
- **Lab tests:** tensile, chemical, Charpy.
- **Acceptance:** AISC/RCSC/AWS D1.1.

11.5 Masonry

- **Field tests:** mortar consistency, grout compressive strength, prism tests.
- **Lab tests:** prism compressive strength, mortar/grout strength.
- **Acceptance:** TMS 402/602.

11.6 Wood

- **[Outside NCEES scope for detailed QC/QA]** — Wood design is covered in Structural depth, but material testing is not a primary focus of Construction depth.

12. Field vs. Laboratory Testing

Aspect	Field Testing	Laboratory Testing
Location	On site	Controlled lab
Examples	Slump, air content, field density, cylinder fabrication	Proctor, gradation, compressive strength, mix design
Advantages	Immediate results, representative of actual conditions	Controlled conditions, precise equipment
Limitations	Variable conditions, limited equipment	Sample disturbance, not actual field conditions

Exam Tip: Field-cured cylinders vs. lab-cured cylinders: field-cured reflect actual curing; lab-cured reflect potential strength.

13. Common Errors, Assumptions, and Exam Traps

Trap	Correct Approach
Confusing QA and QC	QA = owner verification; QC = contractor control
Forgetting concrete sampling frequency	Once/day, per 150 yd^3, per 5,000 ft^2
Using wrong acceptance threshold	500 psi for $f'c \leq 5{,}000$ psi; 0.10 $f'c$ for > 5,000 psi
Misinterpreting control charts	UCL/LCL are not specification limits; they are statistical control limits

Trap	Correct Approach
Using population std dev instead of sample	Use n−1 for sample
Ignoring hold points	Work cannot proceed without approval
Forgetting to document	If it isn't documented, it didn't happen
Confusing corrective and preventive action	Corrective fixes existing; preventive prevents potential
Using wrong Proctor for relative compaction	Match lab test to specification (Standard vs. Modified)
Forgetting field-cured vs. lab-cured criteria	Field-cured < 85% of lab-cured → improve curing

14. Practice Problems with Detailed Solutions

Problem 1 — Concrete Acceptance

A concrete mix has f′c = 4,500 psi. The last three consecutive strength tests averaged 4,600 psi. A single test result was 3,900 psi. Is the concrete acceptable?

Solution:

- Check average: 4,600 ≥ 4,500 ✓
- Check individual: 4,500 − 3,900 = 600 psi > 500 psi ✗
- **Not acceptable** because a single test falls below f′c by more than 500 psi.

Problem 2 — Control Chart

For an X̄-R chart with n = 4, $\bar{\bar{X}} = 4.2$ in., $\bar{R} = 1.0$ in. Compute UCL_X and LCL_X.

Solution:

- A_2 = 0.729 (n=4)
- UCL_X = 4.2 + (0.729)(1.0) = **4.93 in.**
- LCL_X = 4.2 – (0.729)(1.0) = **3.47 in.**

Problem 3 — Relative Compaction

Field dry density = 118 pcf. Lab Modified Proctor max dry density = 125 pcf. Compute relative compaction.

Solution:

$$RC = \frac{118}{125} \times 100 = \mathbf{94.4\%}$$

Problem 4 — Sampling Frequency

A project requires 180 yd³ of concrete in one day. How many strength tests are required?

Solution:

- 180/150 = 1.2 → round up to **2 tests**
- Also check daily: at least 1 test
- **2 tests** required.

Problem 5 — Nonconformance

A concrete cylinder breaks at 3,200 psi. f′c = 4,000 psi. What is the first action?

Solution:

- Identify nonconformance.

- Document on NCR.
- Notify engineer.
- Evaluate extent.
- Do **not** continue production without approval.

Problem 6 — Statistical

Given: 4.0, 4.5, 3.5, 5.0, 4.0. Compute CV.

Solution:

- Mean = 4.2
- s = 0.57
- CV = 0.57/4.2 = **0.136 or 13.6%**

Problem 7 — Asphalt Volumetrics

Gmm = 2.450, Gmb = 2.350, Gsb = 2.650, Pb = 5.5%. Compute air voids, VMA, VFA.

Solution:

- Pa = 100(2.450 − 2.350)/2.450 = **4.08%**
- VMA = 100 − (Ps × Gmb)/Gsb = 100 − (94.5 × 2.350)/2.650 = **16.20%**
- VFA = 100(16.20 − 4.08)/16.20 = **74.8%**

15. High-Yield Checklist

□ QA = owner verification; QC = contractor control

□ Concrete sampling: once/day, per 150 yd^3, per 5,000 ft^2

□ Concrete acceptance: avg of 3 consecutive ≥ f′c; no test < f′c − 500 psi (≤5,000 psi) or < f′c − 0.10 f′c (>5,000 psi)

□ Field-cured < 85% of lab-cured → improve curing

□ Core acceptance: avg of 3 ≥ 85% f′c; no single < 75% f′c

□ Relative compaction = (γd,field / γd,max) × 100%

□ Control chart formulas: $UCL_X = \bar{\bar{X}} + A_2\bar{R}$; $LCL_X = \bar{\bar{X}} - A_2\bar{R}$

□ Hold points stop work; witness points do not

□ Corrective action fixes existing; preventive action prevents potential

□ Documentation: if it isn't documented, it didn't happen

□ Statistical: use n−1 for sample std dev

□ Asphalt: Gmm, Gmb, VMA, VFA, Pa

□ Soils: Standard Proctor = D698/T99; Modified = D1557/T180

□ Audits verify QC plan is followed

□ Common errors: confusing QA/QC, wrong acceptance threshold, missing sampling frequency

16. Self-Test

1. **Define QA and QC.**
2. **What is the concrete sampling frequency per ACI 318?**
3. **A concrete mix has f′c = 6,000 psi. A single test is 5,300 psi. Is it acceptable?**
4. **Compute UCL_X for n=5, $\bar{\bar{X}}$=4.0, $\bar{R}$=1.2.**
5. **What is the relative compaction if field density = 120 pcf and lab max = 125 pcf?**
6. **What is a hold point?**
7. **What is the difference between corrective and preventive action?**
8. **What is the VMA formula?**

9. **What is the first action when a nonconformance is found?**
10. **What is the purpose of a quality audit?**

Answers:

1. QA = planned actions to provide confidence; QC = operational techniques to fulfill quality requirements.
2. Once/day, per 150 yd^3, per 5,000 ft^2.
3. No — 6,000 − 5,300 = 700 psi > 0.10 × 6,000 = 600 psi.
4. UCL_X = 4.0 + (0.577)(1.2) = **4.69 in.**
5. RC = 120/125 × 100 = **96%**
6. A point where work cannot proceed without approval.
7. Corrective fixes existing nonconformance; preventive prevents potential nonconformance.
8. VMA = 100 − (Ps × Gmb)/Gsb.
9. Document, notify engineer, evaluate extent.
10. To verify that the QC plan is being followed and effective.

17. Final Exam Tips

1. **Know QA vs. QC** — this is the most common conceptual question.
2. **Memorize concrete acceptance criteria** — high-yield.
3. **Practice control chart calculations** — formulas will be provided, but know how to use them.
4. **Understand hold vs. witness points** — hold stops work.
5. **Documentation is critical** — if it isn't documented, it didn't happen.
6. **Corrective vs. preventive action** — don't mix them up.
7. **Material-specific frequencies** — concrete, soils, asphalt.
8. **Statistical traps** — sample vs. population std dev, n−1.

9. **Field vs. lab testing** — know the difference and when each is used.
10. **If a detail is not in the Reference Handbook, it may be outside the exam scope** — flag it and move on.

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.

Act as a licensed PE an...
TXT 3.03KB

Thought for 4 seconds

用户需要一份关于混凝土放置的全面考试复习指南，涵盖从预放置规划到缺陷修复的完整流程。我考虑从预放置规划、运输交付、浇筑方法、振捣、收面、养护、施工缝、高温低温施工以及检测验收等几个关键维度分别入手，并行搜索可以更快地获取所需的具体规定和步骤。

Found 78 web pages

搜索结果覆盖了预放置规划、运输、浇筑方法、振捣、收面、养护、施工缝以及高温低温施工等主要方面，信息比较全面。现在需要打开这些页面，获取更具体的规范要求、步骤和参数，以便后续整理成结构化的复习指南。

Read 8 pages

1. Concrete shall not be placed until all formwork, embedded parts, steel reinforcement, foundation surfaces, and... ↗
||Back load up to top of drum and add either ADVA® Flow or Glenium 3000 NS†|0:09 – 0:11|| ↗
Placing Concrete under Water ↗
The concrete shall be consolidated by internal vibration unless self- consolidating concrete is used ↗ B ↗ View All

搜索到的资料涵盖了混凝土浇筑从预放置规划到缺陷修复的完整流程，包括ACI规范的具体要求、施工参数和验收标准。这些信息足够支撑一份结构化的考试复习指南。接下来需要按照施工顺序，将关键规定、公式和常见陷阱整理成易于快速查阅的模块，并配上高收益的检查清单和自测题。

PE Civil: Construction — Concrete Placement

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to **Concrete Placement** within the Material, Production, and Execution Quality Control area of the NCEES PE Civil: Construction exam. Content is aligned with PE Civil Reference Handbook v2.0 Sections **2.5.2** (Concrete Proportioning and Placement), **2.5.2.1** (Mixture Proportioning — yield and absolute volume), **2.5.2.2** (Exposure Categories and Classes), **2.5.2.3** (Cover Requirements), **2.5.3** (Concrete Maturity and Early Strength Evaluation), and **2.5.1** (Material Properties and Testing). Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**. This review is exam-focused preparation and does not guarantee a passing score.

1. Pre-Placement Planning

1.1 Submittals and Mix Design

Before concrete placement, the contractor must submit and obtain approval for:

- **Mix designs** (proportioned per ACI 301) for each type and strength of concrete
- **Material certificates** (cement, aggregates, admixtures)
- **Formwork and shoring drawings**
- **Reinforcement shop drawings**
- **Placement procedures** for special conditions (hot/cold weather, underwater, mass concrete)
- **Curing plans**

1.2 Pre-Placement Checklist

Item	Requirement
Formwork	Completed, approved, clean, tight-fitting, properly oiled
Reinforcement	Placed within tolerance (±½ in. of dimensions shown); free of dirt, loose scale, oil [1]
Embedded items	Anchors, sleeves, inserts secured in place
Foundation/subgrade	Clean, damp, free from standing water, mud, oil, debris, frost, ice, and snow [1]
Absorptive surfaces	Moistened to a depth of at least 1 inch to prevent absorption of water from concrete [1]
Standing water	Must be removed before placement
Access and equipment	Sufficient access for placement and consolidation equipment; standby vibrators available

Exam Tip: Surfaces against which concrete will be placed must be **damp but free of standing water**. Dry absorptive surfaces will suck water from the mix, reducing the effective w/c ratio and causing plastic shrinkage cracking.

1.3 Reinforcement Tolerances (ACI 301 / ACI 117)

- Reinforcing steel placed within **±½ in.** of dimensions shown [1]
- Concrete cover per ACI 318 (see Section 6)

2. Batching, Mixing, Transporting, and Delivery

2.1 Ready-Mix Delivery

Parameter	Requirement
Mixing time (central plant)	Not less than 50 sec nor more than 90 sec
Mixing after water added	Minimum 50 revolutions; agitate at 2–4 rpm during transit [11]
Transit time (agitated)	Typically ≤90 min (up to 75°F); ≤60 min (75°–89°F) [69]
Transit time (non-agitated)	Typically ≤30 min when hauled in non-agitating trucks
Retempering	Adding water to restore slump **not permitted** except when concrete is delivered in transit mixers
Discharge time	Retempering and retesting completed at least 30 min prior to maximum allowable discharge time limit

2.2 Slump, Air Content, and Temperature

Property	Limit / Requirement
Slump	Must be within specified limits at time of placement; concrete not within limits shall not be used
Air content	Must be within specified limits; check by pressure method (ASTM C231) for normal-weight concrete
Concrete temperature (hot weather)	Maximum 90°F at time of placement [69]
Concrete temperature (cold weather)	Minimum 45°F at time of placing; discard concrete that freezes before reaching 500 psi

2.3 Retempering Rules

- Retempering by adding water is **not permitted** except when concrete is delivered in transit mixers
- Retempering operations must be completed **at least 30 minutes** prior to the maximum allowable discharge time limit
- Concrete that is not within specified slump or air content limits at time of placement **shall not be used**

Exam Tip: Adding water to concrete on site is a common exam trap. It increases the w/c ratio and reduces strength. The only legal retempering is adding water to a transit mixer that has not exceeded its time limit.

3. Placement Methods

3.1 Placement Method Comparison

Method	Best For	Key Limitations
Direct Chute	Slabs, shallow foundations	Free-fall limit applies
Pump	High-volume, hard-to-reach areas	Requires pumpable mix; line cleanup
Bucket	Columns, walls, deep foundations	Slow; requires crane
Conveyor	Large horizontal placements	Segregation risk; limited reach
Tremie	Underwater placement	Requires embedding in fresh concrete

3.2 Free-Fall Limits

Condition	Maximum Free-Fall
General concrete	3–4 ft if separation of coarse particles occurs [21]
Concrete with HRWR (superplasticizer)	10 ft
Self-consolidating concrete (SCC)	30 ft (9.1 m) [31]
Conventional concrete (shafts)	60 ft (18.3 m) [31]
Dry shafts ≤24 in. diameter	25 ft

Exam Tip: The free-fall limit depends on the mix. Conventional concrete: ~3–4 ft if segregation occurs. SCC: up to 30 ft. HRWR: up to 10 ft.

3.3 Lift Thickness and Placement Sequence

Condition	Lift Thickness
Reinforced members	6–20 in. [21]
Mass work	15–20 in. [21]
General (formed)	Not exceeding 24 in. [1]
Tremie placement	Not exceeding 20 in. (500 mm)

Placement Sequence Rules:

- Place in **continuous horizontal lifts** with adequate vibration following each layer [1]
- Place concrete as nearly as possible in its **final position** — moving horizontally over long distances causes segregation [21]

- Separate batches shall follow each other closely; interval between successive batches **not greater than 20 minutes** [31]
- In high walls, place to about 1 ft below top and allow ~1 hour for settling; resume before setting occurs to avoid cold joints [21]
- Columns and walls: allow to stand **at least 2 hours** before placing slabs/beams framing into them [21]

3.4 Underwater Placement (Tremie)

- Tremie tube lower end must be **kept embedded in fresh concrete** to prevent washing and segregation [21]
- Tremie inside diameter ≥ **6× maximum aggregate size**, and not less than **10 in.**
- Discharge in horizontal layers not exceeding **20 in.** thick
- Concrete must be placed in one continuous operation from bottom to top

4. Consolidation

4.1 Internal Vibration Requirements

Parameter	Requirement
Method	Internal vibration required unless SCC is used [31]
Insertion	Vertically into concrete at point of deposit
Spacing	Not farther apart than **2× the radius of visible effectiveness** (typically ~24 in.); overlap vibrated areas [31]

Parameter	Requirement
Duration	Sufficient to consolidate but not cause segregation; **3–15 seconds** per insertion; **3–5 seconds** for bridge decks [31]
Depth	Head must penetrate into previous lift (typically 4–6 in.)
Withdrawal	Withdraw **very slowly** to avoid void formation
Prohibited	Vibrators shall **not** be attached to forms, reinforcement, or surface [31]

4.2 Over-Vibration vs. Under-Vibration

Condition	Result	Signs
Under-vibration	Honeycomb, entrapped air, voids	Visible voids, exposed aggregate
Over-vibration	Segregation, bleeding, sand streaks	Excess paste at surface, coarse aggregate settles

Revibration: May be used to increase consolidation, but must be done while concrete is still plastic. Not a substitute for proper initial consolidation.

Exam Tip: The vibrator should be inserted at points no farther apart than **2× the radius of visible effectiveness** (typically ~24 in. for a 2-in. vibrator). Over-vibration causes segregation; under-vibration causes honeycomb.

5. Finishing

5.1 Finishing Sequence (ACI 302.1R)

Operation	Timing	Purpose
Screeding	Immediately after placement	Strike off excess concrete to correct grade
Bull floating	Immediately after screeding, before bleed water appears	Level surface, embed aggregate, remove humps
Darbying	Same as bull floating (for smaller areas)	Compacting and smoothing
Waiting period	After bull floating, before further finishing	Allow bleed water to dissipate
Floating	After bleed water disappears	Compact and smooth surface, close cracks
Troweling	After floating	Produce smooth, dense surface
Brooming	After troweling (for broomed finish)	Provide slip-resistant texture [41]
Edging	While plastic	Round edges to prevent chipping
Jointing	While plastic	Create contraction joints

5.2 Finish Types (ACI 301)

Finish	Application	Procedure
Float Finish	Footings, formed surfaces	Hand or power float; minimum passes [41]
Steel Trowel Finish	Channels, foundation slabs	Trowel to smooth, dense surface [41]

Finish	Application	Procedure
Broom Finish	Walks, decks, slabs on grade	Steel trowel then broom perpendicular to traffic [41]
Scratch Finish	Surfaces to receive bonded topping	Screed, bull float, then scratch with stiff brush

5.3 Common Finishing Errors

Error	Consequence
Finishing before bleed water dissipates	Plastic shrinkage cracking, weak surface
Adding water to surface during finishing	Reduced surface strength, dusting
Over-troweling	Surface densification, but can cause crazing
Delayed jointing	Random cracking
Not bull floating immediately	Surface irregularities, hard to finish

6. Curing

6.1 Curing Methods

Method	Description	Best For
Wet curing	Ponding, sprinkling, wet burlap	Slabs, flatwork

Method	Description	Best For
Moisture-retaining covers	Waterproof paper, plastic sheets	General
Curing compounds	Membrane-forming liquid	Vertical surfaces, areas where wet curing impractical
Steam curing	Accelerated curing	Precast plants

6.2 Curing Duration (ACI 308)

Condition	Minimum Duration
General (Type I/II cement)	7 days or until 70% of specified strength, whichever is shorter [50]
High-early-strength (Type III)	3 days
Type II cement	May extend to 14 days [50]
At temperatures >40°F	7 days minimum [50]

6.3 Curing Temperature

- Maintain concrete at **relatively constant temperature** for the curing period [41]
- Protect from **premature drying** and **excessively hot or cold temperatures** [41]
- Initial curing shall immediately follow finishing [41]

6.4 Curing Compound Rules

- Curing compounds **shall not** be used on surfaces that will receive additional concrete or cementitious finishing materials [41]
- Reapply as necessary to maintain continuous water-retaining film
- White-pigmented Type 2 compound is most commonly used on pavements [50]

7. Joints

7.1 Joint Types (ACI 224.3R)

Joint Type	Purpose	Reinforcement
Construction Joint	Interface between placements to facilitate construction [59]	Bonded or unbonded per design
Contraction Joint	Weakened plane to regulate cracking from dimensional change [59]	Typically unbonded
Isolation Joint	Separation to allow movement in three directions; all bonded reinforcement interrupted [59]	All bonded reinforcement interrupted
Expansion Joint	Separation to allow movement due to dimensional increases; some or all bonded reinforcement interrupted [59]	Some or all interrupted
Cold Joint	Unintentional discontinuity from delay in placement that precludes bonding [59]	—

7.2 Joint Requirements

Parameter	Requirement
Contraction joint depth	At least **¼ of slab thickness**
Sawed joints	Complete within **4–12 hours** after placement
Construction joint surface	Cleaned, roughened to ¼-in. amplitude, moistened
Joint sealing	Defer 60–90 days for industrial floors (ACI recommendation)

Exam Tip: Contraction joints are **weakened planes** (sawed or formed). Isolation joints **interrupt all bonded reinforcement**. Construction joints are **planned interfaces**. Cold joints are **unplanned** and generally unacceptable without engineering approval.

8. Hot-Weather and Cold-Weather Concreting

8.1 Hot-Weather Concreting (ACI 305)

Parameter	Requirement
Definition	High air temperature + low humidity + wind that impairs quality [69]
Maximum concrete temperature	90°F at time of placement [69]
With HRWR	Maximum 100°F [69]
Maximum time (agitated, ≤75°F)	90 min [69]
Maximum time (agitated, 75°–89°F)	60 min [69]

Parameter	Requirement
Maximum time (non-agitated, ≤80°F)	30 min [69]
Maximum time (non-agitated, >80°F)	15 min [69]
Set retarders	Extend time by 30 min for agitated concrete [69]
Cooling methods	Chilled water, ice, fog-spray forms and subgrade

8.2 Cold-Weather Concreting (ACI 306)

Parameter	Requirement
Definition	Air temperature at or below 40°F
Minimum placement temperature	45°F
No placement below	35°F atmospheric temperature [69]
Concrete temperature target	70°F (heat mixing water to achieve) [69]
Maximum mixing water temperature	165°F entering mixer [69]
Maximum aggregate temperature	150°F entering mixer [69]
Protection	Insulating blankets, heaters if freezing anticipated within 7 days [1]
Calcium chloride	**Not permitted** [69]
Protect from freezing until	Compressive strength reaches 500 psi

Exam Tip: Hot weather: max concrete temp 90°F (100°F with HRWR). Cold weather: min concrete temp 45°F; no placement below 35°F ambient. Calcium chloride is prohibited.

9. Testing and QC During Placement

9.1 Tests Required During Placement

Test	Standard	Frequency
Slump	ASTM C143 / AASHTO T119	Each truck or as specified
Air content	ASTM C231 / C173	Each truck for air-entrained concrete
Unit weight / Yield	ASTM C138 / AASHTO T121	As specified
Concrete temperature	ASTM C1064	Each truck
Compressive strength cylinders	ASTM C31 / C39	Per ACI 318 frequency (see below)

9.2 Strength Test Frequency (ACI 318)

- Not less than **once per day**
- Not less than **once for each 150 yd^3** of concrete
- Not less than **once for each 5,000 ft^2** of surface area for slabs or walls
- **Exemption:** If total quantity < 50 yd^3, strength tests not required when evidence of satisfactory strength is submitted and approved

9.3 Acceptance Criteria (ACI 318)

The strength level of an individual class of concrete is satisfactory if **both**:

1. Every arithmetic average of any three consecutive strength tests ≥ f′c
2. No strength test falls below f′c by more than:

- **500 psi** when f′c ≤ 5,000 psi
- **0.10 f′c** when f′c > 5,000 psi

9.4 Field-Cured vs. Laboratory-Cured Cylinders

Condition	Requirement
Field-cured strength < 85% of lab-cured strength	Procedures for protecting and curing concrete shall be improved
Exception	The 85% limitation does not apply if field-cured strength exceeds f′c by more than 500 psi

9.5 Core Testing

Criterion	Requirement
Testing time	Cores tested no later than 7 days after drilling
Acceptance	Average of three cores ≥ 85% f′c AND no single core < 75% f′c

9.6 Concrete Maturity (Handbook Section 2.5.3)

$$M = \sum_{0}^{t} (T - T_0)\Delta t$$

where:

- M = maturity index (°F·hours)
- T = average concrete temperature during interval Δt
- T_0 = datum temperature (usually 32°F unless otherwise specified)

- t = elapsed time (hours)
- Δt = time intervals (hours)

Exam Tip: Maturity method estimates in-place strength based on temperature history. It is a nondestructive method for new construction.

10. Cover Requirements and Placement Around Reinforcement

10.1 Concrete Cover Requirements (ACI 318)

Cast-in-Place Nonprestressed Members:

Exposure	Member	Reinforcement	Cover (in.)
Cast against ground	All	All	3
Exposed to weather/ground	All	No. 6–No. 18	2
Exposed to weather/ground	All	No. 5 and smaller	1½
Not exposed	Slabs, joists, walls	No. 14, No. 18	1½
Not exposed	Slabs, joists, walls	No. 11 and smaller	¾
Not exposed	Beams, columns	Primary reinforcement	1½

10.2 Placement Around Reinforcement

- Concrete shall be thoroughly vibrated **around all embedded items, anchors, and reinforcement** to ensure complete consolidation [1]

- Concrete placed by free fall shall fall **directly to the base without contacting the rebar cage or sidewall** [31]
- Vibrators shall **not** be attached to reinforcement bars [31]

11. Defects and Remediation

Defect	Cause	Remediation
Honeycomb	Under-vibration, segregation	Chip out, patch with approved repair mortar
Voids	Under-vibration, blocked access	Chip out, patch, or grout injection
Segregation	Excessive free fall, over-vibration, dropping through rebar	Remove and replace if severe
Plastic shrinkage cracking	Rapid moisture loss before set	Proper curing, fog spray, avoid finishing too early
Cold joints	Delay in placement	Remove laitance, roughen, apply bonding agent, place new concrete
Surface defects	Improper finishing, curing	Grind, patch, or resurface per specification

Exam Tip: Honeycomb = under-vibration. Segregation = over-vibration or excessive free fall. Cold joint = unplanned delay. Plastic shrinkage cracking = rapid moisture loss.

12. Safety and Inspection Hold Points

12.1 Safety Considerations

- Formwork and shoring must be designed for concrete pressure (ACI 347)
- Fall protection required for elevated placements
- Electrical safety for vibrators and pumps
- Personal protective equipment (PPE)

12.2 Inspection Hold Points

Hold Point	What to Verify
Before placement	Formwork, reinforcement, embedments, subgrade moisture condition
During placement	Slump, air content, temperature, consolidation
After placement	Finishing, curing, protection
Before formwork removal	Concrete strength (per ACI 301 or approved schedule)

Exam Tip: Hold points stop work. Witness points do not stop work. Both must be documented.

13. Common Errors, Assumptions, and Exam Traps

Trap	Correct Approach
Adding water to concrete on site	Retempering only permitted in transit mixers; must be completed 30 min before time limit
Placing concrete on dry, absorptive subgrade	Moisturize subgrade to prevent water absorption

Trap	Correct Approach
Using free-fall limits for all mixes	Limits vary: 3–4 ft (general), 10 ft (HRWR), 30 ft (SCC), 60 ft (shafts, conventional)
Forgetting to vibrate around embedments	Thoroughly vibrate around all embedded items and reinforcement
Finishing before bleed water dissipates	Wait until bleed water disappears before floating/troweling
Curing for only 3 days for all concrete	7 days for Type I/II; 3 days for Type III; Type II may need 14 days
Confusing joint types	Construction = planned interface; contraction = weakened plane; isolation = movement joint
Using cold joint as acceptable	Cold joints are unplanned and require engineering approval
Ignoring concrete temperature limits	Max 90°F (hot); min 45°F (cold); no placement below 35°F ambient
Forgetting core testing time limit	Cores tested no later than 7 days after drilling
Using wrong acceptance threshold	500 psi for $f'_c \leq 5{,}000$ psi; 0.10 f'_c for > 5,000 psi
Not checking field-cured vs. lab-cured	Field-cured < 85% of lab-cured → improve curing

14. Practice Problems with Detailed Solutions

Problem 1 — Sampling Frequency

A project requires 180 yd^3 of concrete in one day. How many strength tests are required per ACI 318?

Solution:

- 180 yd^3 / 150 yd^3 per test = 1.2 → round up to **2 tests**
- Also check daily: at least 1 test
- **2 tests** required.

Problem 2 — Strength Acceptance

A concrete mix has f′c = 4,500 psi. The last three consecutive strength tests averaged 4,600 psi. A single test result was 3,900 psi. Is the concrete acceptable?

Solution:

- Check average: 4,600 ≥ 4,500 ✓
- Check individual: 4,500 − 3,900 = 600 psi > 500 psi ✗
- **Not acceptable** because a single test falls below f′c by more than 500 psi.

Problem 3 — Core Acceptance

Three cores give results of 82%, 78%, and 88% of f′c. Is the concrete structurally adequate?

Solution:

- Average = (82 + 78 + 88)/3 = 82.67% < 85% ✗
- No single core < 75% ✓ (78% > 75%)
- **Not adequate** because the average of three cores is less than 85% of f′c.

Problem 4 — Field-Cured vs. Lab-Cured

A field-cured cylinder breaks at 3,800 psi. A companion laboratory-cured cylinder breaks at 4,500 psi. f′c = 4,000 psi. What action is required?

Solution:

- Field-cured / Lab-cured = 3,800/4,500 = 84.4% < 85%
- **Improve curing procedures** — field-cured is less than 85% of lab-cured.
- Exception does not apply because field-cured (3,800 psi) does not exceed f′c by more than 500 psi.

Problem 5 — Maturity Calculation

A concrete element has a maturity index of 4,000 °F·hours. The datum temperature is 32°F. If the average concrete temperature was 72°F, how many hours did it take to reach this maturity?

Solution:

- $M = \Sigma(T - T_0)\Delta t \rightarrow 4{,}000 = (72 - 32) \times t = 40t$
- $t = 4{,}000 / 40 =$ **100 hours**.

Problem 6 — Yield Calculation

A concrete mix has a unit weight of 145 pcf. The yield is calculated to be 27.5 ft³ per batch. What is the total mass of the batch?

Solution:

- Total mass = unit weight × yield = 145 pcf × 27.5 ft³ = **3,987.5 lb** ≈ 3,988 lb.

Problem 7 — Absolute Volume

A concrete mix design uses the absolute volume method. The coarse aggregate has a bulk specific gravity (SSD) of 2.65 and a mass of 1,850 lb. What is the absolute volume of the coarse aggregate?

Solution:

- Absolute volume = Mass / (Specific Gravity × Unit Weight of Water)
- = 1,850 / (2.65 × 62.4) = 1,850 / 165.36 = **11.19 ft³** ≈ 11.2 ft³.

Problem 8 — Free-Fall Limit

A contractor is placing concrete in a dry shaft using conventional concrete. What is the maximum allowable free-fall height?

Solution:

- Conventional concrete: 60 ft (18.3 m) maximum [31]
- If SCC is used: 30 ft (9.1 m) maximum [31]
- **60 ft** for conventional concrete.

Problem 9 — Hot Weather Concreting

The concrete temperature at the time of placement is 95°F. Is this acceptable?

Solution:

- Maximum concrete temperature at placement: 90°F (or 100°F with HRWR) [69]
- 95°F > 90°F → **Not acceptable** (unless HRWR is used, in which case 100°F limit applies).
- If HRWR is not used, concrete must be cooled before placement.

Problem 10 — Cold Weather Concreting

The atmospheric temperature is 38°F. Can concrete be placed?

Solution:

- Cold weather concreting applies at or below 40°F

- No concrete should be mixed or placed when atmospheric temperature is at or below 35°F [69]
- 38°F > 35°F → **Yes**, concrete can be placed, but must follow ACI 306 cold-weather procedures.
- Concrete temperature must be at least 45°F at time of placing .

15. High-Yield Checklist

□ Pre-placement: formwork, reinforcement, embedments, subgrade clean/damp, no standing water

□ Reinforcement tolerance: ±½ in.; cover per ACI 318

□ Mixing time: 50–90 sec; transit time limits per temperature

□ Retempering: only in transit mixers; complete 30 min before time limit

□ Free-fall limits: 3–4 ft (general), 10 ft (HRWR), 30 ft (SCC), 60 ft (shafts, conventional)

□ Lift thickness: 6–20 in. (reinforced), 15–20 in. (mass), 24 in. max (formed)

□ Batch interval: not greater than 20 min

□ Vibration: spacing ≤ 2× radius of effectiveness; duration 3–15 sec; no form/rebar attachment

□ Bull float immediately after screeding, before bleed water

□ Curing: 7 days (Type I/II), 3 days (Type III), 14 days (Type II may extend)

□ Curing compounds: not on surfaces to receive additional concrete

□ Joints: construction (planned interface), contraction (weakened plane), isolation (movement), cold (unplanned)

□ Hot weather: max 90°F (100°F with HRWR); cold weather: min 45°F, no placement below 35°F

□ Strength tests: once/day, per 150 yd^3, per 5,000 ft^2

□ Acceptance: avg of 3 consecutive ≥ f′c; no test < f′c − 500 psi (≤5,000 psi) or < f′c − 0.10 f′c (>5,000 psi)

□ Field-cured < 85% of lab-cured → improve curing

□ Core acceptance: avg of 3 ≥ 85% f′c; no single < 75% f′c

□ Maturity: $M = \Sigma(T - T_0)\Delta t$

□ Defects: honeycomb (under-vibration), segregation (over-vibration), cold joint (delay), plastic shrinkage (moisture loss)

16. Self-Test

1. **What is the minimum concrete temperature for cold-weather placement?**
2. **What is the maximum concrete temperature for hot-weather placement?**
3. **What is the maximum free-fall height for self-consolidating concrete?**
4. **What is the minimum curing duration for Type I cement?**
5. **A concrete mix has f′c = 6,000 psi. A single test is 5,300 psi. Is it acceptable?**
6. **What is the core acceptance criterion?**
7. **What is the difference between a construction joint and a cold joint?**
8. **How long after placement must sawed contraction joints be completed?**
9. **What is the maximum batch interval during continuous placement?**
10. **What is the maturity formula?**

Answers:

1. 45°F at time of placing.
2. 90°F (100°F with HRWR).
3. 30 ft (9.1 m).
4. 7 days or until 70% of specified strength, whichever is shorter.
5. No — 6,000 − 5,300 = 700 psi > 0.10 × 6,000 = 600 psi.
6. Average of three cores ≥ 85% f′c AND no single core < 75% f′c.
7. Construction joint = planned interface; cold joint = unplanned discontinuity from delay.
8. Within 4–12 hours after placement.

9. 20 minutes.
10. $M = \Sigma(T - T_0)\Delta t$.

17. Final Exam Tips

1. **Know the acceptance criteria** — 500 psi vs. 0.10 f′c threshold is high-yield.
2. **Memorize sampling frequency** — once/day, per 150 yd^3, per 5,000 ft^2.
3. **Remember the 50 yd^3 exemption** — strength tests not required if approved.
4. **Field-cured vs. lab-cured** — 85% rule is frequently tested.
5. **Core criteria** — 85% average, 75% individual minimum.
6. **Retempering rules** — only in transit mixers; complete 30 min before time limit.
7. **Free-fall limits** — vary by mix type (3–4 ft general, 10 ft HRWR, 30 ft SCC, 60 ft shafts).
8. **Vibration spacing** — 2× radius of visible effectiveness.
9. **Curing duration** — 7 days (Type I/II), 3 days (Type III), 14 days (Type II may extend).
10. **Hot/cold weather limits** — max 90°F (100°F HRWR); min 45°F, no placement below 35°F.
11. **Joint types** — construction (planned), contraction (weakened plane), isolation (movement), cold (unplanned).
12. **Maturity formula** — $M = \Sigma(T - T_0)\Delta t$.
13. **Defect causes** — honeycomb = under-vibration; segregation = over-vibration or excessive free fall.
14. **Batch interval** — not greater than 20 minutes.
15. **If a detail is not in the Reference Handbook, it may be outside the exam scope** — flag it and move on.

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.

78 web pages

Act as a licensed PE an...
TXT 3.59KB

Thought for 15 seconds

We need answer to user. User provided file content asking: "Act as licensed PE... Provide comprehensive exam-focused review of only Concrete Maturity and Early Strength Evaluation..." They want generated review. We have file content. We need produce final answer, likely same as earlier reviews. We need follow scope. Need generate actual review. We have previous examples from assistant for other topics. Need craft comprehensive exam-focused review for Concrete Maturity and Early Strength Evaluation. Align with NCEES PE Civil: Construction, PE Civil Reference Handbook v2.0, sections 2.5.3, 2.5.3.1, 2.5.3.2, 2.5.1, 2.5.2, 1.4.2, ACI 318/301. Need cover subtopics listed. Provide definitions, formulas, step-by-step procedures, worked examples, high-yield tips. Tables, bullet lists. Practice problems with detailed solutions. End with high-yield checklist and self-test. Flag outside scope. Don't claim guaranteed pass.

We need produce final answer. We can draw from handbook content: Section 2.5.3.1 gives maturity formula M = sum (T - T0) Δt, M maturity index (°F - hours), T average concrete temp (°F), T0 datum temp (°F) usually 32°F unless otherwise specified, t elapsed time (H), Δt time intervals (H). Section 2.5.3.2 NDT methods table. ACI 318/301 strength test requirements: sampling frequency, acceptance criteria, field-cured vs lab-cured 85%, core testing 85%/75%. Also statistical quality control section 1.4.2 maybe not directly? But can mention. Need cover all subtopics. We need maybe mention Equivalent age/Arrhenius if within scope flag: The PE Civil Reference Handbook v2.0 does not include Arrhenius equivalent age method. NCEES exam specifications likely only include maturity method (TTF). So flag: Arrhenius equivalent age is not specified in the PE Civil Reference Handbook or NCEES exam specs; treat as outside scope unless question provides. Good.

We should structure similar to previous. Use headings. Ensure not too overlong? Desired oververbosity 5. But user asks comprehensive. We can produce substantial. Need maybe include tables. We should be careful to not invent exam content. Use handbook content. We can include "per Handbook" and "outside scope" flags. We can include worked examples. Need practice problems with detailed solutions. End checklist and self-test.

Let's plan.

Title: PE Civil: Construction — Concrete Maturity and Early Strength Evaluation. Exam-focused review.

Scope note.

Part 1: Purpose and Benefits

- form removal, post-tensioning, opening to traffic, cold-weather protection, scheduling, QC.
- Benefits: avoid unnecessary waiting, reduce formwork cost, safety.

Part 2: Concrete Maturity Method

- Definition: maturity index based on temperature history.
- TTF formula: $M = \Sigma (T - T0) \Delta t$.
- Units: °F·hours or °C·hours. Datum temp typically 32°F (0°C) unless otherwise specified.
- T average concrete temperature during interval; T0 datum; Δt time interval.
- Step-by-step procedure: embed sensors, log temperature, compute maturity, use calibration curve to estimate strength.
- Sensors: thermocouples, data loggers; placement representative of critical locations (e.g., near surface? Actually for strength, place near center or critical section).
- Limitations: mix-specific calibration; curing method; temperature history; sensor placement; not valid for all mixes; need validation.

Part 3: Maturity Calibration

- Lab maturity-strength relationship: prepare trial mixes, cylinders, cure at different temperatures, measure maturity at test ages, plot strength vs maturity, curve fit (logarithmic, exponential, hyperbolic). Validate with field cylinders.
- Limitations: calibration must match field mix, materials, curing. Cannot use generic curve without validation.
- Step-by-step.

Part 4: Equivalent Age / Arrhenius

- Flag: Not specified in PE Civil Reference Handbook v2.0 or NCEES exam specs. If encountered, use provided equation. Do not invent.

Part 5: Early Strength Evaluation Methods

- Table of methods: field-cured cylinders, match-cured cylinders, cast-in-place cylinders, cores, pullout, pull-off, probe penetration, rebound hammer, pulse velocity, maturity.

- NDT table from Handbook 2.5.3.2: property/condition → primary/secondary methods.
- Describe each briefly.

Part 6: Nondestructive Test Methods for Concrete (from Handbook Table)

- In-place strength: pullout, pull-off, probe penetration, maturity (new construction); rebound hammer secondary.
- General quality: visual, rebound, pulse velocity, probe.
- Thickness: impact-echo, GPR, ultrasonic echo, eddy-current.
- Dynamic modulus: resonate frequency, pulse velocity, impact-echo, SASW.
- Density: gamma radiometry.
- Reinforcement location: covermeter, GPR, radiography, ultrasonic echo.
- Corrosion: half-cell potential, polarization resistance, radiography.
- Near-surface defects: sounding, infrared thermography, GPR, radiography.
- Internal defects: impact-echo, ultrasonic echo, impulse response, pulse velocity, SASW, radiography.

Part 7: Acceptance Criteria and Specification Conformance

- ACI 318 strength test requirements:
  - Frequency: once/day, per 150 yd^3, per 5,000 ft^2; exemption <50 yd^3 if evidence approved.
  - Strength test: average of at least two 6x12 cylinders or three 4x8 cylinders.
  - Acceptance: every average of 3 consecutive tests ≥ f'c; no individual test below f'c by more than 500 psi (f'c ≤ 5000 psi) or 0.10 f'c (>5000 psi).
- Field-cured vs lab-cured: if field-cured < 85% of lab-cured, improve curing; exception if field-cured exceeds f'c by >500 psi.
- Core testing: average of 3 cores ≥ 85% f'c; no single core <75% f'c; test within 7 days of drilling.
- Opening criteria: typically 75% of design strength? ACI 301? But maybe not specified. Flag if outside. Common: post-tensioning at 75% f'c; form removal per ACI 347. But we can mention that specific opening strengths are project-specific, refer to specs.
- Retest/nonconformance: additional cores, load tests, etc. Flag.

Part 8: Statistical Evaluation

- Mean, range, standard deviation, control charts. ACI 318 acceptance uses averages of consecutive tests. Control charts: X-bar and R charts. UCL, LCL formulas. Use for monitoring production.

- Acceptance evaluation: lower limit, upper limit, both.

Part 9: Factors Affecting Early Strength and Maturity Predictions

- Cement type (Type I, II, III), SCMs (fly ash, slag) slow early strength, admixtures (accelerators, retarders), w/cm ratio, curing temperature, insulation, sensor placement.
- Maturity method assumes strength-maturity relationship is unique for a given mix; temperature history effects (e.g., high early temperature may cause later strength reduction) not captured by TTF.

Part 10: Limitations, Assumptions, Common Errors

- Maturity is mix-specific; calibration required.
- Sensor placement: must represent critical section; not near surface if surface strength governs? Actually for form removal, critical location may be near surface; for structural, at rebar.
- Datum temperature assumption 32°F; if other, adjust.
- TTF method assumes linear relationship between temperature and strength gain above datum; not valid below datum.
- Does not account for effects of high temperature on later-age strength.
- NDT methods require calibration and are not direct strength measurements.
- Common errors: using uncalibrated maturity curve, wrong datum, sensor placement, using lab cylinders not match-cured, misinterpreting 85% rule, forgetting core test time limit.

Part 11: Practice Problems with Solutions

- Several problems: compute maturity, estimate strength from curve, acceptance criteria, core acceptance, field-cured vs lab-cured, NDT method selection, statistical.

Part 12: High-Yield Checklist

- $M = \Sigma(T - T0)\Delta t$, T0 typically 32°F.
- Maturity calibration required.
- Strength test frequency.
- Acceptance: avg 3 consecutive ≥ f'c; no test < f'c - 500 psi (≤5000) or 0.10 f'c (>5000).
- Field-cured <85% lab → improve curing; exception >500 psi above f'c.
- Cores: avg 3 ≥85% f'c, no single <75% f'c, test within 7 days.
- NDT methods table.
- Common errors.

Part 13: Self-Test

- Questions and answers.

We need ensure not too long but comprehensive. We can use tables. We can include references to Handbook sections.

We should not claim guaranteed pass. Include disclaimer.

Let's write final answer in a clear format. Use markdown. We can include equations. We need "If a detail is not specified by NCEES or falls outside the stated scope, flag it rather than inventing exam content." We'll do that.

Potential challenge: We need align with "current NCEES PE Civil: Construction exam specifications" but we don't have actual specs. We can say "aligned with the topics listed in the prompt and the PE Civil Reference Handbook v2.0." That's fine.

Let's produce final. Need maybe mention "Section 2.5.3.2 Nondestructive Test Methods" table exactly from handbook. We can reproduce.

We'll write.

We need include "Equivalent age / Arrhenius method if within scope; flag if not specified by NCEES or the handbook" — We'll flag: The PE Civil Reference Handbook v2.0 does not include the Arrhenius equivalent age method. NCEES exam specifications for Construction do not list it. Therefore, treat as outside scope unless a question provides the equation and data. Good.

We need "ACI 318/301 provisions referenced in the handbook" — We'll cite.

We need "Statistical evaluation of strength results: averages of consecutive tests, allowable deviations from f'c, and control chart concepts" — We'll cover.

We need "common exam traps and high-yield points" — include.

Let's final.

PE Civil: Construction — Concrete Maturity and Early Strength Evaluation

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to **Concrete Maturity and Early Strength Evaluation** within the Material, Production, and Execution Quality Control area of the NCEES PE Civil: Construction exam. It aligns with PE Civil Reference Handbook v2.0 Sections **2.5.3** (Concrete Maturity and Early Strength Evaluation), **2.5.3.1** (Concrete Maturity), **2.5.3.2** (Nondestructive Test Methods), **2.5.1** (Material Properties and Testing), **2.5.2** (Concrete Proportioning and Placement), **1.4.2** (Statistical Quality Control), and the ACI 318/301 provisions referenced in the Handbook. Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**. This review is exam-focused preparation and does not guarantee a passing score.

1. Purpose and Benefits of Maturity and Early Strength Evaluation

Early strength evaluation is used to make construction decisions before 28-day strength results are available. Common applications include:

Application	Why Early Strength Matters
Form removal	Avoid damage to immature concrete; optimize formwork cycling
Post-tensioning	Requires minimum strength before stressing
Opening to traffic	Pavements and bridge decks need sufficient strength
Cold-weather protection	Know when concrete can safely freeze (typically after 500 psi)
Construction scheduling	Reduce waiting time, accelerate next activities
Quality control	Monitor strength gain, detect problems early

Benefits:

- Reduces unnecessary waiting
- Lowers formwork costs

- Improves safety by verifying in-place strength
- Provides data for cold-weather and hot-weather concreting decisions

Exam Tip: Maturity and early strength evaluation are **not** replacements for 28-day acceptance tests. They are supplementary tools for construction operations.

2. Concrete Maturity Method

2.1 Definition

The **maturity method** estimates in-place concrete strength from the concrete's temperature history. It assumes that strength gain is a function of both time and temperature.

2.2 Time–Temperature Factor (TTF) Formula

$$M = \sum_{0}^{t} (T - T_0)\Delta t$$

where:

- M = maturity index (typically **°F·hours** or **°C·hours**)
- T = average concrete temperature during time interval Δt (°F or °C)
- T_0 = datum temperature, usually **32°F (0°C)** unless otherwise specified
- t = elapsed time (hours)
- Δt = time interval (hours)

Units: If T and T_0 are in °F, M is in °F·hours. If in °C, M is in °C·hours.

2.3 Step-by-Step Field Implementation

1. **Embed temperature sensors** at critical locations in the concrete (e.g., near the surface for form removal, at the core for structural strength).
2. **Connect sensors to a data logger** that records temperature at regular intervals (e.g., every 15–30 minutes).
3. **Compute maturity** using the TTF formula:
   - For each interval, calculate $(T - T_0)\Delta t$.
   - Sum all intervals to obtain M.
4. **Use a maturity calibration curve** to estimate strength from M.
5. **Verify** with field-cured cylinders or cores as required.

2.4 Datum Temperature

- Default: **32°F (0°C)**.
- Some specifications use **14°F (−10°C)** or other values.
- If the datum temperature is not 32°F, use the specified value. The Handbook states: "usually 32°F unless otherwise specified."

2.5 Worked Example — Maturity Calculation

Problem: A concrete element has the following temperature history:

Time Interval (hours)	Average Temperature (°F)
0–10	60
10–20	70
20–30	80

Datum temperature = 32°F. Compute the maturity index.

Solution:

$$
\begin{aligned}
M &= \sum (T - T_0)\Delta t \\
&= (60 - 32)(10) + (70 - 32)(10) + (80 - 32)(10) \\
&= (28)(10) + (38)(10) + (48)(10) \\
&= 280 + 380 + 480 \\
&= \mathbf{1{,}140}\ ^\circ\mathrm{F}\cdot\mathrm{hours}
\end{aligned}
$$

3. Maturity Calibration

3.1 Laboratory Maturity–Strength Relationship

The maturity method requires a **mix-specific calibration curve** that relates maturity index to compressive strength.

Step-by-step calibration:

1. **Prepare trial mixes** representative of the field concrete (same materials, proportions, and curing conditions).
2. **Cast cylinders** and cure them at different temperatures (e.g., 40°F, 60°F, 73°F, 90°F).
3. **Measure maturity** at the time of each strength test.
4. **Test cylinders** at various ages (e.g., 1, 3, 7, 14, 28 days).
5. **Plot strength vs. maturity** and fit a curve (logarithmic, exponential, hyperbolic, or polynomial).
6. **Validate** the curve with field-cured cylinders or cores from the actual placement.

3.2 Curve Fitting

Common relationships:

- **Logarithmic:** $S = a + b\ln(M)$
- **Exponential:** $S = ae^{bM}$
- **Hyperbolic:** $S = \frac{M}{a+bM}$

The Handbook does not prescribe a specific curve; use the best fit for the data.

3.3 Limitations

- Calibration is **mix-specific**. A curve for one mix cannot be used for another.
- Changes in cement type, SCMs, admixtures, or w/cm ratio invalidate the curve.
- Curing method and temperature history affect the relationship.
- The TTF method assumes strength gain is a unique function of maturity, which is not strictly true for all temperature histories (e.g., high early temperature can reduce later strength).

Exam Tip: If a problem provides a maturity–strength curve, use it. If not, state that calibration is required.

4. Equivalent Age / Arrhenius Method

[Outside NCEES scope] — The PE Civil Reference Handbook v2.0 does **not** include the Arrhenius equivalent age method. The NCEES PE Civil: Construction exam specifications do not list it. If a question provides the Arrhenius equation and data, follow the provided information. Do not memorize Arrhenius constants for the exam. Flag this as outside the stated scope.

5. Early Strength Evaluation Methods

5.1 Comparison of Methods

Method	Type	Measures	Best For
Field-cured cylinders	Destructive	Compressive strength	Actual curing conditions
Match-cured cylinders	Destructive	Compressive strength	Simulating in-place temperature
Cast-in-place cylinders	Destructive	Compressive strength	In-place strength
Cores	Destructive	Compressive strength	Existing structures
Pullout test	NDT	In-place strength	Early strength, form removal
Pull-off test	NDT	Bond strength	Bonded overlays
Probe penetration	NDT	In-place strength	Early strength
Rebound hammer	NDT	Surface hardness	General quality/uniformity
Pulse velocity	NDT	Dynamic modulus	Uniformity, defects
Maturity method	NDT	In-place strength	New construction

5.2 Field-Cured vs. Laboratory-Cured Cylinders

Condition	Requirement
Field-cured strength < 85% of lab-cured strength	Procedures for protecting and curing concrete shall be improved
Exception	The 85% limitation does not apply if field-cured strength exceeds f'_c by more than 500 psi

5.3 Core Testing

Criterion	Requirement
Testing time	Cores tested **no later than 7 days** after drilling
Acceptance	Average of **three cores** ≥ **85%** f'_c AND no single core < **75%** f'_c

Exam Tip: Cores are the most direct method for evaluating in-place strength of existing structures. The 85%/75% criteria are high-yield.

6. Nondestructive Test Methods for Concrete

Per Handbook Section 2.5.3.2:

Property or Condition	Primary NDT Method	Secondary NDT Method
In-place strength	Pullout test, Pull-off test (bond), Probe penetration, Maturity method (new construction)	Rebound hammer
General quality and uniformity	Visual inspection, Rebound hammer, Pulse velocity	Probe penetration
Thickness	Impact-echo, Ground-penetrating radar, Ultrasonic echo	Eddy-current thickness gauge
Dynamic modulus of elasticity	Resonate frequency (small specimens)	Pulse velocity, Impact-echo, Spectral analysis of surface waves
Density	Gamma radiometry (nuclear gauge)	—

Property or Condition	Primary NDT Method	Secondary NDT Method
Reinforcement location	Covermeter, Ground-penetrating radar	Radiography, Ultrasonic echo
Reinforcement bar size	Covermeter	Radiography
Corrosion state of steel reinforcement	Half-cell potential, Polarization resistance	Radiography
Presence of near-surface defects	Sounding, Infrared thermography	Ground-penetrating radar, Radiography
Presence of internal defects	Impact-echo, Ultrasonic echo, Impulse response	Pulse velocity, Spectral analysis of surface waves, Radiography

Exam Tip: NDT methods do not directly measure strength. They must be calibrated against destructive tests. The maturity method is the only NDT method that estimates strength from temperature history.

7. Acceptance Criteria and Specification Conformance

7.1 ACI 318 Strength Test Requirements

Sampling frequency:

- Not less than **once per day**
- Not less than **once for each 150 yd^3** of concrete
- Not less than **once for each 5,000 ft^2** of surface area for slabs or walls
- **Exemption:** If total quantity of a given class of concrete is **less than 50 yd^3**, strength tests are **not required** when evidence of satisfactory strength is submitted to and approved by the building

official.

Strength test: The average of the strengths of at least **two 6 in. × 12 in. cylinders** or at least **three 4 in. × 8 in. cylinders** made from the same sample of concrete and tested at 28 days (or at the test age designated for determination of f'_c).

Acceptance criteria: The strength level of an individual class of concrete shall be considered satisfactory if **both**:

1. Every arithmetic average of any **three consecutive strength tests** equals or exceeds f'_c.
2. No strength test falls below f'_c by more than:
   - **500 psi** when $f'_c \leq 5{,}000$ psi
   - **0.10** f'_c when $f'_c > 5{,}000$ psi

7.2 Field-Cured Cylinders

- Field-cured cylinders are used to determine whether the concrete in the structure is being protected and cured properly.
- If field-cured strength at the test age is **less than 85%** of companion laboratory-cured strength, procedures for protecting and curing concrete shall be improved.
- The 85% limitation does **not** apply if field-cured strength exceeds f'_c by more than 500 psi.

7.3 Core Testing

- Cores drilled from existing structures shall be tested **no later than 7 days** after drilling.
- The concrete in an area represented by core tests shall be considered structurally adequate if:
  - The average of **three cores** is equal to at least **85%** of f'_c, AND
  - No single core is less than **75%** of f'_c.

7.4 Opening Criteria

[Outside NCEES scope] — Specific opening strengths for form removal, post-tensioning, or traffic are project-specific and not standardized in the PE Civil Reference Handbook. Refer to project specifications or ACI 301/347. Typical values: post-tensioning at 75% f'_c; form removal per ACI 347.

7.5 Retest and Nonconformance

If strength tests fail acceptance criteria, options include:

- Additional cores
- Load tests (ACI 318 Chapter 27)
- Engineering evaluation
- Repair or replacement

[Outside NCEES scope] — Detailed retest procedures are not in the Handbook.

8. Statistical Evaluation of Strength Results

8.1 Descriptive Statistics

Statistic	Formula
Mean	$\bar{X} = \frac{1}{n}\sum X_i$
Range	$R = X_{\max} - X_{\min}$
Sample standard deviation	$s = \sqrt{\frac{1}{n-1}\sum(X_i - \bar{X})^2}$
Coefficient of variation	$CV = \frac{s}{\bar{X}}$

8.2 Control Charts

- **X̄ chart:** monitors the mean strength. $UCL_X = \bar{\bar{X}} + A_2\bar{R}$; $LCL_X = \bar{\bar{X}} - A_2\bar{R}$.
- **R chart:** monitors variability. $UCL_R = D_4\bar{R}$; $LCL_R = D_3\bar{R}$.
- Constants A_2, D_3, D_4 depend on subgroup size n (see Handbook Section 1.4.2).

8.3 Acceptance Evaluation

- **Lower limit only:** Accept if $\bar{X} \geq L$.
- **Upper limit only:** Accept if $\bar{X} \leq U$.
- **Both limits:** Accept if $L \leq \bar{X} \leq U$.

Exam Tip: Control charts are used for production monitoring, not for acceptance. Acceptance is per ACI 318 criteria.

9. Factors Affecting Early Strength and Maturity Predictions

Factor	Effect on Early Strength / Maturity
Cement type	Type III (high-early) gains strength faster; Type I/II slower
SCMs (fly ash, slag)	Slow early strength; maturity calibration must reflect this
Admixtures	Accelerators increase early strength; retarders decrease
w/cm ratio	Lower w/cm → higher strength; affects maturity curve
Curing temperature	Higher temperature accelerates early strength but may reduce later strength
Insulation	Retains heat, accelerates maturity

Factor	Effect on Early Strength / Maturity
Sensor placement	Must represent critical location; improper placement gives misleading maturity

Exam Tip: The maturity method assumes the strength–maturity relationship is unique for a given mix. Temperature history effects (e.g., high early temperature) are not captured by TTF alone.

10. Limitations, Assumptions, and Common Errors

Limitation / Assumption	Explanation
Mix-specific calibration	Curve cannot be transferred between mixes
Datum temperature	Usually 32°F; if not, use specified value
Linear TTF	Assumes strength gain is linear with temperature above datum
No high-temperature effects	Does not account for later-age strength reduction from high early temperature
Sensor placement	Must be at critical location
NDT calibration	NDT methods require calibration against destructive tests
Cores	Must be tested within 7 days; 85%/75% criteria
Field-cured cylinders	85% rule; exception if > f_c' + 500 psi

Common Errors:

- Using an uncalibrated maturity curve.

- Using wrong datum temperature.
- Placing sensors in non-critical locations.
- Confusing field-cured and lab-cured criteria.
- Forgetting core testing time limit.
- Using NDT methods without calibration.
- Misinterpreting the 85% rule (it applies to field-cured vs. lab-cured, not to acceptance).

11. Practice Problems with Detailed Solutions

Problem 1 — Maturity Calculation

A concrete element has the following temperature history. Datum temperature = 32°F. Compute the maturity index.

Time Interval (hours)	Average Temperature (°F)
0–12	55
12–24	65
24–36	75

Solution:

$$\begin{aligned} M &= (55-32)(12) + (65-32)(12) + (75-32)(12) \\ &= (23)(12) + (33)(12) + (43)(12) \\ &= 276 + 396 + 516 \\ &= \mathbf{1{,}188}\ ^\circ\text{F}\cdot\text{hours} \end{aligned}$$

Problem 2 — Strength Acceptance

A concrete mix has $f'_c = 4{,}500$ psi. The last three consecutive strength tests averaged 4,600 psi. A single test result was 3,900 psi. Is the concrete acceptable?

Solution:

- Check average: $4{,}600 \geq 4{,}500$ ✓
- Check individual: $4{,}500 - 3{,}900 = 600$ psi > 500 psi ✗
- **Not acceptable** because a single test falls below f'_c by more than 500 psi.

Problem 3 — Core Acceptance

Three cores give results of 82%, 78%, and 88% of f'_c. Is the concrete structurally adequate?

Solution:

- Average = $(82 + 78 + 88)/3 = 82.67\%$ < 85% ✗
- No single core < 75% ✓ (78% > 75%)
- **Not adequate** because the average of three cores is less than 85% of f'_c.

Problem 4 — Field-Cured vs. Lab-Cured

A field-cured cylinder breaks at 3,800 psi. A companion laboratory-cured cylinder breaks at 4,500 psi. $f'_c = 4{,}000$ psi. What action is required?

Solution:

- Field-cured / Lab-cured = $3{,}800/4{,}500 = 84.4\%$ < 85%
- **Improve curing procedures** — field-cured is less than 85% of lab-cured.

- Exception does not apply because field-cured (3,800 psi) does not exceed f'_c by more than 500 psi.

Problem 5 — NDT Method Selection

Which NDT method is most appropriate for determining the in-place strength of new concrete?

A) Rebound hammer
B) Maturity method
C) Half-cell potential
D) Ground-penetrating radar

Answer: B

Solution: The maturity method is specifically used for determining in-place strength of new construction by monitoring temperature history. Rebound hammer measures surface hardness; half-cell potential measures corrosion; GPR locates reinforcement or defects.

Problem 6 — Statistical Evaluation

Given strength test results: 4,200, 4,500, 4,000, 4,800, 4,300 psi. Compute the mean, range, and sample standard deviation.

Solution:

- Mean = $(4{,}200 + 4{,}500 + 4{,}000 + 4{,}800 + 4{,}300)/5 = 21{,}800/5 = \mathbf{4{,}360}$ psi
- Range = $4{,}800 - 4{,}000 = \mathbf{800}$ psi
- Sample standard deviation:
  - Deviations: −160, +140, −360, +440, −60
  - Squared: 25,600; 19,600; 129,600; 193,600; 3,600

- Sum = 372,000
- $s = \sqrt{372{,}000/4} = \sqrt{93{,}000} = \mathbf{305}$ psi

Problem 7 — Maturity Calibration

A maturity calibration curve gives the following relationship: $S = 1{,}200\ln(M) - 5{,}000$, where S is strength in psi and M is maturity in °F·hours. If the maturity index is 2,500 °F·hours, what is the estimated strength?

Solution:

$$S = 1{,}200\ln(2{,}500) - 5{,}000$$

$\ln(2{,}500) \approx 7.824$

$$S = 1{,}200(7.824) - 5{,}000 = 9{,}388.8 - 5{,}000 = \mathbf{4{,}389}\text{ psi}$$

12. High-Yield Checklist

□ Maturity formula: $M = \sum(T - T_0)\Delta t$

□ Datum temperature: usually 32°F (0°C) unless otherwise specified

□ Maturity units: °F·hours or °C·hours

□ Maturity calibration is mix-specific

□ Field-cured vs. lab-cured: field-cured < 85% of lab-cured → improve curing

□ Exception: if field-cured > $f'_c + 500$ psi

□ Core acceptance: average of 3 ≥ 85% f'_c; no single < 75% f'_c

□ Cores tested within 7 days of drilling

□ Strength test frequency: once/day, per 150 yd³, per 5,000 ft²

- □ Exemption: < 50 yd³ if evidence approved
- □ Acceptance: average of 3 consecutive ≥ f'_c; no test < $f'_c - 500$ psi (≤5,000 psi) or < $f'_c - 0.10f'_c$ (>5,000 psi)
- □ NDT methods: pullout, pull-off, probe penetration, maturity (in-place strength)
- □ Rebound hammer, pulse velocity (general quality)
- □ Impact-echo, GPR, ultrasonic echo (thickness, defects)
- □ Half-cell potential (corrosion)
- □ Common errors: uncalibrated maturity curve, wrong datum, sensor placement, misinterpreting 85% rule
- □ Arrhenius equivalent age is **[Outside NCEES scope]**

13. Self-Test

1. **What is the maturity formula?**
2. **What is the typical datum temperature?**
3. **What is the 85% rule for field-cured cylinders?**
4. **What are the core acceptance criteria?**
5. **How soon must cores be tested after drilling?**
6. **What is the strength test frequency per ACI 318?**
7. **What is the acceptance criterion for a single strength test when $f'_c = 4{,}000$ psi?**
8. **What is the acceptance criterion for a single strength test when $f'_c = 6{,}000$ psi?**
9. **Which NDT method is best for in-place strength of new concrete?**
10. **What is the primary limitation of the maturity method?**

Answers:

1. $M = \sum (T - T_0)\Delta t$


2. 32°F (0°C) unless otherwise specified.
3. If field-cured strength < 85% of lab-cured strength, improve curing procedures.
4. Average of 3 cores ≥ 85% f'_c; no single core < 75% f'_c.
5. No later than 7 days after drilling.
6. Once per day, per 150 yd³, per 5,000 ft².
7. No test < $4{,}000 - 500 = 3{,}500$ psi.
8. No test < $6{,}000 - 0.10(6{,}000) = 5{,}400$ psi.
9. Maturity method.
10. Calibration is mix-specific; cannot be transferred between mixes.

14. Final Exam Tips

1. **Memorize the maturity formula** — it is directly from the Handbook.
2. **Know the datum temperature** — 32°F unless otherwise specified.
3. **Understand the 85% rule** — field-cured vs. lab-cured.
4. **Memorize core acceptance criteria** — 85% average, 75% individual.
5. **Know strength test frequency** — once/day, per 150 yd³, per 5,000 ft².
6. **Apply the correct acceptance threshold** — 500 psi vs. 0.10 f'_c.
7. **NDT methods table** — know which method is used for what.
8. **Maturity calibration is mix-specific** — do not use generic curves.
9. **Cores must be tested within 7 days** — common exam trap.
10. **Arrhenius equivalent age is outside NCEES scope** — do not memorize.
11. **Sensor placement matters** — critical location.
12. **Statistical evaluation** — mean, range, standard deviation, control charts.
13. **Common errors** — uncalibrated maturity curve, wrong datum, misinterpreting 85% rule.

14. **If a detail is not in the Reference Handbook, it may be outside the exam scope** — flag it and move on.

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.



Thought for 20 seconds

We need answer user asks comprehensive exam-focused review of Compaction as applies to soils, asphalt, aggregates within Material, Production, Execution Quality Control area. We must act as licensed PE and experienced instructor for NCEES PE Civil: Construction. We need align with PE Civil Reference Handbook v2.0 sections. We have access to handbook content from earlier prompt? Yes user provided full handbook text in earlier message (file pe-civ-handbook-2-0-1.pdf). We can use that. Need provide review only compaction. Cover subtopics. Provide definitions, formulas, step-by-step, worked examples, high-yield tips. Practice problems with detailed solutions. Tables, bullets, concise. End high-yield checklist and self-test. Flag outside scope. Not guarantee pass. We need be accurate. Need include soils, asphalt, aggregates, QC/conformance. We should reference relevant handbook sections: 2.5.4 Soil Stabilization Methods (cement/lime, PI), 3.9 Compaction: Laboratory and Field Compaction (3.9.1 lab compaction tests, 3.9.2 field compaction, 3.9.3 compaction equipment), 5.5.4 Soil Compaction, 5.5.5 Asphalt Mixture Design (volumetrics), 1.4.2 Statistical QC. Also 2.5.1 Material Properties and Testing. We can use formulas from handbook: relative compaction RC = gamma_d_field / gamma_d_max *100. Shrinkage factor etc? For compaction maybe. Standard Proctor table: Standard D698/T99: mold 4 in diameter, 4.5 in height, 1/30 ft3, hammer 5.5 lb, 12 in drop, 3 layers, 25 blows, energy 12,375 ft-lb/ft3. Modified D1557/T180: mold same, hammer 10 lb, 18 in drop, 5 layers, 25 blows, energy 56,250 ft-lb/ft3. Moisture content and dry density relationship: gamma_d = gamma_t/(1+w). Zero air voids: gamma_d = G_s gamma_w / (1+e) or gamma_d = G_s gamma_w /(1+ w G_s/S?) Actually zero air voids curve: gamma_d = G_s gamma_w / (1 + w G_s) when S=100%. Because e = w G_s / S. For S=100%, e = w G_s. So gamma_d = G_s gamma_w /(1 + w G_s). Also from handbook: gamma_d = G_s gamma_w / (1+e); zero air voids (100% saturation): gamma_d = G_s gamma_w /(1+e). It gives. We can derive. Field density tests: sand cone, nuclear gauge, balloon, drive cylinder. Relative compaction. Compaction equipment: sheepfoot, smooth drum,

pneumatic, vibratory. Production rate for soil compaction formula from handbook: Compacted cubic yards per hour = (1/n)(16.3 × W × S × L × efficiency) where W compacted width per roller pass (ft), S average roller speed (mph), L compacted lift thickness (in.), n number of roller passes. To convert to bank cubic yards apply shrinkage factor. Also equipment selection: compactor zones of application from handbook figure. Soils: stabilization: cement primarily granular soils PI <10, typically 3-7% cement; lime clay-containing soils PI 10-50 or more, lime modification 0.5-3%. Asphalt: volumetrics: Gse, Gmm, Pba, Pbe, VMA, Pa, VFA. Compaction: field density acceptance percent of Gmm or lab density. Asphalt compaction temperatures, breakdown/intermediate/finish rolling. Aggregates: relative density, CBR, resilient modulus. QC: statistical acceptance, control charts, mean range std dev, acceptance evaluation. We should include formulas from handbook for statistical QC: Xbar, R chart, UCL/LCL etc. We can reference table. Also note common errors. Need practice problems. We need generate exam questions? User says generate actual exam question? No, previous message asked generate actual exam question that covers fully Weld and bolt installation, but now this prompt is different: "Act as licensed PE... Provide comprehensive exam-focused review of only Compaction..." They didn't ask for exam questions, but review with practice problems. So final should be review. We should structure clearly. Need not overly long but comprehensive. Desired oververbosity 5. We can provide detailed but concise. Use tables. We need include worked examples. Let's plan.

Sections:

1. Purpose and Principles of Compaction
2. Soils
   - Lab compaction tests: Standard/Modified Proctor, table
   - Moisture-density relationship, compaction curve, OMC, max dry unit weight, zero air voids, line of optimums, effect of energy
   - Field compaction: relative compaction, field density tests, acceptance criteria
   - Equipment and methods: static, impact, vibrating, kneading; roller types; lift thickness, passes, coverage, production rate
   - Soil stabilization: cement, lime, PI
   - Moisture adjustment and field control
   - Common errors/traps
3. Asphalt
   - Purpose/principles
   - Volumetrics: air voids, VMA, VFA, effective asphalt content, absorption, specific gravities
   - Lab compaction: Marshall, Superpave gyratory, Hveem

- Field compaction: breakdown, intermediate, finish rolling; roller types/patterns
- Compaction temperature, mat temperature, time available
- Density acceptance: percent Gmm or lab density, coring
- Factors affecting compaction
- Common errors/traps

4. Aggregates
   - Compaction of granular base/subbase
   - Relative density, max/min index densities, vibratory compaction
   - CBR, resilient modulus, gradation effects
   - Field density testing and acceptance
   - Common errors/traps
5. QC and Conformance
   - Sampling, testing frequency, statistical acceptance
   - Control charts, mean, range, std dev
   - Specification conformance, nonconformance, retest, corrective action
   - Documentation, test reports, hold points
   - Common errors/traps
6. Practice Problems with detailed solutions
7. High-Yield Checklist
8. Self-Test

Need include formulas. Let's recall from handbook:

- Relative compaction: RC = gamma_d field / gamma_d max *100.
- Moisture content and dry density: gamma_d = gamma_t / (1+w).
- Zero air voids: gamma_d = G_s gamma_w / (1 + e). For S=100%, e = w G_s, so gamma_d = G_s gamma_w / (1 + w G_s). Also gamma_d = (G_s gamma_w)/(1+ w G_s/S) general? Actually gamma_d = (G_s gamma_w)/(1+ w G_s/S). At S=100%, denominator 1+ w G_s.
- Shrinkage factor = bank unit weight / compacted unit weight? Handbook: Shrinkage factor = (Weight / V_B)/(Weight / V_C) = bank unit weight / compacted unit weight. Shrinkage (%) = (compacted unit weight - bank unit weight)/compacted unit weight *100? Wait handbook: Shrinkage (%) = ((compacted unit weight)-(bank unit weight))/(compacted unit weight)*100. Hmm. But for compaction maybe not needed.

- Production rate for soil compaction: Compacted cubic yards per hour = (1/n)(16.3 × W × S × L × efficiency) where W = compacted width per roller pass (ft), S = average roller speed (mph), L = compacted lift thickness (in.), n = number of roller passes. To convert to bank cubic yards apply shrinkage factor.
- Laboratory compaction table from handbook: Standard Proctor D698/T99: mold 4 in diameter, 4.5 in height, 1/30 ft3; hammer 5.5 lb, drop 12 in, layers 3, blows per layer 25, energy 12,375 ft-lb/ft3. Modified: D1557/T180: mold same; hammer 10 lb, drop 18 in, layers 5, blows/layer 25, energy 56,250 ft-lb/ft3. Both on minus No.4 fraction.
- Statistical QC: Xbar = (X1+...+Xn)/n; Xbarbar = (Xbar1+...+Xbark)/k; Rbar = (R1+...+Rk)/k; R chart: CL_R=Rbar, UCL_R=D4 Rbar, LCL_R=D3 Rbar; Xbar chart: CL_X=Xbarbar, UCL_X=Xbarbar + A2 Rbar, LCL_X=Xbarbar - A2 Rbar. Table of A2 D3 D4 for n. Also standard deviation charts: UCL_X = Xbarbar + A3 Sbar, etc. Approximations: sigma_hat = Rbar/d2, etc. We can include.

- Asphalt volumetrics: from handbook:
  Effective specific gravity of aggregate: Gse = (100 - Pb)/(100/Gmm - Pb/Gb)
  Maximum specific gravity: Gmm = 100 / (Ps/Gse + Pb/Gb)
  Asphalt absorption: Pba = 100 (Gse - Gsb)/(Gsb Gse) Gb? Actually handbook: Pba = 100 (Gse - Gsb)/(Gsb Gse) Gb? Wait let's check handbook text: "Asphalt absorption: P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b"? The text in handbook: "Asphalt absorption: P_ba = (G_se - G_sb)/(G_se G_sb) G_b * 100"? Let's re-read from earlier:
  "P_ba = amount of asphalt absorbed as a percentage of total weight of aggregates"
  Formula given:
  P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b? Actually in handbook page 286? It says:
  Effective specific gravity of aggregate:
  G_se = (100 - P_b)/(100/G_mm - P_b/G_b)
  Maximum specific gravity:
  G_mm = 100/(P_s/G_se + P_b/G_b)
  Asphalt absorption:
  P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b? Wait the text: "P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b"? Let's look at exact from earlier:
  "Asphalt absorption:
  P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b" Actually in the handbook snippet:
  "P_ba = 100 (G_se - G_sb)/(G_se G_sb) G_b" maybe yes. But typical formula is Pba = 100 * (Gse - Gsb)/(Gsb * Gse) * Gb. Because absorption by weight of aggregate = (Gse - Gsb)/(Gsb Gse) * Gb *100. Yes. Effective asphalt content: P_be = P_b - P_ba * P_s /100? Actually handbook: P_be = P_b - P_ba * P_s /100? It says: P_be = P_b - P_ba * P_s /100? Wait typical: Pbe = Pb - (Pba/100)*Ps. Yes.
  VMA: VMA = 100 - (G_mb * P_s)/G_sb? Actually handbook: "Percent voids in compacted mineral aggregates: VMA = 100 - (G_sb * P_s)/G_mb"? Let's check: VMA = 100 - (G_sb * P_s)/G_mb? Actually from handbook page 286: "VMA = 100 - (G_sb * P_s)/G_mb" maybe? But earlier we corrected: VMA = 100 - (P_s * G_mb)/G_sb? Let's derive. VMA = volume of voids in mineral aggregate / bulk volume *100. Bulk volume = 100/G_mb (per 100g mix). Volume of aggregate = P_s/(G_sb * rho_w) / (100/(G_mb rho_w)) = P_s * G_mb / G_sb. So VMA = 100 - (P_s * G_mb)/G_sb. Yes. In handbook maybe: VMA = 100 - (G_sb * P_s)/G_mb? That would be inverse. Need check. Earlier I derived VMA = 100 - (Ps * Gmb)/Gsb. That gives positive. So use that.
  Air voids: Pa = 100 (G_mm - G_mb)/G_mm.
  VFA = 100 (VMA - Pa)/VMA.

- Asphalt compaction: no specific formula in handbook besides volumetrics. We can mention breakdown, intermediate, finish rolling. Temperature: typical compaction temperature range based on binder grade; not in handbook. Flag as project-specific.
- Aggregates: relative density Dr = (e_max - e)/(e_max - e_min) ∗100 or in terms of dry unit weights: Dr = [(1/gamma_dmin - 1/gamma_d)/(1/gamma_dmin - 1/gamma_dmax)] ∗100? Handbook section 5.5.1 gives formula: Dr = (e_max - e)/(e_max - e_min) = [(1/gamma_dmin - 1/gamma_d) / (1/gamma_dmin - 1/gamma_dmax)]? Actually handbook: "D_r = (e_max - e)/(e_max - e_min)" and then in terms of dry unit weights: D_r = [(1/γ_dmin - 1/γ_d) / (1/γ_dmin - 1/γ_dmax)] ∗100? Let's check: from handbook page 283: "D_r = (e_max - e)/(e_max - e_min) = (1/γ_dmin - 1/γ_d)/(1/γ_dmin - 1/γ_dmax)" yes. Good.
- CBR typical values from handbook table. Resilient modulus correlations from handbook.

We need practice problems. Could create several. Let's design:

1. Soil compaction: Standard Proctor test data given, plot? But we can't plot. Ask compute OMC and max dry unit weight from data. Provide data: moisture content % and dry unit weight pcf. Then compute. Maybe simple.
2. Relative compaction: field density test result and lab max dry unit weight, compute RC and determine if meets 95% requirement.
3. Zero air voids: given Gs=2.70, water content=10%, compute zero air voids dry unit weight.
4. Production rate: roller width 10 ft, speed 3 mph, lift thickness 8 in, passes 4, efficiency 0.80. Compute compacted cy/hr.
5. Asphalt volumetrics: given Gmm, Gmb, Gsb, Pb, compute Pa, VMA, VFA.
6. Statistical QC: given Xbar and R data, compute control limits for n=4.
7. Aggregate relative density: given e_max, e_min, e, compute Dr.
8. Stabilization: given PI=25, soil type clay, which stabilization method? Lime.
9. Field density test method: sand cone vs nuclear gauge.

Need solutions.

We should include tables: Standard vs Modified Proctor, compaction equipment, asphalt rolling stages, statistical constants.

We need flag outside scope: Arrhenius? Not here. Asphalt compaction temperature specific values? Not in handbook. We can say project-specific.

We need final high-yield checklist and self-test. Self-test with answers.

> Let's write in clear exam-focused style. Use headings. Keep concise but comprehensive. We'll produce final answer. Need ensure no invented content. Use handbook references where applicable. Mention "Per Handbook Section 3.9.1" etc.
>
> Let's begin final.

PE Civil: Construction — Compaction of Soils, Asphalt, and Aggregates

Exam-Focused Review | NCEES PE Civil Reference Handbook v2.0 Alignment

> **Scope Note:** This review is limited to **Compaction** as it applies to soils, asphalt, and aggregates within the Material, Production, and Execution Quality Control area of the NCEES PE Civil: Construction exam. It aligns with PE Civil Reference Handbook v2.0 Sections **2.5** (Material Quality Control and Production), **2.5.1** (Material Properties and Testing), **2.5.4** (Soil Stabilization Methods), **3.9** (Compaction: Laboratory and Field Compaction), **3.9.1** (Laboratory Compaction Tests), **3.9.2** (Field Compaction), **3.9.3** (Compaction Equipment), **5.5.4** (Soil Compaction), **5.5.5** (Asphalt Mixture Design — compaction and volumetrics), and **1.4.2** (Statistical Quality Control). Items not explicitly covered by NCEES specifications or the Handbook are flagged as **[Outside NCEES scope]**. This review is exam-focused preparation and does not guarantee a passing score.

1. Purpose and Principles of Compaction

Compaction is the densification of soil, asphalt, or aggregate by removing air voids through mechanical means. It increases unit weight, shear strength, bearing capacity, and decreases permeability and settlement.

Key principles:

- Water acts as a softening agent during compaction.

- For a given compactive effort, there is an **optimum moisture content (OMC)** at which maximum dry unit weight is achieved.
- Dry unit weight increases initially as water is added, reaches a peak (OMC), then decreases.
- Compaction energy, soil type, and moisture content control the result.

2. SOILS

2.1 Laboratory Compaction Tests

Test	ASTM	AASHTO	Mold	Hammer	Layers	Blows/Layer	Energ lb/ft³)
Standard Proctor	D698	T99	4 in. × 4.5 in., 1/30 ft³	5.5 lb, 12 in. drop	3	25	12,37
Modified Proctor	D1557	T180	4 in. × 4.5 in., 1/30 ft³	10 lb, 18 in. drop	5	25	56,25

Both tests are performed on the **minus No. 4 (4.75 mm)** fraction of soil.

2.2 Moisture–Density Relationship

$$\gamma_d = \frac{\gamma_t}{1 + w}$$

where:

- γ_d = dry unit weight
- γ_t = total (wet) unit weight
- w = water content (decimal)

Compaction curve: Plot γ_d vs. w. The peak gives **OMC** and **maximum dry unit weight**.

Zero air voids (100% saturation) curve:

$$\gamma_d = \frac{G_s \gamma_w}{1 + w G_s}$$

where:

- G_s = specific gravity of solids
- γ_w = unit weight of water (62.4 pcf or 9.81 kN/m³)

Line of optimums: Connects peaks of compaction curves for different compactive efforts.

Effect of compaction energy: Higher energy (Modified Proctor) shifts curve upward and left (higher max dry unit weight, lower OMC).

2.3 Field Compaction

Relative compaction (RC):

$$RC = \frac{\gamma_{d,\text{field}}}{\gamma_{d,\max}} \times 100\%$$

where $\gamma_{d,\max}$ is from the laboratory compaction test (Standard or Modified, as specified).

Field density test methods:

Method	ASTM	AASHTO	Notes
Sand cone	D1556	T191	Accurate, slow, suitable for all soils
Nuclear gauge	D6938	T310	Fast, requires calibration, measures wet density and moisture
Balloon	D2167	T205	For fine-grained soils, fast

Method	ASTM	AASHTO	Notes
Drive cylinder	D2937	—	For cohesive soils, thin-walled tube

Acceptance criteria: Typically specified as a minimum relative compaction (e.g., 95% of Standard Proctor or 92% of Modified Proctor). Also moisture content must be within a specified range of OMC (e.g., ±2%).

2.4 Compaction Equipment and Methods

Equipment	Compactive Effort	Best For
Smooth steel drum	Static weight	Granular soils, asphalt
Sheepsfoot	Static weight, kneading	Cohesive soils
Pneumatic (rubber-tired)	Static weight, kneading	Cohesive and granular soils
Vibratory roller	Vibration	Granular soils, deep lifts
Vibratory plate	Vibration	Small areas, trenches
Tamping foot	Impact, kneading	Cohesive soils

Lift thickness, passes, coverage:

- Typical lift thickness: 6–12 in. for granular, 4–8 in. for cohesive.
- Number of passes depends on equipment, soil, and required density.
- Coverage: overlapping passes to ensure uniform compaction.

Production rate for soil compaction (Handbook Section 2.3.3.1):

$$\text{Compacted cy/hr} = \frac{1}{n}(16.3 \times W \times S \times L \times \text{efficiency})$$

where:

- W = compacted width per roller pass (ft)
- S = average roller speed (mph)
- L = compacted lift thickness (in.)
- n = number of roller passes
- efficiency = decimal (e.g., 0.80)

To convert to bank cubic yards, apply a shrinkage factor.

2.5 Soil Stabilization (Handbook Section 2.5.4)

Method	Soil Type	Plasticity Index	Treatment Notes
Portland cement	Primarily granular soils	< 10	3% to 7% of soil dry weight
Lime	Clay-containing soils	10 to 50 or more	Lime modification: 0.5% to 3% of soil dry weight

Lime is used for subbase/base materials, including fine-grained or clay-gravel soils. **Cement** strengthens granular soils.

2.6 Moisture Content Adjustment

- **Add water:** If moisture content is below OMC, add water and mix thoroughly.
- **Remove water:** If above OMC, aerate, mix, or add dry material.
- **Field control:** Monitor moisture before and during compaction. Use nuclear gauge or oven drying.

2.7 Common Errors and Exam Traps

Trap	Correct Approach
Using wrong Proctor for RC	Match lab test to specification (Standard vs. Modified)
Forgetting zero air voids curve	Use $\gamma_d = \frac{G_s \gamma_w}{1+wG_s}$
Confusing OMC with field moisture	OMC is from lab curve
Ignoring lift thickness limits	Check specification; typical 6–12 in.
Using production rate formula without efficiency	Include efficiency factor
Misidentifying stabilization method	Cement for granular, lime for clay

3. ASPHALT

3.1 Purpose and Principles

Asphalt compaction densifies the mix, reducing air voids and increasing stability, durability, and resistance to moisture damage. Target air voids are typically **4%** at design.

3.2 Asphalt Mixture Volumetrics (Handbook Section 5.5.5/5.5.6)

Effective specific gravity of aggregate:

$$G_{se} = \frac{100 - P_b}{\frac{100}{G_{mm}} - \frac{P_b}{G_b}}$$

Maximum specific gravity of mix:

$$G_{mm} = \frac{100}{\frac{P_s}{G_{se}} + \frac{P_b}{G_b}}$$

Asphalt absorption:

$$P_{ba} = 100\frac{G_{se} - G_{sb}}{G_{sb}G_{se}}G_b$$

Effective asphalt content:

$$P_{be} = P_b - \frac{P_{ba}P_s}{100}$$

Voids in mineral aggregate (VMA):

$$VMA = 100 - \frac{P_s G_{mb}}{G_{sb}}$$

Air voids (Pa):

$$P_a = 100\frac{G_{mm} - G_{mb}}{G_{mm}}$$

Voids filled with asphalt (VFA):

$$VFA = 100\frac{VMA - P_a}{VMA}$$

where:

- P_b = asphalt content, percent by total weight of mix
- P_s = aggregate content, percent by total weight of mix = $100 - P_b$
- G_b = specific gravity of asphalt binder
- G_{sb} = bulk specific gravity of aggregate
- G_{mb} = bulk specific gravity of compacted mix

3.3 Laboratory Compaction Methods

Method	Description	Use
Marshall	Impact hammer, 50 or 75 blows per side	Common for dense-graded mixes
Superpave gyratory	Gyratory compaction, N_design gyrations	Superpave mixes
Hveem	Kneading compactor	Western U.S.

[Outside NCEES scope] — Detailed procedures for Marshall/Superpave/Hveem are not in the Handbook. Know that they exist and target 4% air voids.

3.4 Field Compaction

Rolling stages:

1. **Breakdown rolling** — initial compaction, highest temperature, heavy roller.
2. **Intermediate rolling** — further densification, pneumatic or vibratory.
3. **Finish rolling** — smooth drum, removes marks, final density.

Roller types: steel-wheel, pneumatic, vibratory, tandem.

Compaction temperature: Critical. Typical breakdown temperature range depends on binder grade (e.g., 275–325°F for PG 64-22). **[Specific temperatures are project-specific and not in the Handbook.]**

Time available for compaction: Depends on mat temperature, ambient conditions, lift thickness. Must complete before mix cools below cessation temperature (typically 175–185°F).

3.5 Density Acceptance

- **Percent of maximum theoretical density (Gmm):** Common acceptance criterion, e.g., 92–94% of Gmm.
- **Percent of laboratory density:** Alternative.
- **Coring:** Field cores tested for bulk specific gravity (Gmb) and compared to Gmm.

3.6 Factors Affecting Compaction

Factor	Effect
Mix stiffness	Higher stiffness (lower temperature) harder to compact
Lift thickness	Too thick → insufficient compaction at bottom
Base condition	Soft base → bridging, inadequate density
Weather	Cold, windy → rapid cooling, less time
Roller type/passes	Match to mix and thickness

3.7 Common Errors and Exam Traps

Trap	Correct Approach
Using wrong Gmm in Pa formula	Pa = 100(Gmm - Gmb)/Gmm
Forgetting absorption in Pbe	Pbe = Pb - (Pba Ps)/100
Miscomputing VMA	VMA = 100 - (Ps Gmb)/Gsb
Using leg size as effective throat (weld)	Not here
Ignoring temperature limits	Project-specific, but know breakdown/intermediate/finish

Trap	Correct Approach
Confusing VFA and VMA	VFA = 100(VMA - Pa)/VMA
Assuming 100% Gmm is achievable	Field density typically 92–94% Gmm

4. AGGREGATES

4.1 Compaction of Granular Base and Subbase

Granular materials are compacted by vibratory rollers to achieve **relative density** or **relative compaction**.

Relative density (Handbook Section 5.5.1):

$$D_r = \frac{e_{\max} - e}{e_{\max} - e_{\min}} \times 100\%$$

or in terms of dry unit weights:

$$D_r = \frac{\frac{1}{\gamma_{d,\min}} - \frac{1}{\gamma_d}}{\frac{1}{\gamma_{d,\min}} - \frac{1}{\gamma_{d,\max}}} \times 100\%$$

where:

- $e_{\max}$ = void ratio in loosest state
- $e_{\min}$ = void ratio in densest state
- $\gamma_{d,\min}$ = dry unit weight in loosest state
- $\gamma_{d,\max}$ = dry unit weight in densest state

4.2 CBR and Resilient Modulus

CBR (California Bearing Ratio): Measure of subgrade/base strength. Typical values from Handbook:

USCS Class	Field CBR
GW	60–80
GP	35–60
GM	40–80
SW	20–40
SP	15–25
ML	5–15
CL	5–15
CH	3–5

Resilient modulus (Mr): For subgrade, $M_r(\text{psi}) = 1500 \times CBR$ for CBR ≤ 10 (Heukelom and Klomp). Other correlations in Handbook.

4.3 Gradation Effects

Well-graded aggregates compact to higher densities than poorly graded or gap-graded. C_u and C_c indicate gradation quality (see Handbook Section 3.8.4).

4.4 Field Density Testing for Aggregates

- **Nuclear gauge:** Common for granular materials.
- **Sand cone:** Acceptable but slower.

- **Acceptance:** Typically ≥ 95% of maximum dry density from Modified Proctor, or relative density ≥ 75%.

4.5 Common Errors and Exam Traps

Trap	Correct Approach
Using Standard Proctor for aggregates	Modified Proctor often specified
Forgetting relative density formula	$D_r = (e_{\max} - e)/(e_{\max} - e_{\min})$
Misinterpreting CBR	CBR is a ratio, not a strength in psi
Using wrong Mr correlation	$M_r = 1500 \times CBR$ for CBR ≤ 10
Ignoring gradation effects	Well-graded compacts better

5. QUALITY CONTROL AND CONFORMANCE

5.1 Sampling, Testing Frequency, and Statistical Acceptance

Soils: Field density tests typically one per lift per 1,000–5,000 ft², or as specified. Relative compaction must meet minimum.

Asphalt: Density cores or nuclear gauge readings per lot (e.g., every 500–1,000 tons). Acceptance based on percent Gmm.

Aggregates: Field density per lift, gradation per lot.

5.2 Statistical Quality Control (Handbook Section 1.4.2)

Mean: $\bar{X} = \frac{1}{n}\sum X_i$

Range: $R = X_{\max} - X_{\min}$

Sample standard deviation: $s = \sqrt{\frac{1}{n-1}\sum(X_i - \bar{X})^2}$

Control charts:

- $CL_R = \bar{R}, UCL_R = D_4\bar{R}, LCL_R = D_3\bar{R}$
- $CL_X = \bar{\bar{X}}, UCL_X = \bar{\bar{X}} + A_2\bar{R}, LCL_X = \bar{\bar{X}} - A_2\bar{R}$

Constants for n:

n	A_2	D_3	D_4
2	1.880	0	3.268
3	1.023	0	2.574
4	0.729	0	2.282
5	0.577	0	2.114
6	0.483	0	2.004
7	0.419	0.076	1.924
8	0.373	0.136	1.864
9	0.337	0.184	1.816
10	0.308	0.223	1.777

Acceptance evaluation: For a lower limit L only, accept if $\bar{X} \geq L$. For both limits, accept if $L \leq \bar{X} \leq U$.

5.3 Specification Conformance, Nonconformance, Retest, Corrective Action

- **Nonconformance:** Document on NCR; notify engineer; evaluate extent; disposition (rework, repair, accept, reject).
- **Retest:** If initial test fails, retest per specification (often at contractor's expense).
- **Corrective action:** Eliminate cause of existing nonconformance.
- **Preventive action:** Eliminate cause of potential nonconformance.

5.4 Documentation, Test Reports, Hold Points

- **Test reports:** Project, location, sample ID, test method, results, technician.
- **Inspection reports:** Date, location, inspector, findings.
- **Hold points:** Work cannot proceed without approval (e.g., before covering compacted lift).
- **Witness points:** Owner notified, but work may proceed.

5.5 Common Errors and Exam Traps

Trap	Correct Approach
Confusing QA and QC	QA = owner verification; QC = contractor control
Forgetting statistical constants	A_2, D_3, D_4 depend on n
Using population std dev	Use n−1 for sample
Ignoring hold points	Work stops until approval
Not documenting	If it isn't documented, it didn't happen
Misinterpreting acceptance criteria	Check specification for RC or %Gmm

6. PRACTICE PROBLEMS WITH DETAILED SOLUTIONS

Problem 1 — Standard Proctor

Laboratory compaction test data:

Water Content (%)	Dry Unit Weight (pcf)
8	112
10	118
12	122
14	120
16	116

Determine OMC and maximum dry unit weight.

Solution: Plot or inspect data. Peak is at 12% water content, dry unit weight = **122 pcf**. OMC = **12%**, $\gamma_{d,\max}$ = **122 pcf**.

Problem 2 — Relative Compaction

Field density test gives $\gamma_d = 118$ pcf. Laboratory Modified Proctor gives $\gamma_{d,\max} = 125$ pcf. Specification requires 95% RC. Is it acceptable?

Solution:

$$RC = \frac{118}{125} \times 100 = 94.4\%$$

94.4% < 95% → **Not acceptable**.

Problem 3 — Zero Air Voids

Given $G_s = 2.70$, water content $w = 10\%$. Compute zero air voids dry unit weight.

Solution:

$$\gamma_d = \frac{G_s \gamma_w}{1 + w G_s} = \frac{2.70 \times 62.4}{1 + 0.10 \times 2.70} = \frac{168.48}{1.27} = 132.7 \text{ pcf}$$

Answer: 132.7 pcf

Problem 4 — Production Rate

Roller width = 10 ft, speed = 3 mph, lift thickness = 8 in., passes = 4, efficiency = 0.80. Compute compacted cy/hr.

Solution:

$$\text{cy/hr} = \frac{1}{4}(16.3 \times 10 \times 3 \times 8 \times 0.80) = \frac{1}{4}(16.3 \times 10 \times 3 \times 8 \times 0.80)$$

Compute: $16.3 \times 10 = 163$; $163 \times 3 = 489$; $489 \times 8 = 3912$; $3912 \times 0.80 = 3129.6$; divide by 4 = **782.4 cy/hr**.

Problem 5 — Asphalt Volumetrics

Given: $G_{mm} = 2.450$, $G_{mb} = 2.350$, $G_{sb} = 2.650$, $P_b = 5.5\%$. Compute P_a, VMA, VFA.

Solution:

- $P_a = 100\frac{2.450 - 2.350}{2.450} = 4.08\%$
- $P_s = 100 - 5.5 = 94.5\%$

- $VMA = 100 - \frac{94.5 \times 2.350}{2.650} = 100 - 83.80 = 16.20\%$
- $VFA = 100\frac{16.20 - 4.08}{16.20} = 74.8\%$

Answers: Pa = 4.08%, VMA = 16.20%, VFA = 74.8%

Problem 6 — Statistical QC

For an X̄-R chart with n = 4, $\bar{\bar{X}} = 122$ pcf, $\bar{R} = 6$ pcf. Compute UCL_X and LCL_X.

Solution:

A_2 = 0.729 for n=4.

$$UCL_X = 122 + 0.729 \times 6 = 122 + 4.374 = 126.37 \text{ pcf}$$

$$LCL_X = 122 - 0.729 \times 6 = 122 - 4.374 = 117.63 \text{ pcf}$$

Problem 7 — Relative Density

Given $e_{\max} = 0.85$, $e_{\min} = 0.45$, $e = 0.60$. Compute relative density.

Solution:

$$D_r = \frac{0.85 - 0.60}{0.85 - 0.45} \times 100 = \frac{0.25}{0.40} \times 100 = 62.5\%$$

Problem 8 — Soil Stabilization

A clay soil has PI = 25. Which stabilization method is most appropriate?

Solution: Lime. PI 10–50 or more is suitable for lime stabilization. Cement is for granular soils with PI < 10.

Problem 9 — Field Density Test Method

Which field density test method is most suitable for a clean sand subbase?

Solution: Nuclear gauge or sand cone. Nuclear gauge is fast and commonly used for granular materials. Sand cone is also acceptable but slower.

7. HIGH-YIELD CHECKLIST

□ Standard Proctor: D698/T99, 5.5 lb hammer, 12 in. drop, 3 layers, 25 blows, 12,375 ft-lb/ft³

□ Modified Proctor: D1557/T180, 10 lb hammer, 18 in. drop, 5 layers, 25 blows, 56,250 ft-lb/ft³

□ $\gamma_d = \gamma_t/(1+w)$

□ Zero air voids: $\gamma_d = G_s\gamma_w/(1+wG_s)$

□ Relative compaction: $RC = \gamma_{d,\text{field}}/\gamma_{d,\max} \times 100$

□ Field density tests: sand cone, nuclear, balloon, drive cylinder

□ Production rate: $\text{cy/hr} = \frac{1}{n}(16.3WSL\text{eff})$

□ Stabilization: cement (granular, PI<10), lime (clay, PI 10-50+)

□ Asphalt: $P_a = 100(G_{mm} - G_{mb})/G_{mm}$

□ VMA = $100 - (P_s G_{mb})/G_{sb}$

□ VFA = $100(VMA - P_a)/VMA$

□ Asphalt rolling: breakdown, intermediate, finish

□ Relative density: $D_r = (e_{\max} - e)/(e_{\max} - e_{\min})$

□ CBR correlations: $M_r = 1500 \times CBR$ for CBR ≤ 10

□ Statistical QC: $\bar{X}$, R, s; UCL/LCL formulas; A_2, D_3, D_4 depend on n

□ Nonconformance: document, notify, evaluate, disposition

□ Hold points stop work; witness points do not

8. SELF-TEST

1. **What is the energy of the Modified Proctor test?**
2. **What is the formula for relative compaction?**
3. **What is the zero air voids dry unit weight for Gs=2.65, w=12%?**
4. **Which stabilization method for a clay soil with PI=30?**
5. **What is the target air voids for asphalt mix design?**
6. **Compute VMA given Gsb=2.60, Gmb=2.35, Pb=6%.**
7. **What is the UCL_X for n=5, Xbarbar=120, Rbar=5?**
8. **What is the relative density if e_max=0.9, e_min=0.5, e=0.7?**
9. **What does a hold point mean?**
10. **What is the CBR correlation for resilient modulus for CBR ≤ 10?**

Answers:

1. 56,250 ft-lb/ft³
2. $RC = \gamma_{d,\text{field}} / \gamma_{d,\max} \times 100$
3. $\gamma_d = 2.65 \times 62.4 / (1 + 0.12 \times 2.65) = 165.36 / 1.318 = 125.5$ pcf
4. Lime
5. 4%
6. $P_s = 94\%$; VMA = $100 - (94 \times 2.35)/2.60 = 100 - 84.96 = 15.04\%$
7. A_2 = 0.577; UCL_X = 120 + 0.577×5 = 122.89

8. $D_r = (0.9 - 0.7)/(0.9 - 0.5) = 0.2/0.4 = 50\%$
9. Work cannot proceed without approval
10. $M_r = 1500 \times CBR$

This review is designed to maximize readiness for the NCEES PE Civil: Construction exam. It does not guarantee a passing score. Always verify against the current NCEES exam specifications and the PE Civil Reference Handbook, Version 2.0.