NovaFiber GX400 — Quick Start Guide

Overview

The NovaFiber GX400 is a carrier-grade XGS-PON fiber gateway designed for zero-touch field deployment. Most installs require no on-site configuration.

What's in the Box

- NovaFiber GX400 unit
- Fiber patch cord (SC/APC)
- Power adapter
- Quick Start card with QR code

Provisioning

The GX400 auto-provisions on power-up:

- **TR-069 (CWMP)**: The unit calls home to the carrier ACS automatically once fiber and power are connected. All WAN, VoIP, and Wi-Fi profiles are pushed remotely — no technician configuration required.
- **DHCP**: LAN-side clients receive addresses automatically from the gateway's built-in DHCP server.
- **QR / Mobile App**: Installers (or end customers) may scan the QR code printed on the unit's label with the NovaFiber Connect app to confirm activation status and run a guided self-install flow.
- **Web GUI**: An advanced local web interface is available at 192.168.10.1 for technicians who need to override auto-provisioned settings, but it is not required for a standard install.

No console port is present on this model; there is no local CLI access.

Required Tools

No additional tools are required for a standard install. A smartphone camera is used to scan the setup QR code.

Key Features

- Wi-Fi 6 (802.11ax) tri-band with mesh support
- Built-in ONT — no separate ONT box needed
- USB 3.0 port for external storage or printer sharing
- Automatic firmware updates with zero-touch rollback

Specifications

- Wi-Fi Standard: 802.11ax (Wi-Fi 6), tri-band
- WAN Speed: Up to 2.5 Gbps (XGS-PON)
- Form Factor: Compact desktop, wall-mountable

FCC Compliance: This device complies with Part 15 of the FCC Rules.
© 2026 Example Corp. All Rights Reserved.

Cabling & Ports

Port	Type	Notes
PON	SC/APC fiber	Connects to carrier ONT drop cable
LAN1–LAN4	RJ45 Gigabit Ethernet	Auto-negotiating
Wi-Fi	802.11ax (internal)	No external antenna cabling
Power	DC barrel, 12V	Included adapter only

LED Indicators

LED	Meaning
Power/Status	pulsing green during startup and ACS handshake
Power/Status	solid green once fully online and provisioned
PON	blinking amber 2Hz while acquiring optical signal
PON	solid green once optical link is established
Alert	solid red if optical signal is lost or provisioning fails

Installation Steps

1. Connect the fiber patch cord to the PON port.
2. Connect power.
3. Wait for the Power/Status LED to turn solid green (typically under 3 minutes).
4. Optionally scan the QR code with the NovaFiber Connect app to verify service.

No screwdriver, console cable, or laptop is required for a standard residential or SMB install.

FCC Compliance: This device complies with Part 15 of the FCC Rules.
© 2026 Example Corp. All Rights Reserved.