

NEVER MISS THE ENTRY.

TRADINGVIEW ALERT TO YOUR DESK IN FIVE SECONDS



240 x 240

IPS PANEL

ESP8266

39 KB RAM

5s

ALERT TO SCREEN

0

PORTS OPENED


\$0

TO KEEP RUNNING

TELEGRAM @DrFXGOD · CHANNEL @DrFXAi · TRADINGVIEW RaptorAlgo

THE ALERT FIRED. YOU DIDN'T SEE IT.

It buzzed while your phone was face-down. The tab was behind thirty others. By the time you looked, the candle had already closed.



A SCREEN CANNOT BE MINIMISED.

ALWAYS ON

It sits on the desk doing one job. No lock screen, no app to open, no tab to find.

ALWAYS RIGHT

Symbol, direction, entry, both targets and the stop — the whole trade, not a headline.


ALWAYS THERE

Runs with your computer off. The bridge lives on Cloudflare, not your laptop.

Prices and the clock run whether or not you ever send a signal.

THREE MACHINES. ONE DIRECTION.

TradingView cannot reach a screen on your home network. So nothing tries to.



WHY IT IS BUILT THIS WAY

NOTHING EXPOSED

The screen only ever makes outbound requests. No port forwarding, no dynamic DNS, no inbound hole in your router. Your network stays exactly as it was.

NOTHING LEFT ON

The bridge runs on Cloudflare's free tier, not your PC. Shut the laptop, go out, come back — the screen never stopped.

A CHIP THAT CANNOT

The ESP8266 has ~39 kB of RAM and each secure connection wants 16 kB. It cannot talk to four exchanges. The bridge does that, and sends a few hundred bytes.

WHAT ARRIVES AT THE SCREEN

```
{"v":"2.1.2","src":"coinpaprika","tickers":[{"s":"BTCUSD",  
"d":"BTC","p":"63074.68","c":0.42,  
"k":[27,23,43,39,55,47,33,...,100]}]}
```

PAYLOAD

A few hundred bytes. The sparkline is already scaled 0–100, so the device does no arithmetic at all.

The screen is a small, single-purpose device that can only talk out to the internet.

OUTBOUND ONLY.

NO PORTS OPENED
NO INBOUND ROUTE

THREE SCREENS, ON ROTATION.

Each holds for fifteen seconds. A new signal interrupts and stays put — it is the thing you actually care about.



SIGNAL

Symbol, direction, score ring, targets and stop. On screen about five seconds after the alert fires.

CRYPTO

Up to four pairs. 24-hour change and an hourly sparkline, from whichever source is reachable where you are.

CLOCK

Keeps time even where the network blocks NTP — the bridge supplies it instead. Dims itself at night.

ALSO INCLUDED

- SETTINGS IN A BROWSER
- NO APP REQUIRED
- NIGHT DIMMING
- 52 ZONES, REAL DST
- WI-FI FAILOVER
- OVER-THE-AIR UPDATES
- OPEN SOURCE, MIT
- SELF-DIAGNOSING
- FOUR PAIRS AT ONCE
- NO CLOUD ACCOUNT
- CAROUSEL OR FIXED
- USB-C, 0.6 W

Everything on these three screens is configured from one page in your browser. Nothing is hard-coded.

FOUR READS. ONE VERDICT.

GOD MODE Quad Consensus only speaks when four independent reads of the market agree. Fewer prints, and every one of them arrives on your screen complete — symbol, direction, entry, both targets, the stop.



AVAILABLE ON

TRADINGVIEW

Pine, alert() driven

METATRADER

MT4 / MT5

NOTHING TO TYPE

On TradingView, set the alert to “Any alert() function call”. The script writes the whole message itself.

SCORE AND CONFIDENCE

Every print carries a 0–100 score and a separate confidence figure, both drawn on the card.

YOUR OWN ALERTS TOO

The bridge takes plain JSON or plain text, so any indicator or strategy can drive the screen.

Signals are information, not instructions. Nothing here is financial advice.

TWENTY MINUTES. NO CODING.

Six steps. Each one tells you what you should see when it worked.

01

MAKE YOUR KEYS

16%

Double-click keygen.html. Two random keys appear. It runs offline and sends nothing anywhere.

02

PUT THE BRIDGE ONLINE

33%

Run one script, or paste one file into the Cloudflare dashboard. The free tier is plenty.

03

FLASH THE SCREEN

50%

Download the ready-built file and upload it through the device's own update page.

04

JOIN YOUR WI-FI

66%

The screen makes its own network the first time. Join it, pick your Wi-Fi, save.

05

POINT IT AT THE BRIDGE

83%

Paste the address and one key. Status should read: connected, nothing new.

06

WIRE UP TRADINGVIEW

100%

Paste the webhook address into any alert. Optional — prices work without it.

IF SOMETHING IS WRONG

The screen tells you in plain words, not a code: “no bridge URL saved”, “Wi-Fi not connected”, “no device key saved”. And one command tests every link in the chain and names the broken one:

```
python tools/drfx.py doctor
```

PICK YOUR LANE.

PAY ONCE, OR NEVER.

The device software is open source under MIT — clone it and build it yourself for nothing, forever. These are for people who would rather skip the afternoon and get the indicator that was written for it.

BEST VALUE

PROGRAM FILE	FULL PACKAGE	LIFETIME
\$25 one-time	\$50 one-time	\$181 one-time
Built, tested, ready to flash	Everything, plus a month of GOD Mode	Never pay again, and own the source
■ The compiled firmware, both images ■ Your two keys generated for you ■ Quickstart walkthrough ■ Free updates to the software	■ Everything in Program File ■ 1 month GOD MODE indicator ■ TradingView AND MetaTrader ■ Alerts wired to your screen	■ Lifetime GOD MODE access ■ Full indicator source code ■ Both platforms, all future versions ■ Priority support on Telegram

MESSAGE ME AND START TODAY.

TELEGRAM

@DrFXGOD

CHANNEL

@DrFXAi

TRADINGVIEW

RaptorAlgo

IN EVERY TIER

- ✓ NO SUBSCRIPTION
to keep the screen running
- ✓ NO PC LEFT ON
the bridge lives on Cloudflare
- ✓ OPEN SOURCE CORE
MIT, auditable, yours to keep

DRFX ULTRA OS is a custom operating system designed for the Raspberry Pi 4. It is not affiliated with or endorsed by Raspberry Pi.

Not financial advice. Not affiliated with GeekMagic, TradingView or MetaQuotes.

BUILT TO BE GLANCED AT.

A screen you look at for one second, twenty times a day, and trust.

TELEGRAM

@DrFXGOD

questions, orders, support

CHANNEL

@DrFXAi

updates and new releases

TRADINGVIEW

RaptorAlgo

the GOD MODE indicator



SPECIFICATION

PANEL	1.54" IPS 240×240	DRIVER	ST7789V
MCU	ESP-12F / ESP8266	FLASH	4 MB
POWER	USB-C, ~0.6 W	BRIDGE	Cloudflare Workers
SOFTWARE	MIT, open source	PAIRS	up to 4