

DRFX ULTRA OS

LIVE TRADING SIGNALS ON A DESK-SIZED SCREEN

240 x 240

IPS PANEL



ESP8266

39 KB RAM

SIGNALS
PRICES
CLOCK

NO SUBSCRIPTION TO RUN IT.
NO COMPUTER LEFT ON.
NOTHING EXPOSED TO THE INTERNET.

THREE MACHINES. ONE DIRECTION.

WHY IT IS BUILT THIS WAY

NOTHING EXPOSED

NOTHING LEFT ON

A CHIP THAT CANNOT

The ESP8266 has ~39 kB of RAM and each secure connection wants 16 kB. It cannot talk to four exchanges. The bridge does that, and sends a few hundred bytes.

```
{
  "v": "2.1.2",
  "src": "coinpaprika",
  "tickers": [
    {
      "s": "BTCUSD",
      "d": "BTC",
      "p": "63074.68",
      "c": 0.42,
      "k": [27, 23, 43, 39, 55, 47, 33, ..., 100]}
  ]
}
```

PAYLOAD

OUTBOUND ONLY.

THREE SCREENS, ON ROTATION.

Each holds for fifteen seconds. A new signal interrupts and stays put — it is the thing you actually care about.



SIGNAL

Symbol, direction, score ring, targets and stop. On screen about five seconds after the alert fires.

CRYPTO

Up to four pairs. 24-hour change and an hourly sparkline, from whichever source is reachable where you are.

CLOCK

Keeps time even where the network blocks NTP — the bridge supplies it instead. Dims itself at night.

ALSO INCLUDED

- SETTINGS IN A BROWSER
- NO APP REQUIRED
- NIGHT DIMMING
- 52 ZONES, REAL DST
- WI-FI FAILOVER
- OVER-THE-AIR UPDATES
- OPEN SOURCE, MIT
- SELF-DIAGNOSING
- FOUR PAIRS AT ONCE
- NO CLOUD ACCOUNT
- CAROUSEL OR FIXED
- USB-C, 0.6 W

Everything on these three screens is configured from one page in your browser. Nothing is hard-coded.

TWENTY MINUTES. NO CODING.

Six steps. Each one tells you what you should see when it worked.

01

MAKE YOUR KEYS

16%

Double-click `keygen.html`. Two random keys appear. It runs offline and sends nothing anywhere.

02

PUT THE BRIDGE ONLINE

33%

Run one script, or paste one file into the Cloudflare dashboard. The free tier is plenty.

03

FLASH THE SCREEN

50%

Download the ready-built file and upload it through the device's own update page.

04

JOIN YOUR WI-FI

66%

The screen makes its own network the first time. Join it, pick your Wi-Fi, save.

05

POINT IT AT THE BRIDGE

83%

Paste the address and one key. Status should read: connected, nothing new.

06

WIRE UP TRADINGVIEW

100%

Paste the webhook address into any alert. Optional — prices work without it.

IF SOMETHING IS WRONG

The screen tells you in plain words, not a code: “no bridge URL saved”, “Wi-Fi not connected”, “no device key saved”. And one command tests every link in the chain and names the broken one:

```
python tools/drfx.py doctor
```

THREE WAYS IN. THE CODE STAYS FREE.

Every line is open source under MIT. You can build all of this yourself, for nothing, forever. These exist only to save you the afternoon.

MOST POPULAR

READY-MADE

£ _____

The screen, flashed and tested

- Arrives working — join Wi-Fi, done
- Your keys pre-loaded
- Bridge already deployed
- 12-month replacement

Learn more about this

DONE FOR YOU

£ _____

You have the screen. We set it up

- Bridge deployed to your Cloudflare
- TradingView alerts wired up
- One screen-share, start to finish
- 30 days of follow-up questions

Learn more about this

THE SIGNALS

£ ____ /mo

The indicator this was built for

- GOD MODE Quad Consensus
- Sends straight to your screen
- Works on any TradingView plan
- Cancel whenever

Learn more about this

START WITH THE FREE ONE.

Clone the repository, run one script, and watch it working before you spend anything at all.

github.com/drfxai/GeekMagic-Ultra

your@email.com

BUILD IT FREE.

MIT LICENCE
NO ACCOUNT REQUIRED

For more information on how to build it, see the README in the repository.

Not financial advice. Not affiliated with GeekMagic or TradingView.

BUILT TO BE GLANCED AT.

A screen you look at for one second, twenty times a day, and trust.



SPECIFICATION

PANEL	1.54" IPS 240×240	DRIVER	ST7789V
MCU	ESP-12F / ESP8266	FLASH	4 MB
POWER	USB-C, ~0.6 W	BRIDGE	Cloudflare Workers
LICENCE	MIT	PAIRS	up to 4

