

FRONT · cut to 255 × 135 mm



LEFT · cut to 105 × 135 mm




TOP · cut to 255 × 105 mm



Sheet 1 of 3
Print at 100% (actual size), not "fit to page".
Check: the bar below must measure 100 mm.
Cut each panel on its corner marks. The picture runs 3 mm past every cut.

100 mm

BACK · cut to 255 × 135 mm



FLIGHTRADAR24

The whole world



MY RECEIVER

Your own patch of sky

BOTTOM · cut to 255 × 105 mm

RIGHT · cut to 105 × 135 mm

Sheet 2 of 3

Print at 100% (actual size), not "fit to page".

Check: the bar below must measure 100 mm.


Cut each panel on its corner marks. The picture runs 3 mm past every cut.

100 mm


FRONT · cut to 255 × 135 mm



LEFT · cut to 105 × 135 mm



RIGHT (on its side) · cut to 135 × 105 mm



Sheet 3 of 3
Print at 100% (actual size), not "fit to page".
Check: the bar below must measure 100 mm.
Cut each panel on its corner marks. The picture runs 3 mm past every cut.

100 mm