

The Computer Deconstruction Lab Presents 3D Printing Tutorial




1

Joseph E. Wilkes, PhD

September 2024

Work Flow

2



September 2024

Download Premade Objects from Web

- Many people design objects and upload them to sites
 - for free (or optional donations)
 - for a one time cost
- Sites for Free Projects
 - <https://www.thingiverse.com/>
 - <https://www.printables.com/>
 - <https://makerworld.com/en> (has pre-sliced files for bambu printers)
 - <https://pinshape.com/>
 - <https://cults3d.com/>
 - <https://www.3devo.com/blog/top-10-sites-for-free-3d-stl-files>

Tweak Pre-made Design

- Sometimes you may want to make changes to an existing design
- Change its size
- Separate multiple objects in an .stl file into individual .stl files
- Add additions to the design
- Other things
- You may need other tools to do these design changes
- Need list of tools!!!

Tools to Design Your Own Project

- <https://www.tinkercad.com/>
 - on line only but can download project into your computer
- <https://www.freecad.org/>
 - for windows, Mac and Linux
 - Bug in saving files on Windows 11
- <https://www.blender.org/download/>
 - for windows, Mac and Linux
- <https://www.sketchup.com/en>
 - Not Free
- <https://www.youtube.com/watch?v=J--QVhGheP4>
 - "BEST FREE CAD / 3D Modelling software 2024 - I tested them all!"

Getting ready for the slicer

- Each design tool will create and thus save files in their own format
- The interchange file must be in an .stl format
- If the project is downloaded from the web, you need to download the set of stl files
- If you created your own project and saved it, you then need to "export" the project in the .stl format
- Each program will have its own way of "exporting."
- If you download your project from the web, read carefully the notes that come with the project
- Some projects are customized for specific 3D printers and may not build correctly on other printers.

Slicers

7

- Slicers take the .stl file and reformat into the specific .gcode file that each 3D printer needs
- gcode for one printer may not print correctly for another printer
- In the slicer you must select your printer
 - Similar to selecting a printer when you print a document
- Most 3D printers companies have their own slicer customized for their product line.
- You can use your own slicer, if your printer is supported in the slicer
- In general, it is best to use the slicer that comes with the 3D printer

Slicer Software

- Cura
 - <https://ultimaker.com/software/ultimaker-cura/>
- Slic3r
 - <https://slic3r.org/download/>
- Bambu Studio for Bambu 3D Printers
 - <https://bambulab.com/en-us/download/studio>
- For Pura 3D Printers
 - https://www.prusa3d.com/page/prusaslicer_424/
- For Creality 3D Printers
 - <https://www.creality.com/pages/download-software>

Using Bambu Studio

- CDL's printer is the Bambu P1S with optional capability to support 4 different filaments
- Each time the printer needs to switch filaments, it must pause
 - cut off a length of filament
 - purge the filament out the garbage slot in the back
 - feed the new filament
- Printing a multi-color object takes a long time and is very wasteful of filament since the filament must be changed multiple times for each layer in the print
- Only print multiple color objects if you really need them, not just for fun, or consider buying CDL some filament





Example waste by
Printer

10

September 2024

Types of Filament

11

- PLA - polylactic acid (most commonly used)
- PETG HF - Polyethylene terephthalate glycol-modified
- ABS - Acrylonitrile Butadiene Styrene
- ABS-GF
- ASA
- Multi Colors
- Wood Pulp infused
- Metal

<https://bambulab.com/en-us/filament/guide>

<https://www.xometry.com/resources/3d-printing/types-of-3d-printer-filaments/>

September 2024


Recommended Settings for PLA

12

- nozzle size
- layer thickness
- bed temperature
- nozzle temperature
- head speed
- infill percent
- top and bottom layer thickness
- ?
- 0.4 mm, range 0.2-0.8
- 0.2 mm (changes with nozzle size)
- 60° C
- 200° C
- 5000 mm/sec
- 10%, range: 10-100%
- 2-3, range: as high as you want

September 2024


Bambu Studio Software Setup



This will be presented live

September 2024

Bambu Studio Software Setup




This will be presented live

September 2024

Bambu Studio Software Setup

15



This will be presented live

September 2024

Bambu Security Risks

16

- The default setup of the Bambu 3D printer and the Bambu Studio Software is to send all files to a Mainland China server and then the server sends the file to the 3D printer
- Since Bambu realizes that some users/companies may not want to release their designs to Bambu, they offer an option to directly send the file to the printer on the local wireless network.
- CDL has implemented this option.
- It is recommended that anyone using a Bambu printer use this option
- But the down side it that the tablet/phone remote control and viewing of the printer is now not available.

September 2024

How to Replace Filament in Printer

17

- Matt or Neil to provide info here

gcode editing

18

- Sometimes it is necessary to modify the generated gcode
- It can be done in a text editor
- But there are other programs that will do it also and help with make the changes
- <https://www.crealitycloud.com/blog/reviews/the-5-best-gcode-editors-for-3d-printing>

Print your project

19

- Once you have sliced the project, you should save the gcode file so you can print without slicing again
- Two Options:
 - Store gcode file on an SD card and put it in the printer to be printed
 - Send the gcode to the printer over the InfoAge guest network
- Reminder, the gcode will only work on the printer that was selected in the slicer program
- With the Bambu Studio Software you can see the printer status in a window (snap shots every few seconds)

September 2024

Remove it from the Bed when Finished

20

- After the printer is finished you can remove it from the bed.
- The bed is magnetically attached to the print plate
- Remove it and let is cool down
- Then flex the plate in both directions and the project should pop off the plate
- Return the plate to the printer bed and make sure it is correctly placed
- In some cases the object will stick to the plate and will need a scraper to lift it off the plate
- Do not use a knife or razor blade as that will destroy the plate and it will need to be replaced at a cost of about \$40.00

September 2024

Replacement Plate

21



Bambu Textured PEI Plate

\$37.99 USD

 [PayPal](#) Pay in 4 interest-free payments of \$9.50. [Learn more](#)

Shop now. Pay with Klarna. [Learn more](#) 

Select a Compatibility

For X1 Series/P1 Series/A1 For A1 mini

Quantity:

Discover More Discounts Here!

Both main product and add-ons must be added to the cart for extra discount to apply.

September 2024

Other Thoughts

22

- Here is where Matt, Neil, Pat and others can chime in with more information

Questions???

23

September 2024

References

24

- Free Projects:
 - <https://www.thingiverse.com/>
 - <https://www.printables.com/>
 - <https://pinshape.com/>
 - <https://cults3d.com/>
 - <https://www.3devo.com/blog/top-10-sites-for-free-3d-stl-files>
- Filaments:
 - <https://bambulab.com/en-us/filament/guide>
 - <https://www.xometry.com/resources/3d-printing/types-of-3d-printer-filaments/>
- Slicers:
 - Cura
 - <https://ultimaker.com/software/ultimaker-cura/>
 - Slic3r
 - <https://slic3r.org/download/>
- Bambu Specific:
 - <https://bambulab.com/en-us>
 - <https://makerworld.com/en>
has pre-sliced files for bambu printers
 - <https://bambulab.com/en-us/download/studio>

September 2024