

Analog Controller A Header Pins Upper Drawbars

- 1 Drawbar 16
- 2 Drawbar 5 1/3
- 4 Drawbar 4
- 5 Drawbar 2 2/3
- 7 Drawbar 1 5/9
- 9 Drawbar 1
- 11 Leslie Volume Pot
- 12 Swell Pedal (no connect if jack used)
- 15, 16 Drawbar End V+ (Reference)

Analog Controller B Header Pins Lower and Bass Drawbars

- 1 Drawbar 16
- 2 Drawbar 5 1/3
 - 3 Drawbar 8
- 4 Drawbar 4
- 6 Drawbar 2
- 8 Drawbar 1 1/3
- 9 Drawbar 1
- 12 Drawbar/Pot Bass Sustain 11 - Drawbar Bass 8
- 13, 14 Drawbar Gnd 15, 16 Drawbar End V+ (Reference)