# **Build Guide - Ender 3 Y (Bed) ExoSlide Motion Kit**

1/18/20




www.exoslide.com

#### 0. Parts removal and prep:

- -Remove the front Y belt Idler and bracket
- -Remove the rear Y belt motor and bracket set aside the motor to re-use
- -Remove the rear Y endstop set aside to re-use
- -Loosen all the bed hand adjusters, and remove the heated bed plate set aside to re-use
- -Loosen the V-wheels, and remove the bed carrier plate set aside the carrier plate to re-use
- -Remove the 2040 or 4040 (Pro) Y bed extrusion.

#### 1. Bed Rail Mounting:




#### Notes:

- -Install the bed mount on the frame the then the 2040 extrusion on top, using the M5x40 bolts.
- -For the Ender 3 (non-Pro), install the captured M5 nylock nuts into the mount first.
- -Do not overtighten the bolts!

#### 2. Carriage Assembly:

Parts Needed:
ExoSlide 20P, 2x
ExoSlide 40P, 1x
Belt Y Bracket, 1x
M4x18 bolt, 2x
M4x30 bolt, 2x
M4x35 bolt, 2x
M4x60 bolt, 2x
M4 nylock nut, 2x



#### Notes:


- -Tighten the six M4 bolts down firmly that secure the three ExoSlides together.
- -The two M4x14 bolts are for the Belt Y Bracket.

### 3. Motor Bracket Assembly:

Parts Needed:
Motor bracket, 1x
M3x6 bolt, 3x
M5x8 bolt, 2x
M5 T nut, 2x
Printed motor spacer, 1x
(only for the Pro)

Re-use:

*Re-use:* Motor, pulley



#### 4. Idler Bracket Assembly:

Parts Needed:
Idler bracket, 1x
MF688 bearings, 2x
M5x8 bolts, 2x
M5 T nut, 2x
M8x25 bolt, 1x
M8 nut, 1x
M8 jam nut, 1x
M8 washer, 1x



## 5. Gantry Assembly:

#### Parts Needed:

Motor bracket assembly, 1x Idler bracket assembly, 1x Carriage assembly, 1x Belt, 1x Printed end-stop, 1x (when installing only the Y ExoSlide kit)

#### Re-use:

End-stop assembly (when installing XY ExoSlide kit as well)




#### Notes:

- -Install the carriage assembly first, then the other assemblies.
- -Tension the belt with the idler assembly.
- -If only installing the Y ExoSlide kit, install the printed end-stop bracket (to clear bed plate of the next step)


## 6. Bed Plate Assembly:

Parts Needed:
Bed mount bracket, 1x
M4x14 flat head bolt, 4x
M4x8 bolt, 4x
M4 fender washer, 4x

*Re-use:* Bed plate











B: Mounting with both Y and XZ Exoslide kits



## Notes:

- -Install the bed mount bracket on the top ExoSlide with then four M4x14 flat head bolts.
- -Install the bed plate using M4x8 bolts with fender washers.

## 7. Motion Assembly:



#### Notes:

- -Install and level the bed.
- -Make cool stuff!