may be more caps needed to decouple source

instrumental (differential with high input
impedance) amplifier avoids gnd loop(s)

driving indcutive load need caps...?? (see LH0101)

driving indcutive load need caps...?? (see LH0101)

all R1 (R1.A - R1.D) have to be of exact the same value

R3- controls the gain (open is gain 1)

R2 (R2.A - R2.B) can be shortened (0 ohms)
    results in an bad common-mode rejection (cf. Tietze, Schenk p.1033 or p.1071)

IC4, IC5, IC6 can be omitted (shortcut pin 3 with1 and 5 with 7) for a worser input impedance

driving indcutive load need caps...?? (see LH0101)

		Tag	Name		
	Bearb.				
	Gepr.			Benennung	
	zu Gerät				
	zu Anlage			Zeichnungs-Nr.	
Rev	Änderungs-Nr.	Tag	Name	high-power-supply	Blatt 1/1	26.09.13 08:49

high-power-supply
Solèr, Piegsa, Kirch
rev. 02, 2013

high-power-supply
26.09.13 08:49
Sheet: 1/1