Model-TG Plaits Edition · Quick Reference

New machines, macros and shortcuts for the Elektron Model:Cycles (OS 1.13)

Install: drusanow.github.io/Model-TG-VA-Edition
Full guide: docs/USER_GUIDE.md

Hold A + B = hold A, press B. Model-TG's pages open with **SETTINGS** held; tapping SETTINGS alone still opens the Config Menu.
Every knob on every new machine p-locks, slides, takes LFOs and is saved.

On every machine

Control	What it does
PRESET + Decay	**Attack**: instant up to about 2 s
PRESET + Sweep / Contour	**Filter** / **Resonance** (a ladder filter; bypassed when fully open)
Pitch, Decay	As stock. Decay is the Amp Decay and comes *after* each engine's own envelope: turn it up to hear the full sound.

VA machine 8: two-oscillator analogue-style synth

Color: OSC1	Shape: OSC2	Sweep: DTUN	Contour: MIX
Osc 1 wave: 0-42 saw, 43-85 square, 86-127 tri	Osc 2 wave, same ranges	Osc 2 tuning: 64 unison, near 64 = cents, 0 / 127 = octave down / up	0 osc 1 only, 64 both equally, 127 osc 2 only

VA KICK, VA SNARE, VA HIHAT machines 9-11: analogue-style drums

Machine	Color	Shape	Sweep	Contour
VA KICK	SWP sweep depth	STM sweep time	SAT drive	CLK click
VA SNARE	NOIS body / noise	PENV pitch drop	TONE noise colour	SAT drive
VA HIHAT	TONE high-pass	SPRD spread	NOIS noise	SAT drive

VA HIHAT: short Decay for a closed hat, long for an open one.

PLAITS machine 12: ten engines after Mutable Instruments Plaits

Contour (ENG) picks the engine: the screen shows its picture and name, and four clicks move one engine. Color / Shape / Sweep = Plaits' HARMONICS / TIMBRE / MORPH.

ENG	Engine	Color	Shape	Sweep
WSHP	waveshaping	SHPE waveshaper	FOLD wavefolder	ASYM slope
FM	2-operator FM	RATI ratio	INDX index	FDBK feedback
SWRM	granular cloud (a grain per trig too)	SPRD pitch spread	DENS density	DUR grain length
GRAN	formants	FRM2 2nd formant	FRMT formant	WDTH grain shape
PD	phase distortion	RATI ratio	DIST amount	ASYM asymmetry
CHIP	chiptune arpeggio (a step per trig)	CHRD chord	ARP pattern	SYNC synced ratio
NOIS	filtered noise	TYPE LP-BP-HP	CLK clock	RESO resonance
MODL	modal resonator (struck per trig)	MATR string-bell-drum-bar	BRIG brightness	DEC decay
PART	particles	SPRD spread	DENS density	RESO resonance
STRG	plucked string	STIF stiffness	BRIG brightness	DAMP damping

DX machine 13: 6-operator FM after the DX7

Knob	What it does
Color: BRIG	Brighter / darker (modulators up to ±12 dB, same loudness)
Shape: TIME	All the voice's envelopes shorter / longer
Sweep: FDBK	Less / more feedback (0 none, 127 most)
Contour: VOIC	The voice: 1-63 built in, or 1-32 of your cartridge; its name is shown
SETTINGS + Shape	**Algorithm**: VCE (the voice's own), A1-A32

The macros start in the middle (0 = the voice exactly as saved). Picking a voice resets the macros and sets the algorithm back to VCE.

Built-in bank (63 voices): 1-32 Legowelt's "Magic DX7", 33-52 a DX9 cartridge, 53-63 our own: INIT, E.PIANO, SYN BASS, GLASS BELL, BRASS, DRAWBARS, FM PLUCK, SOFT PAD, MARIMBA, CLAV, SINE BASS.

Your own DX7 cartridges:

- Send a DX7 `.syx` over USB or MIDI IN (the DX Cartridge Sender page, a SysEx librarian or Dexed). It is saved in `/DX7/`.
- On a DX track: **FUNCTION + PRESET** › DX7 › pick it ("Cartridge loaded").
- The pattern keeps it and reloads it with the project.

Turn Decay up: a low Decay cuts pads short.

LXR machine 14: the Erica Synths LXR-02's voices, ported NEW

Contour (ENG) picks the preset: the voices of the LXR's own init kit.

Preset	LXR voice
KICK	drum 1: sine, fast pitch drop
TOM	drum 2: sine, slow pitch drop
PERC	drum 3: sine, big very fast drop
SNAR	snare: triangle + sample-and-hold noise
CLAP	snare in repeat mode: 4 claps, a tail
CHAT / OHAT	hi-hat: carrier phase-modulated by 2 oscs
CYMB	cymbal: noise carrier, high-passed, long

Color / Shape / Sweep move the preset's LXR settings; **64** = the preset exactly:

Presets	Color	Shape	Sweep
KICK, TOM, PERC	PAMT pitch drop	PTIM drop time	FMAM FM amount
SNAR	NMIX tone ↔ noise	NTON noise rate	SNAP pitch drop
CLAP	SPRD clap spacing	TONE filter	CLPS claps
CHAT, OHAT	TUNE semitones	METL modulators	BRIT filter
CYMB	TUNE noise rate	RING resonance	BRIT filter

Each preset has its own natural length; Amp Decay comes after it.

SETTINGS + PRESET: the voice menu, every LXR setting of the preset (wave, tuning, FM, pitch and amp EGs, repeat, filter, drive, distortion, sample rate, transient, volume). **DATA** moves, **any knob** changes, DATA press: DATA changes too. Last row: put back the preset. Saved with the pattern; the macros move from it.

LFO 2, 3 and 4, and LFOs to MIDI CC

Control	What it does
LFO, then tap LFO again	LFO 1 › LFO 2 › LFO 3 › LFO 4 › close. LFO 3 and 4 can't be p-locked (saved per pattern).
Hold LFO + turn a knob	That parameter becomes the destination of the LFO showing
MIDI CC row: DATA, turn, DATA	The CC that LFO sends (OFF / 0-127), on the track's MIDI channel; switched on at the second press
CC Base row: turn DATA	The value the CC sweeps from (Depth sweeps one way from it). Destination None = only the external gear moves.

Trig generator

SETTINGS + TRACK: **RND** (chance DNS %) or **EUC** (HIT trigs, ROT rotation). Options: **NOT** random notes from SCL / KEY / OCT / RNG, **VEL** random velocity VMN-VMX. Select **GEN** and press **DATA** (again for another result). It **replaces the track's trigs**; there is no undo.

Quantised mute and solo

While playing, mutes change on the next bar. **SETTINGS + pad** solos that track (same again = SOLO OFF). **Device Config › Mute Q**: 1BAR / PTN / OFF.

Alternative send effects

SETTINGS + PAGE › turn **DATA**, saved per pattern.

- **Delay:** DELAY, PING (ping-pong), TAPE, CHORUS (flanger past half Feedback)
- **Reverb:** REVERB, PHASER, SPRING, RING, DIST, RESO (Size = pitch, Tone = ring)

The FX page's Time / Feedback / Size / Tone knobs drive the chosen effect.

Slide trigs and Scale Lock

SETTINGS + trig key: slide trig on/off (double-blinks). Every value that differs glides into the slide trig.

FUNC + PAGE: Scale menu: **Scl** and **Key**; played notes snap to the scale.

Button reference

Buttons	Does
PRESET + Decay	Attack
PRESET + Sweep / Contour	Filter / Resonance
SETTINGS + Shape (DX)	DX algorithm
FUNCTION + PRESET (DX)	load a DX7 cartridge
SETTINGS + TRACK	trig generator
SETTINGS + PAGE	Send FX
SETTINGS + pad	solo on the next bar
SETTINGS + trig key	slide trig on / off

Buttons	Does
SETTINGS + PRESET	Sampler: playback mode. LXR: voice menu
SETTINGS + PUNCH	the mode's options
SETTINGS + RECORD	Resample menu
SETTINGS + RETRIG	retrig page and master FX
SETTINGS + return	master FX off
LFO (tap again)	LFO 2 / 3 / 4
TRACK + tap FUNC	latching mute mode
step held + PAGE (stopped)	trig preview

Device Config: **System** (CPU, memory), **Mute Q**, **CPU Guard** (ON: DX/LXR drop to 32 kHz, then the oldest note ends, not the audio), **LXR Rate** (48K: cheaper), **Transfer** CYC / SMP (SMP = upload samples with Transfer; only install an OS when it's set to CYC).

Unofficial firmware, not made or endorsed by Elektron; back up first. Model-TG by TinyGregAudio (MIT). PLAITS after Mutable Instruments Plaits (MIT). LXR is a modified port of the Erica Synths LXR-02 firmware (GPL-3.0), not endorsed by Erica Synths; the firmware is GPL-3.0 as a whole. Source: github.com/drusanow/Model-TG-VA-Edition.