


# **Quadrature Decoder (QuadDec)**

2.0

### **Features**


- Adjustable counter size: 8, 16, or 32 bits
- Counter resolution of 1x, 2x, or 4x the frequency of the A and B inputs, for more accurate determination of position or speed
- Optional index input to determine absolute position
- Optional glitch filtering to reduce the impact of system-generated noise on the inputs



# **General Description**

The Quadrature Decoder (QuadDec) Component gives you the ability to count transitions on a pair of digital signals. The signals are typically provided by a speed/position feedback system mounted on a motor or trackball.

The signals, typically called A and B, are positioned 90 degrees out of phase, which results in a Gray code output. A Gray code is a sequence where only one bit changes on each count. This is essential to avoid glitches. It also allows detection of direction and relative position. A third optional signal, named Index, is used as a reference to establish an absolute position once per rotation.



#### When to Use a Quadrature Decoder

A quadrature decoder is used to decode the output of a quadrature encoder. A quadrature encoder senses the current position, velocity, and direction of an object (for example, mouse, trackball, robotic axles, and others).

A quadrature decoder can also be used for precision measurement of speed, acceleration, and position of a motor's rotor and with rotary knobs to determine user input.

# **Input/Output Connections**

This section describes the various input and output connections for the Quadrature Decoder Component. An asterisk (\*) in the list of I/Os indicates that the I/O may be hidden on the symbol under the conditions listed in the description of that I/O.

### quad\_A - Input

The "A" input of the Quadrature Decoder.

### quad\_B - Input

The "B" input of the Quadrature Decoder.

### index - Input \*

This input detects a reference position for the Quadrature Decoder. When using an index input, if inputs A, B, and index are all zero, the counter is also reset to zero. Additional logic is typically added to gate the index pulse. Index gating allows the counter to only be reset during one of many possible rotations. An example is a linear actuator that only resets the counter when the far limit of travel has been reached. This limit is signaled by a mechanical limit switch whose output is connected to the Index pulse.

This input displays by default, but it can be hidden by deselecting the **Use index input** parameter.

## clock - Input

Clock signal for sampling and glitch filtering the inputs. If you are using glitch filtering, the filtered outputs will not change until three successive samples of the input have the same value. For effective glitch filtering, the sample clock period should be greater than the maximum time during which glitching is expected to take place. A counter can be incremented or decremented at a resolution of 1x, 2x, or 4x the frequency of the A and B inputs.

The clock input frequency should be greater than or equal to 10x the maximum A or B input frequency.

## interrupt - Output

Interrupt on one or more of the following events:


- Counter overflow and underflow
- Counter reset due to index input (if index is used)
- Invalid state transition on the A and B inputs



# **Component Parameters**

Drag a Quadrature Decoder component onto your design and double-click it to open the **Configure** dialog. The dialog contains multiple tabs with categorized parameters.

#### **Counter Size Tab**



This tab is used to define the counter size, in bits. The counter holds the current position encoded by a quadrature encoder.


Select a counter that is large enough to encode the maximum position in both the positive and negative directions. The setting can be: 8 bit, 16 bit, or 32 bit.

The 32-bit counter implements the lower 16 bits in the hardware counter and the upper 16 bits in software to reduce hardware resource use. For this target, an additional ISR is used. To work properly with the 32-bit counter, interrupts must be enabled. You can add ISR code to source files as needed; see the Interrupt Component datasheet for more details.




Document Number: 001-69402 Rev. \*A Page 3 of 32

#### **Counter Resolution Tab**



This tab contains the number of counts recorded in one period of the A and B inputs. It shows the transitions of the input signals that are used to update the counter. As the resolution gets higher, the position can be resolved more accurately, at the possible cost of a larger counter. The setting can be 1x, 2x, or 4x.


### **Use Index Input Tab**





This tab contains a field to enable or disable the index input. An index input can be used to indicate that a reference position has been reached. If an index input is used, then when the A, B, and index inputs are all zero, the counter is reset and an interrupt can be generated. Index input is enabled by default.

#### **Enable Glitch Filtering Tab**



This tab contains a field to enable or disable digital glitch filtering. Filtering can be applied to reduce the probability of miscounts because of glitches on the inputs. Some filtering is already done using hysteresis on the GPIOs, but additional filtering could be required.

If enabled, filtering is applied to all inputs. The filtered outputs do not change until three successive samples of the input have the same value. For effective filtering, the period of the sample clock should be greater than the maximum time during which glitching is expected to occur. Glitch filtering is enabled by default.

### **Clock Selection**

A clock source for clocking the Quadrature Decoder component must be connected. It clocks the status register and generates interrupts.

## **Placement**

The Quadrature Decoder component is placed in the UDB array and all placement information is provided to the API through the *cyfitter.h* file.



Document Number: 001-69402 Rev. \*A

## Resources

# 1x Resolution without Glitch Filtering

			Resou		lemory rtes)			
Resources	Datapath Cells	PLDs	Status Cells	Control/ Count7 Cells	Interrupts	Flash	RAM	Pins (per External I/O)
8 bits	1	6	2	1	0	566	7	2
8 bits *	1	6	2	1	0	566	7	3
16 bits	2	6	2	1	0	652	9	2
16 bits *	2	6	2	1	0	652	9	3
32 bits	2	6	2	1	1	906	14	2
32 bits *	2	9	2	1	1	906	14	3

<sup>\*</sup> Using Index Input

# 1x Resolution with Glitch Filtering

			Resou		lemory rtes)			
Resources	Datapath Cells	PLDs	Status Cells	Control/ Count7 Cells	Interrupts	Flash	RAM	Pins (per External I/O)
8 bits	1	7	2	1	0	566	7	2
8 bits *	1	9	2	1	0	566	7	3
16 bits	2	7	2	1	0	652	9	2
16 bits *	2	9	2	1	0	652	9	3
32 bits	2	7	2	1	1	906	14	2
32 bits *	2	9	2	1	1	906	14	3

<sup>\*</sup> Using Index Input



Page 6 of 32 Document Number: 001-69402 Rev. \*A

# 2x Resolution without Glitch Filtering

		API Memory Resource Type (Bytes)			_			
Resources	Datapath Cells Status Control/ Count7 Cells Interrupts				Flash	RAM	Pins (per External I/O)	
8 bits	1	6	2	1	0	566	7	2
8 bits *	1	7	2	1	0	566	7	3
16 bits	2	6	2	1	0	652	9	2
16 bits *	2	7	2	1	0	652	9	3
32 bits	2	6	2	1	1	906	14	2
32 bits *	2	7	2	1	1	906	14	3

<sup>\*</sup> Using Index Input

# 2x Resolution with Glitch Filtering

		API Memory Resource Type (Bytes)						
Resources	Datapath Cells	PLDs Status Cells C		Control/ Count7 Cells	Interrupts	Flash	RAM	Pins (per External I/O)
8 bits	1	8	2	1	0	566	7	2
8 bits *	1	9	2	1	0	566	7	3
16 bits	2	8	2	1	0	652	9	2
16 bits *	2	9	2	1	0	652	9	3
32 bits	2	8	2	1	1	906	14	2
32 bits *	2	9	2	1	1	906	14	3

<sup>\*</sup> Using Index Input



Document Number: 001-69402 Rev. \*A Page 7 of 32

# 4x Resolution without Glitch Filtering

			Res		emory rtes)			
Resources	Datapath Cells	•		Flash	RAM	Pins (per External I/O)		
8 bits	1	7	2	1	0	566	7	2
8 bits *	1	7	2	1	0	566	7	3
16 bits	2	7	2	1	0	652	9	2
16 bits *	2	7	2	1	0	652	9	3
32 bits	2	7	2	1	1	906	14	2
32 bits *	2	7	2	1	1	906	14	3

<sup>\*</sup> Using Index Input

# 4x Resolution with Glitch Filtering

			Res	API Memory (Bytes)				
Resources	Datapath Cells	PLDs	Status Control/ Count7 Cells Cells Inte		Interrupts	Flash	RAM	Pins (per External I/O)
8 bits	1	8	2	1	0	566	7	2
8 bits *	1	9	2	1	0	566	7	3
16 bits	2	8	2	1	0	652	9	2
16 bits *	2	9	2	1	0	652	9	3
32 bits	2	8	2	1	1	906	14	2
32 bits *	2	9	2	1	1	906	14	3

<sup>\*</sup> Using Index Input



Page 8 of 32 Document Number: 001-69402 Rev. \*A

# **Application Programming Interface**

Application Programming Interface (API) routines allow you to configure the component using software. The following table lists and describes the interface to each function. The subsequent sections cover each function in more detail.

By default, PSoC Creator assigns the instance name "QuadDec\_1" to the first instance of a component in a given design. You can rename it to any unique value that follows the syntactic rules for identifiers. The instance name becomes the prefix of every global function name, variable, and constant symbol. For readability, the instance name used in the following table is "QuadDec."

Function	Description
QuadDec_Start()	Initializes UDBs and other relevant hardware
QuadDec_Stop()	Turns off UDBs and other relevant hardware
QuadDec_GetCounter()	Reports the current value of the counter
QuadDec_SetCounter()	Sets the current value of the counter
QuadDec_GetEvents()	Reports the current status of events
QuadDec_SetInterruptMask()	Enables or disables interrupts due to the events
QuadDec_GetInterruptMask()	Reports the current interrupt mask settings
QuadDec_Sleep()	Prepares the component to go to sleep
QuadDec_Wakeup()	Prepares the component to wake up
QuadDec_Init()	Initializes or restores default configuration provided with the customizer
QuadDec_Enable()	Enables the Quadrature Decoder
QuadDec_SaveConfig()	Saves the current user configuration
QuadDec_RestoreConfig()	Restores the user configuration

#### **Global Variables**

Function	Description
QuadDec_initVar	QuadDec_initVar indicates whether the Quadrature Decoder has been initialized. The variable is initialized to 0 and set to 1 the first time QuadDec_Start() is called. This allows the component to restart without reinitialization after the first call to the QuadDec_Start() routine.
	If reinitialization of the component is required, then the QuadDec_Init() function can be called before the QuadDec_Start() or QuadDec_Enable() function.
QuadDec_count32SoftPart	High 16 bits of 32-bit counter value is stored in this variable.
QuadDec_swStatus	Status register value is stored in this variable.



Document Number: 001-69402 Rev. \*A Page 9 of 32

### void QuadDec\_Start(void)

**Description:** Initializes UDBs and other relevant hardware. Resets counter to 0, and enables or disables

all relevant interrupts. Starts monitoring the inputs and counting.

Parameters: None
Return Value: None
Side Effects: None

### void QuadDec\_Stop(void)

**Description:** Turns off UDBs and other relevant hardware.

Parameters: None
Return Value: None
Side Effects: None

### int8/16/32 QuadDec\_GetCounter(void)

**Description:** Reports the current value of the counter.

Parameters: None

Return Value: int8/16/32: Counter value. Return type is signed depending on the counter size setting. A

positive value indicates clockwise movement (B before A).

Side Effects: None

## void QuadDec\_SetCounter(int8/16/32 value)

**Description:** Sets the current value of the counter.

Parameters: int8/16/32 value: The new value. Parameter type is signed depending on the counter size

setting.

Return Value: None
Side Effects: None



## uint8 QuadDec\_GetEvents(void)

**Description:** Reports the current status of events.

Parameters: None

**Return Value:** The events, as bits in an unsigned 8-bit value:

Bit	Description
QuadDec_COUNTER_OVERFLOW	Counter overflow
QuadDec_COUNTER_UNDERFLOW	Counter underflow
QuadDec_COUNTER_RESET	Counter reset due to index, if index input is used
QuadDec_INVALID_IN	Invalid A, B inputs state transition

Side Effects: None

## void QuadDec\_SetInterruptMask(uint8 mask)

**Description:** Enables or disables interrupts caused by the events. For the 32-bit counter, the overflow,

underflow, and reset interrupts cannot be disabled; these bits are ignored.

Parameters: uint8 mask: Enable or disable bits in an 8-bit value, where 1 enables the interrupt:

Bit	Description
QuadDec_COUNTER_OVERFLOW	Enable interrupt caused by counter overflow
QuadDec_COUNTER_UNDERFLOW	Enable interrupt caused by counter underflow
QuadDec_COUNTER_RESET	Enable interrupt caused by counter reset
QuadDec_INVALID_IN	Enable interrupt caused by invalid input state transition

Return Value: None
Side Effects: None



Document Number: 001-69402 Rev. \*A

### uint8 QuadDec\_GetInterruptMask(void)

**Description:** Reports the current interrupt mask settings.

Parameters: None

Return Value: Enable or disable bits in an 8-bit value, where 1 enables the interrupt.

For the 32-bit counter, the overflow, underflow, and reset enable bits are always set.

Bit	Description
QuadDec_COUNTER_OVERFLOW	Interrupt caused by counter overflow
QuadDec_COUNTER_UNDERFLOW	Interrupt caused by counter underflow
QuadDec_COUNTER_RESET	Interrupt caused by counter reset
QuadDec_INVALID_IN	Interrupt caused by invalid A, B inputs state transition

Side Effects: None

## void QuadDec\_Sleep(void)

**Description:** This is the preferred routine to prepare the component for sleep. The QuadDec\_Sleep()

routine saves the current component state. Then it calls the QuadDec\_Stop() function and

calls QuadDec\_SaveConfig() to save the hardware configuration.

Call the QuadDec\_Sleep() function before calling the CyPmSleep() or the CyPmHibernate() function. Refer to the PSoC Creator *System Reference Guide* for more information about

power management functions.

Parameters: None
Return Value: None
Side Effects: None

## void QuadDec\_Wakeup(void)

**Description:** This is the preferred routine to restore the component to the state when QuadDec\_Sleep()

was called. The QuadDec\_Wakeup() function calls the QuadDec\_RestoreConfig() function to restore the configuration. If the component was enabled before the QuadDec\_Sleep() function was called, the QuadDec\_Wakeup() function will also re-enable the component.

Parameters: None Return Value: None

Side Effects: Calling the QuadDec\_Wakeup() function without first calling the QuadDec\_Sleep() or

QuadDec SaveConfig() function may produce unexpected behavior.



### void QuadDec\_Init(void)

**Description:** Initializes or restores the component according to the customizer Configure dialog settings. It

is not necessary to call QuadDec\_Init() because the QuadDec\_Start() routine calls this

function and is the preferred method to begin component operation.

Parameters: None Return Value: None

Side Effects: All registers will be set to values according to the customizer Configure dialog.

#### void QuadDec\_Enable(void)

**Description:** Activates the hardware and begins component operation. It is not necessary to call

QuadDec Enable() because the QuadDec Start() routine calls this function, which is the

preferred method to begin component operation.

Parameters: None
Return Value: None
Side Effects: None

### void QuadDec\_SaveConfig(void)

**Description:** This function saves the component configuration and nonretention registers. This function

also saves the current component parameter values, as defined in the Configure dialog or as

modified by appropriate APIs. This function is called by the QuadDec Sleep() function.

Parameters: None
Return Value: None
Side Effects: None

## void QuadDec\_RestoreConfig(void)

**Description:** This function restores the component configuration and nonretention registers. This function

also restores the component parameter values to what they were before calling the

QuadDec\_Sleep() function.

Parameters: None
Return Value: None

Side Effects: Calling this function without first calling the QuadDec\_Sleep() or QuadDec\_SaveConfig()

function may produce unexpected behavior.



# **Sample Firmware Source Code**

PSoC Creator provides numerous example projects that include schematics and example code in the Find Example Project dialog. For component-specific examples, open the dialog from the Component Catalog or an instance of the component in a schematic. For general examples, open the dialog from the Start Page or **File** menu. As needed, use the **Filter Options** in the dialog to narrow the list of projects available to select.

Refer to the "Find Example Project" topic in the PSoC Creator Help for more information.


# **Functional Description**

### **Default Configuration**

The default configuration for the Quadrature Decoder is an 8-bit up and down counter with 1x resolution, enabled index input, and enabled glitch filtering.

#### **State Transition**


Quadrature phase signals are typically decoded with a state machine and an up/down counter. A conventional decoder has four states, corresponding to all possible values of the A and B inputs. The state transition diagram is shown below (same-state transitions are not depicted). State transitions marked with a "+" and "-" indicate increment and decrement operations on the quadrature phase counter.



For each full cycle of the quadrature phase signal, the quadrature phase counter changes by four counts. Lower-resolution counters can also be used by implementing up/down operations on only a subset of the state transitions. A quarter-resolution decoder is shown below.




Page 15 of 32



All inputs are sampled using a clock signal derived internally within the device.

# **Block Diagram and Configuration**

The Quadrature Decoder is only available as a UDB configuration of blocks. The APIs are described earlier in this document and the registers are described in the next section to define the overall implementation of the component.





Document Number: 001-69402 Rev. \*A

# Registers

#### **Status**

Bits	7	6	5	4	3	2	1	0
Value		rese	rved		invalid in	reset	underflow	overflow

The status register is read-only. It contains the various status bits defined for the Quadrature Decoder. The value of this register is available with the QuadDec\_GetEvents() function. The interrupt output signal is generated from an ORing of the masked bit fields within the status register.

You can set the mask using the QuadDec\_SetInterruptMask() function. After you receive an interrupt you can retrieve the interrupt source by reading the status register with the QuadDec\_GetEvents() function. The status register is transparent, so the QuadDec\_GetEvents() function does not clear the bits of the status register. All operations on the status register must use the following defines for the bit fields, because these bit fields may be moved within the status register at build time.

There are several bit field masks defined for the status registers. Any of these bit fields may be included as an interrupt source. All bit fields are configured as sticky bits in the status register. Defines are available in the generated header (.h) file as follows:

- QuadDec\_COUNTER\_OVERFLOW Defined as the bit mask of the Status register bit "counter overflow."
- QuadDec\_COUNTER\_UNDERFLOW Defined as the bit mask of the Status register bit "Counter underflow."
- QuadDec RESET Defined as the bit-mask of the Status register bit "reset due index."
- QuadDec\_INVALID\_IN Defined as the bit- mask of the Status register bit "invalid state transition on the A and B inputs."



### DC and AC Electrical Characteristics

The following values indicate expected performance and are based on initial characterization data.

## **Timing Characteristics "Maximum with Nominal Routing"**

Parameter	Description	Config.	Min	Тур	Max	Units
f <sub>CLOCK</sub>	Component clock frequency	Config 1 1			34	MHz
		Config 2 <sup>2</sup>			29	MHz
		Config 3 <sup>3</sup>			16	MHz
t <sub>CLOCKH</sub>	Input clock high time 4	N/A		0.5		1/f <sub>CLOCK</sub>
t <sub>CLOCKL</sub>	Input clock low time 4	N/A		0.5		1/f <sub>CLOCK</sub>
		Inputs				
t <sub>PD_ps</sub>	Input path delay, pin to sync 5	1			STA <sup>6</sup>	ns
t <sub>PD_ps</sub>	Input path delay, pin to sync <sup>7</sup>	2			8.5	ns
t <sub>PD_IE</sub>	Input path delay to component clock (edge-sensitive input)	1,2	t <sub>PD_ps</sub> + t <sub>SYNC</sub> + t <sub>PD_si</sub>		t <sub>PD_ps</sub> + t <sub>SYNC</sub> + t <sub>PD_si</sub> + t <sub>I_clk</sub>	ns

<sup>1</sup> Config 1 options:

CounterResolution: 1
CounterSize: 8
UsingGlitchFiltering: false
UsingIndexInput: true

<sup>2</sup> Config 2 options:

CounterResolution: 2
CounterSize: 16
UsingGlitchFiltering: true
UsingIndexInput: true

<sup>3</sup> Config 3 options:

CounterResolution: 4
CounterSize: 32
UsingGlitchFiltering: true
UsingIndexInput: true

<sup>&</sup>lt;sup>7</sup> t<sub>PD\_ps</sub> in configuration 2 is a fixed value defined per pin of the device. The number listed here is a nominal value of all of the pins available on the device.



Document Number: 001-69402 Rev. \*A Page 17 of 32

 $<sup>^{4}</sup>$  t<sub>CY clock</sub> = 1/f<sub>CLOCK</sub> - Cycle time of one clock period

<sup>&</sup>lt;sup>5</sup> t<sub>PD\_ps</sub> is found in the Static Timing Results, as described later. The number listed here is a nominal value based on STA analysis on many inputs.

<sup>&</sup>lt;sup>6</sup> t<sub>PD\_ps</sub> and t<sub>PD\_si</sub> are route path delays. Because routing is dynamic, these values can change and directly affect the maximum component clock and sync clock frequencies. The values must be found in the Static Timing Analysis results.

Parameter	Description	Config.	Min	Тур	Max	Units
t <sub>PD_si</sub>	Sync output to input path delay (route)	1,2,3,4			STA <sup>6</sup>	ns
t <sub>l_clk</sub>	Alignment of clockX and clock	1,2,3,4	0		1	t <sub>CY_clock</sub>
t <sub>IH</sub>	Input high time	1,2	t <sub>CY_clock</sub>			ns
t <sub>IL</sub>	Input low time	1,2	t <sub>CY_clock</sub>			ns
t <sub>PD_IE</sub>	Input path delay to component clock (edge-sensitive input)	3,4	t <sub>SYNC</sub> + t <sub>PD_si</sub>		t <sub>SYNC</sub> + t <sub>PD_si</sub> + t <sub>l_clk</sub>	ns
t <sub>IH</sub>	Input high time	1,2,3,4	t <sub>CY_clock</sub>			ns
t <sub>IL</sub>	Input low time	1,2,3,4	t <sub>CY_clock</sub>			ns
f <sub>AB</sub>	Component A and B Frequency	N/A			f <sub>CLOCK</sub> /10	MHz
t <sub>IND</sub>	Index signal width	Without glitch filtering	2 × t <sub>CY_clock</sub> + 5			ns
		With glitch filtering	3 × t <sub>CY_clock</sub> + 5			ns
t <sub>RD</sub>	Index input low to reset time	Without glitch filtering		2		t <sub>CY_clock</sub>
		With glitch filtering		5		t <sub>CY_clock</sub>
t <sub>GL</sub>	Time during which glitching is expected to occur	With glitch filtering			3	t <sub>CY_clock</sub>
t <sub>CD</sub>	Delay time, rising edge of clock to count valid	N/A		2		t <sub>CY_clock</sub>
t <sub>E</sub>	Encoder pulse width (low or high)	N/A	4			t <sub>CY_clock</sub>
t <sub>ES</sub>	Encoder state period	N/A	2			t <sub>CY_clock</sub>
t <sub>ELP</sub>	Encoder period width	N/A	10			t <sub>CY_clock</sub>



## **Timing Characteristics "Maximum with All Routing"**

Parameter	Description	Config.	Min	Тур	Max 1	Units
f <sub>CLOCK</sub>	Component clock frequency	Config 1 <sup>2</sup>			17	MHz
		Config 2 <sup>3</sup>			14	MHz
		Config 3 <sup>4</sup>			8	MHz
t <sub>CLOCKH</sub>	Input clock high time <sup>5</sup>	N/A		0.5		1/f <sub>CLOCK</sub>
t <sub>CLOCKL</sub>	Input clock low time 5	N/A		0.5		1/f <sub>CLOCK</sub>
	In	puts				
t <sub>PD_ps</sub>	Input path delay, pin to sync <sup>6</sup>	1			STA 7	ns
t <sub>PD_ps</sub>	Input path delay, pin to sync <sup>8</sup>	2			8.5	ns
t <sub>PD_IE</sub>	Input path delay to component clock (edge-sensitive input)	1,2	t <sub>PD_ps</sub> + t <sub>SYNC</sub> + t <sub>PD_si</sub>		t <sub>PD_ps</sub> + t <sub>SYNC</sub> + t <sub>PD_si</sub> + t <sub>l_clk</sub>	ns
t <sub>PD_si</sub>	Sync output to input path delay (route)	1,2,3,4			STA 7	ns
t <sub>l_clk</sub>	Alignment of clockX and clock	1,2,3,4	0		1	t <sub>CY_clock</sub>

<sup>&</sup>lt;sup>1</sup> Maximum for "All Routing" is calculated by <nominal>/2 rounded to the nearest integer. This value provides a basis for you to not have to worry about meeting timing if the component is running at or below this component frequency.

<sup>2</sup> Config 1 options:

CounterResolution: 1
CounterSize: 8
UsingGlitchFiltering: false
UsingIndexInput: true

<sup>3</sup> Config 2 options:

CounterResolution: 2
CounterSize: 16
UsingGlitchFiltering: true
UsingIndexInput: true

<sup>4</sup> Config 3 options:

CounterResolution: 4
CounterSize: 32
UsingGlitchFiltering: true
UsingIndexInput: true

<sup>&</sup>lt;sup>8</sup> t<sub>PD\_ps</sub> in configuration 2 is a fixed value defined per pin of the device. The number listed here is a nominal value of all of the pins available on the device.



Document Number: 001-69402 Rev. \*A Page 19 of 32

 $<sup>^{5}</sup>$  t<sub>CY\_clock</sub> = 1/f<sub>CLOCK</sub> - Cycle time of one clock period

 $<sup>^{6}</sup>$   $t_{PD\_ps}$  ios found in the Static Timing Results, as described later. The number listed here is a nominal value based on STA analysis on many inputs.

<sup>&</sup>lt;sup>7</sup> t<sub>PD\_ps</sub> and t<sub>PD\_si</sub> are route path delays. Because routing is dynamic, these values can change and will directly affect the maximum component clock and sync clock frequencies. The values must be found in the Static Timing Analysis results.

Parameter	Description	Config.	Min	Тур	Max 1	Units
t <sub>IH</sub>	Input high time	1,2	t <sub>CY_clock</sub>			ns
t <sub>IL</sub>	Input low time	1,2	t <sub>CY_clock</sub>			ns
t <sub>PD_IE</sub>	Input path delay to component clock (edge-sensitive input)	3,4	t <sub>SYNC</sub> + t <sub>PD_si</sub>		t <sub>SYNC</sub> + t <sub>PD_si</sub> + t <sub>I_clk</sub>	ns
t <sub>IH</sub>	Input high time	1,2,3,4	t <sub>CY_clock</sub>			ns
t <sub>IL</sub>	Input low time	1,2,3,4	t <sub>CY_clock</sub>			ns
f <sub>AB</sub>	Component A and B frequency	N/A			f <sub>CLOCK</sub> /10	MHz
t <sub>IND</sub>	Index signal width	Without glitch filtering	2 × t <sub>CY_clock</sub> + 5			ns
		With glitch filtering	3 × t <sub>CY_clock</sub> + 5			ns
t <sub>RD</sub>	Index input low to reset time	Without glitch filtering		2		t <sub>CY_clock</sub>
		With glitch filtering		5		t <sub>CY_clock</sub>
t <sub>GL</sub>	Time during which glitching is expected to occur	With glitch filtering			3	t <sub>CY_clock</sub>
t <sub>CD</sub>	Delay time, rising edge of clock to count valid	N/A		2		t <sub>CY_clock</sub>
t <sub>E</sub>	Encoder pulse width (low or high)	N/A	4			t <sub>CY_clock</sub>
t <sub>ES</sub>	Encoder state period	N/A	2			t <sub>CY_clock</sub>
t <sub>ELP</sub>	Encoder period width	N/A	10			t <sub>CY_clock</sub>



Page 20 of 32 Document Number: 001-69402 Rev. \*A

Figure 1. Timing Diagram Without Using Glitch Filtering







Figure 2. Timing Diagram Using Glitch Filtering



#### How to Use STA Results for Characteristics Data

Nominal route maximums are gathered through multiple test passes with Static Timing Analysis (STA). You can calculate the maximums for your designs with the STA results using the following methods:

**f**<sub>CLOCK</sub> Maximum component clock frequency appears in Timing results in the clock summary as the named external clock. The graphic below shows an example of the clock limitations from the *\_timing.html* file:

## -Clock Summary

	_	Max Freq	
BUS_CLK	24.000 MHz	118.683 MHz	
clock	24.000 MHz	56.967 MHz	

### Input Path Delay and Pulse Width


When characterizing the functionality of inputs, all inputs, no matter how you have configured them, look like one of the four possible configurations shown in Figure 3.

All inputs must be synchronized. The synchronization mechanism depends on the source of the input to the component. To fully interpret how your system will work you must understand which input configuration you have set up for each input and the clock configuration of your system. This section describes how to use the Static Timing Analysis (STA) results to determine the characteristics of your system.



Document Number: 001-69402 Rev. \*A

Figure 3. Input Configurations for Component Timing Specifications



Configuration	Component Clock	Synchronizer Clock (Frequency)	Figures
1	master_clock	master_clock	Figure 8
1	clock	master_clock	Figure 6
1	clock	clockX = clock <sup>1</sup>	Figure 4
1	clock	clockX > clock	Figure 5
1	clock	clockX < clock	Figure 7
2	master_clock	master_clock	Figure 8
2	clock	master_clock	Figure 6
3	master_clock	master_clock	Figure 13

<sup>&</sup>lt;sup>1</sup> Clock frequencies are equal but alignment of rising edges is not guaranteed.



Page 24 of 32 Document Number: 001-69402 Rev. \*A

Configuration	Component Clock	Synchronizer Clock (Frequency)	Figures
3	clock	master_clock	Figure 11
3	clock	clockX = clock <sup>1</sup>	Figure 9
3	clock	clockX > clock	Figure 10
3	clock	clockX < clock	Figure 12
4	master_clock	master_clock	Figure 13
4	clock	clock	Figure 9

- The input is driven by a device pin and synchronized internally with a "sync" component. This
  component is clocked using a different internal clock than the clock the component uses (all
  internal clocks are derived from master clock).
  - When characterizing inputs configured in this way clockX may be faster, equal to, or slower than the component clock. It may also be equal to master\_clock, which produces the characterization parameters shown in Figure 4, Figure 5, Figure 7, and Figure 8.
- 2. The input is driven by a device pin and synchronized at the pin using master\_clock. When characterizing inputs configured in this way, master\_clock is faster than or equal to the component clock (it is never slower). This produces the characterization parameters shown in Figure 5 and Figure 8.

Figure 4. Input Configuration 1 and 2; Sync Clock Freq.= Component Clock Frequency (Edge alignment of clock and clockX is not guaranteed)






Figure 5. Input Configuration 1 and 2; Sync. Clock Freq. > Component Clock Frequency





Figure 6. Input Configuration 1 and 2; [Sync. Clock Freq. == master\_clock] > Component Clock Frequency







Figure 7. Input Configuration 1; Sync. Clock Freq. < Component Clock Frequency

Figure 8. Input Configuration 1 and 2; Sync. Clock = Component Clock = master\_clock



- 3. The input is driven by logic internal to the PSoC, which is synchronous based on a clock other than the clock the component uses (all internal clocks are derived from master\_clock). When characterizing inputs configured in this way, the synchronizer clock is faster than, slower than, or equal to the component clock, which produces the characterization parameters shown in Figure 9, Figure 10, and Figure 12.
- 4. The input is driven by logic internal to the PSoC, which is synchronous based on the same clock the component uses.



Document Number: 001-69402 Rev. \*A Page 27 of 32

When characterizing inputs configured in this way, the synchronizer clock will be equal to the component clock, which will produce the characterization parameters as shown in Figure 13.

Figure 9. Input Configuration 3 only; Sync. Clock Freq. = Component Clock Frequency (Edge alignment of clock and clockX is not guaranteed)





Figure 9 represents the extent to which Static Timing Analysis understands the clocks. All clocks in the digital clock domain are synchronous to master\_clock. However, it is possible that two clocks with the same frequency are not rising-edge aligned. Therefore, the static timing analysis tool does not know which edge the clocks are synchronous to and must assume the minimum of one master\_clock cycle. This means that t<sub>PD\_si</sub> now has a limiting effect on master\_clock of the system. master\_clock setup time violations appear if this path delay is too long. You must change the synchronization clocks of your system or run master\_clock at a slower frequency.

Figure 10. Input Configuration 3; Sync. Clock Freq. > Component Clock Frequency





In much the same way as shown in Figure 9, all clocks are derived from master\_clock. STA indicates the  $t_{PD\_si}$  limitations on master\_clock for one master\_clock cycle in this configuration. master\_clock setup time violations appear if this path delay is too long. You must change the synchronization clocks of your system or run the master\_clock at a slower frequency.

Figure 11. Input Configuration 3; Synchronizer Clock Frequency = master\_clock > Component Clock Frequency





Figure 12. Input Configuration 3; Synchronizer Clock Frequency < Component Clock Frequency




In much the same way as shown in Figure 9, all clocks are derived from master\_clock. STA indicates the t<sub>PD\_si</sub> limitations on master\_clock for one master\_clock cycle in this configuration. master\_clock setup time violations appear if this path delay is too long. You must change the synchronization clocks of your system or run master\_clock at a slower frequency.



Document Number: 001-69402 Rev. \*A Page 29 of 32

Figure 13. Input Configuration 4 only; Synchronizer Clock = Component Clock



In all previous figures in this section, the most critical parameters to use when understanding your implementation are  $f_{CLOCK}$  and  $t_{PD\_IE}$ .  $t_{PD\_IE}$  is defined by  $t_{PD\_ps}$  and  $t_{SYNC}$  (for configurations 1 and 2 only),  $t_{PD\_si}$ , and  $t_{I\_Clk}$ . It is crucial to note that  $t_{PD\_si}$  defines the maximum component clock frequency.  $t_{I\_Clk}$  does not come from the STA results but is used to represent when  $t_{PD\_IE}$  is registered. This is the margin left over after the route between the synchronizer and the component clock.

t<sub>PD ps</sub> and t<sub>PD si</sub> are included in the STA results.

To find  $t_{PD\_ps}$ , look at the input setup times defined in the *\_timing.html* file. The fanout of this input may be more than 1 so you will need to evaluate the maximum of these paths.

#### -Setup times

#### -Setup times to clock BUS\_CLK

Start	Register	Clock	Delay (ns)
input1(0):iocell.pad_in	input1(0):iocell.ind	BUS_CLK	16.500

 $t_{PD\_si}$  is defined in the register-to-register times. You will need to know the name of the net to use the *\_timing.html* file. The fanout of this path may be more than 1 so you will need to evaluate the maximum of these paths.



#### -Register-to-register times

#### -Destination clock clock

Destination clock clock (Actual freq: 24.000 MHz)

#### +Source clock clock

#### -Source clock clock\_1

Source clock clock\_1 (Actual freq: 24.000 MHz)
Affected clock: BUS\_CLK (Actual freq: 24.000 MHz)

Start	End	Period (ns)	Max Freq	Frequency V	iolation
\Sync_1:genblk1[0]:INST\:synccell.syncq	\PWM_1:PWMUDB:runmode_enable\:macrocell.mc_d	7.843	127.508 MHz	24.000 MHz	

### **Output Path Delays**

When characterizing the path delays of outputs, you must consider where the output is going in order to know where you can find the data in the STA results. For this component, all outputs are synchronized to the component clock. Outputs fall into one of two categories. The output goes either to another component inside the device, or to a pin to the outside of the device. In the first case, you must look at the register-to-register times shown for the logic-to-input descriptions given previously (the source clock is the component clock). For the second case, you can look at the clock-to-output times in the *\_timing.html* STA results.



Document Number: 001-69402 Rev. \*A Page 31 of 32

# **Component Changes**

This section lists the major changes in the component from the previous version.

Version	Description of Changes	Reason for Changes / Impact		
2.0	Updated block diagram of Quadrature Decoder in the Block Diagram and Configuration section of the datasheet.	For use with the latest version of the Counter component.		
	Updated internal Counter component to version 2.0 on Quadrature Decoder Component schematic.	For use with the latest version of the Counter component.		
	Removed obsolete defines.			
1.50.a	Added characterization data to datasheet			
	Minor datasheet edits and updates			
1.50	Changed QuadDec_Start() API: removed write to Control Register.	Beta5 STA-Based Optimization.		
	Added QuadDec_Sleep()/ QuadDec_Wakeup() APIs.	Added APIs to support the low power modes.		
	Added QuadDec_Init() API.	Added to provide an API to initialize/restore the component without starting it.		
1.20	Updated the Configure dialog.  Removed the QuadDec_INT.c file after compilation if the counter size is less than 32.			
	Removed the checking condition in the QuadDec_INT.c file for counter size = 32 bit.			

© Cypress Semiconductor Corporation, 2011. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

PSoC® is a registered trademark, and PSoC Creator™ and Programmable System-on-Chip™ are trademarks and of Cypress Semiconductor Corp. All other trademarks or registered trademarks referenced herein are property of the respective corporations.

Any Source Code (software and/or firmware) is owned by Cypress Semiconductor Corporation (Cypress) and is protected by and subject to worldwide patent protection (United States and foreign), United States copyright laws and international treaty provisions. Cypress hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use, modify, create derivative works of, and compile the Cypress Source Code and derivative works for the sole purpose of creating custom software and or firmware in support of licensee product to be used only in conjunction with a Cypress integrated circuit as specified in the applicable agreement. Any reproduction, modification, translation, compilation, or representation of this Source Code except as specified above is prohibited without the express written permission of Cypress.

Disclaimer: CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes without further notice to the materials described herein. Cypress does not assume any liability arising out of the application or use of any product or circuit described herein. Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress' product in a life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Use may be limited by and subject to the applicable Cypress software license agreement.



Page 32 of 32 Document Number: 001-69402 Rev. \*A