



WIRING. CLAP DECAY



1. SOLDER WIRES FROM PIN1 AND PIN2(EXT MOD BOARD) TO C59(MAIN BOARD*)


*VOICING BOARD

WIRING. BASS DRUM DRIVE



*VOICING BOARD

WIRING. BASS DRUM 2X DECAY



*VOICING BOARD

WIRING. HI-HAT PITCH

