

PL vs AIE — attention block summary (VC1902, PL @ 200 MHz / AIE @ 1.25 GHz)

block	PL err	AIE err	PL μ s/evt	AIE fill μ s	AIE Δ_{ss} μ s	AIE vs PL (steady)	AIE N	PL LUT	PL DSP	AIE tiles
obj	0.0293	0.0276	101.9	497.0	318.8	3.13× slower	98	100,217	146	13
cand	0.0137	0.0110	23.4	56.3	14.4	1.62× faster	98	96,571	137	13
cross	0.0605	0.0562	75.8	235.5	91.9	1.21× slower	98	97,565	169	13
Total	—	—	201.1	788.8	425.1	2.11× slower	—	294,353	452	39