

 $q_{\text{tot}} = q_{\text{walls}} + q_{\text{windows}} + q_{\text{ceiling}} + q_{\text{floor}} + q_{\text{doors}} + q_{\text{infiltration}}$