These instruction found at the One For All(OFA) web site. https://websupport.uei.com/?lang=en

URC 6540 Audio Zapper

Brand: AVI Model: S21MI Device key: MD

Result:

OFA Audio Zapper (6540)

AVI S21MI (Device Key: MD)

Try the following code(s) in order, until your Universal Remote Control works properly for your device. See below for instructions on how to program a code into your remote.

121142	Fully 🗖	Partially	Not at all	Not tried
132414	Fully 🖸	Partially	Not at all	Not tried

Setup Instructions for AVI S21 MI (option 1):

- 1. Press the relevant *DEVICE* key, (press MD)
- 2. Press and hold down the *MAGIC* (or *SETUP*) key until the light blinks twice (the light will blink once then twice).
- 3. Enter the setup code according to the chart below (the light will blink twice at the end).
- 4. Enter a 1, (press VOLUME UP)
- 5. Enter a 2, (press VOLUME DOWN)
- 6. Enter a 1, (press VOLUME UP)
- 7. Enter a 1, (press VOLUME UP)
- 8. Enter a 4, (press TRACK DOWN)
- 9. Enter a 2, (press VOLUME DOWN)

Setup Instructions for AVI S21 MI (option 2):

- 1. Press the relevant *DEVICE* key, (press MD)
- 2. Press and hold down the *MAGIC* (or *SETUP*) key until the light blinks twice (the light will blink once then twice).
- 3. Enter the setup code according to the chart below (the light will blink twice at the end).
- 4. Enter a 1, (press VOLUME UP)
- 5. Enter a 3, (press TRACK UP)
- 6. Enter a 2, (press VOLUME DOWN)
- 7. Enter a 4, (press TRACK DOWN)
- 8. Enter a 1, (press VOLUME UP)
- 9. Enter a 4, (press TRACK DOWN)
- 1 = VOLUME UP
- 2 = VOLUME DOWN
- 3 = TRACK UP
- 4 = TRACK DOWN

