## Audi AAN ightarrow 3B ightarrow B3 7A Repin & Conversion Guide

Rev 2 — October 31 2025 • Compiled by Andrew Schlueter • MIT License

This guide explains converting an Audi AAN harness to operate a 3B ECU in a B3 7A chassis. Includes ECU pin mappings, connector integration, and diagnostic wiring.

## **Representative Pin Mapping**

```
18 | RT | +12V Batt (30) \rightarrow Batt (30) | No Move | T6a | Fuse 30
27 | SW/GN | +12V IGN (15) \rightarrow IGN (15) | No Move | T6a | Ign sw
37 | SW/RT | +12V inj/MAF \rightarrow J271 feed | No Move | T6a | Relay
                         → Ground | No Move | T6b | Chassis
10 | BR | Ground
3 | BR/GE | Fuel Pump Relay → J17 coil | No Move | T6a | Fuel pump
47 | VI | G4 Ref
                       \rightarrow G4
                                  | No Move | Engine | —
49 | GR | G28 RPM
                           \rightarrow G28
                                       | No Move | Engine | —
8 | GR/RT | Cam G40
                            \rightarrow G40
                                        | No Move | Engine | —
                           \rightarrow G42
                                       | No Move | Engine | —
44 | BR/BL | IAT G42
                            \rightarrow G62
                                         | No Move | Engine | —
45 | GR/BR | CLT G62
                                        | No Move | Engine | —
11 | GN/GN | Knock1
                            \rightarrow G61
29 | WS/WS | Knock2
                            \rightarrow G66
                                        | No Move | Engine | —
                            \rightarrow G70
                                         | No Move | T8a | Cluster
7 | GN/WS | MAF Signal
25 | GN/VI | MAF Burn-off \rightarrow —
                                        |Remove |-- |--
                            \rightarrow F60
52 | WS/GR | TPS Idle
                                        | Rewire | T8b | HVAC
                             \rightarrow F96
54 | RT/WS | TPS WOT
                                         | Rewire | T8b | HVAC
55 | BR/GE | TPS GND
                             \rightarrow GND
                                          | Verify | T8b | HVAC
53 | WS/GE | TPS Pot
                            \rightarrow —
                                       |Remove |-- |--
1 | — | COP1
                        → N124 trig | Repurpose | T6a | N124
22 | WS/BL | MIL Lamp
                            \to \mathsf{MIL}
                                        | No Move | T8a | Cluster
```

## Diagnostics (2×2) and MIL Lamp

White 2-pin pin 1: K-line (WS) — Diagnostics White 2-pin pin 2: L-line (GR) — Optional

Black 2-pin pin 1: +12V IGN (SW) — From fuse Black 2-pin pin 2: Ground (BR) — Body ground MIL pin —: ECU Pin 22 (WS/BL) — MIL bulb

## **Sources & References**

- Audi AG AAN/3B diagrams
- Bentley Audi 80/90/CQ manuals
- S2Central / S2Forum archives
- Audi ELSAWin docs