

Lecture 32: The Front End of the Fuel Cycle

CBE 30235: Introduction to Nuclear Engineering — D. T. Leighton

April 8, 2026

Introduction

The "Front End" encompasses every step required to take Uranium from the earth's crust and turn it into a precision-engineered fuel assembly ready for the reactor core.

1. **Mining/Milling:** Getting the ore out of the ground (U_3O_8).
2. **Conversion:** Turning solid rock into gas (UF_6).
3. **Enrichment:** Increasing the U-235 fraction.
4. **Fabrication:** Turning gas back into solid ceramic pellets (UO_2) and loading rods.

1 Step 1: The Resource Base

1.1 Abundance and "Running Out"

Is Uranium rare? No. It is more common in the Earth's crust than Tin, Silver, or Mercury.

- **Crustal Average:** ≈ 2.8 parts per million (ppm).
- **Granite:** Standard granite rocks contain $\approx 4 - 5$ ppm Uranium. (Your granite countertop is slightly radioactive).

1.1.1 The Concept of Reserves

Students often confuse "Reserves" (economically recoverable at current prices) with "Resources" (what is physically there).

- **Identified Resources:** ≈ 8 Million Tonnes (at $< \$260/\text{kgU}$ cost).
- **Current Consumption:** $\approx 60,000$ Tonnes/year globally.
- **Static Lifespan:** At current rates, known mines last ≈ 130 years.
- **Dynamic Reality:** As price increases, lower grade ores become economic. If the price of Uranium doubles, the "Reserves" essentially quadruple. Because fuel cost is a tiny fraction of nuclear electricity cost ($\approx 5\%$), the industry can absorb high fuel prices that would bankrupt a coal or gas plant.

1.2 Ore Grades

The concentration of Uranium varies wildly by geology.

Mine Location	Type	Ore Grade (% U)
Cigar Lake (Canada)	High Grade Underground	$\approx 15.0 - 20.0\%$
Ranger (Australia)	Open Pit	$\approx 0.1 - 0.2\%$
Rössing (Namibia)	Low Grade Granite	$\approx 0.03\%$

Table 1: The disparity in ore quality. Canadian mines are so rich the workers must be shielded from the raw rock.

1.3 The "Backstop": Seawater Extraction

The oceans contain a vast, dilute suspension of Uranium.

- **Concentration:** ≈ 3.3 ppb (parts per billion).
- **Total Inventory:** ≈ 4.5 Billion Tonnes. (Enough for thousands of years).
- **The Method:** Passive adsorption.
 - *Polymer Braids:* Polyethylene fibers grafted with **amidoxime** groups are moored in ocean currents.
 - The amidoxime chelation groups selectively bind Uranyl ions (UO_2^{2+}).
 - Braids are hauled up after weeks, eluted with acid to strip the Uranium, and reused.
- **Economics:** Currently estimated at \$300 – \$600 per kg (3-6x current mining costs), but recent PNNL/ORNL research has improved capacity significantly.
- **Strategic Value:** Even if never used, seawater sets a **price ceiling**. Uranium can never cost more than the seawater extraction price, effectively making the fuel supply "infinite" in economic terms.

2 Step 2: Mining Techniques

2.1 Conventional Mining (Open Pit & Underground)

The legacy methods of open pit and underground mining still produce roughly half of the world's uranium. The choice between these methods depends entirely on the depth and grade of the ore body (e.g., Canada's Athabasca Basin features extremely high-grade ore deep underground, while Namibia utilizes massive open pits for lower-grade surface ore).

The conventional extraction process follows four main chemical engineering steps:

1. **Extraction & Comminution:** The uranium-bearing rock is physically mined, brought to the surface, and fed into a mill. It is crushed and ground into a fine slurry (resembling fine sand or mud) to maximize the surface area for chemical extraction.
2. **Leaching:** The slurry is treated with a leaching agent to dissolve the uranium out of the host rock.
 - **Acid Leaching:** The most common method. Strong sulfuric acid (H_2SO_4) is used, often combined with an oxidant like hydrogen peroxide, to dissolve the uranium.

- **Alkaline Leaching:** If the host rock has high levels of limestone or calcium carbonate (which would neutralize and waste massive amounts of acid), a sodium carbonate/bicarbonate solution is used instead.
- 3. **Separation & Precipitation:** The uranium-rich liquid is separated from the barren rock solids. The dissolved uranium is then concentrated using ion exchange or solvent extraction, and precipitated out using ammonia or sodium hydroxide.
- 4. **Calcining (Yellowcake):** The precipitate is filtered, dried, and sometimes baked (calcined) to produce a stable uranium oxide powder (U_3O_8), universally referred to as **Yellowcake** (though modern high-temperature drying often turns it green or black).

The Environmental Challenge (Tailings): The defining characteristic of conventional mining is the massive volume of physical waste. Because commercial uranium ore grades are often between 0.1% and 1%, over 99% of the mined rock is left over after milling. This finely ground, acidic rock sludge—known as **tailings**—contains heavy metals and most of the original radioactive decay products of uranium (like Radium-226 and Thorium-230). Managing these tailings safely in engineered, heavily monitored dams to prevent groundwater contamination is the primary environmental and economic burden of conventional uranium mining.

2.2 In-Situ Leaching (ISL) or In-Situ Recovery (ISR)

Today, over 50% of global uranium is mined without digging a physical hole. ISL is used primarily in "roll-front" uranium deposits located in porous sandstone aquifers, typically at depths of **100 to 500 meters**.

2.2.1 The Chemistry of ISL

Uranium in deep, undisturbed ores exists in a reduced state (U^{4+}), primarily as the mineral uraninite (UO_2). In this state, it is virtually insoluble in water. To extract it, we must manipulate its oxidation state.

1. **Injection:** A leaching solution (the *lixiviant*) is pumped down injection wells into the aquifer.
2. **Oxidation:** The lixiviant contains an oxidant (usually Oxygen gas, O_2 , or Hydrogen Peroxide, H_2O_2). This oxidizes the insoluble U^{4+} into the highly soluble U^{6+} (the uranyl ion, UO_2^{2+}).
3. **Complexation:** To keep the uranyl ion dissolved in the groundwater and prevent it from precipitating out, a complexing agent is added.
 - *Acidic Leaching (e.g., Australia, Kazakhstan):* Sulfuric acid (H_2SO_4) is used. It is fast and highly efficient but harsh on the host rock.
 - *Alkaline Leaching (e.g., USA):* Sodium bicarbonate ($NaHCO_3$) is used if the host rock contains high levels of limestone (which would neutralize acid).
4. **Extraction:** The uranium-rich fluid is drawn up through a central production well, and the uranium is stripped out at a surface facility using Ion Exchange (IX) resins.

2.2.2 Environmental Downsides and Mitigation

While ISL leaves no open pits or radioactive tailings piles on the surface, the environmental battleground is entirely subterranean.

- **Excursions:** The primary risk is that the lixiviant "escapes" the wellfield and contaminates adjacent, clean drinking water aquifers. To prevent this, operators must constantly pump out slightly *more* water than they inject, creating a localized pressure sink that draws groundwater inward.
- **Heavy Metal Mobilization:** The oxidation process does not just dissolve uranium; it actively dissolves heavy metal contaminants trapped in the rock, such as Arsenic, Selenium, and Lead.
- **Aquifer Restoration:** Once mining is complete, the aquifer must be restored. This requires pumping the groundwater through massive surface Reverse Osmosis (RO) plants for years, and often injecting chemical reductants (like hydrogen sulfide) to return the deep aquifer to its natural, reducing state so remaining heavy metals lock back into the rock.

3 Step 3: Conversion ($U_3O_8 \rightarrow UF_6$)


To enrich uranium, we need it in gas form. The only stable gas of uranium is Uranium Hexafluoride (UF_6). This conversion is a multi-step chemical process.

3.1 The Chemistry


1. **Reduction ($U_3O_8 \rightarrow UO_2$):** Yellowcake (U_3O_8) is heated to $\approx 600^\circ\text{C}$ in a kiln with Hydrogen gas (H_2). The hydrogen chemically strips oxygen from the uranium, converting the powder from yellow/brown to black Uranium Dioxide (UO_2).



2. **Hydrofluorination ($UO_2 \rightarrow UF_4$):** The UO_2 powder is reacted with anhydrous Hydrofluoric Acid (HF) to form "**Green Salt**" (UF_4).




3. **Fluorination ($UF_4 \rightarrow UF_6$):** Finally, the Green Salt reacts with expensive elemental Fluorine gas (F_2) in a fluidized bed reactor to create the final product.



3.2 Properties and Hazards

- **Phase:** UF_6 is solid at room temperature but **sublimes** (turns directly to gas) at 56°C .
- **The HF Hazard:** If UF_6 touches moist air, it hydrolyzes instantly:



This creates a cloud of Hydrofluoric Acid (HF), which is chemically lethal to lung tissue even at low concentrations.

4 Step 4: Enrichment

Natural Uranium is 0.71% U-235. LWRs need 3.0 – 5.0% (LEU). We must separate isotopes based solely on their tiny mass difference (^{238}U is 1.2% heavier than ^{235}U).

4.1 Separative Work Units (SWU)

Enrichment is sold in "SWUs" (units of effort), not strictly by mass. The SWU required depends heavily on the economic balance between the cost of raw uranium and the cost of the electrical energy used to enrich it.

To calculate the SWU required for a given batch of fuel, we must first define the three streams of the enrichment cascade:

- **Product (P):** The mass of the enriched uranium (with enrichment mass fraction x_p).
- **Feed (F):** The mass of the natural uranium input (with enrichment mass fraction $x_f \approx 0.00711$).
- **Tails (T):** The mass of the depleted uranium waste (with enrichment mass fraction x_t , typically 0.002 – 0.003).

1. Mass and Isotope Balances

Before calculating the effort (SWU), we must calculate the mass of Feed and Tails required to produce a specific mass of Product. We use standard steady-state mass balances:

Overall Mass Balance:

$$F = P + T$$

Isotope (U-235) Mass Balance:

$$F x_f = P x_p + T x_t$$

By rearranging these, we can find the Feed-to-Product ratio (F/P) and the Tails-to-Product ratio (T/P) required for our desired enrichment:

$$\frac{F}{P} = \frac{x_p - x_t}{x_f - x_t} \quad \text{and} \quad \frac{T}{P} = \frac{x_p - x_f}{x_f - x_t}$$

2. The Value Function and Total SWU

The thermodynamic effort required to change the concentration of an isotope stream is defined by the **Value Function**, $V(x)$. The value function can be interpreted as a measure of how "difficult" it is to separate a mixture at concentration x ; streams near 0 or 1 are much more "valuable" than those near natural abundance. For any mass stream with an isotopic fraction x , its separation value is:

$$V(x) = (2x - 1) \ln \left(\frac{x}{1 - x} \right)$$

The total Separative Work (SWU) is simply the "value" of the outgoing streams minus the "value" of the incoming feed stream:

$$SWU = P \cdot V(x_p) + T \cdot V(x_t) - F \cdot V(x_f)$$

SWU has units of mass (typically kg-SWU), but represents an abstract measure of separative effort rather than physical work in the thermodynamic sense.

Engineering Economics Note: The Tails Assay (x_t) is an optimization variable. If raw mined uranium (F) is cheap but enrichment electricity (SWU) is expensive, you run a high tails assay (e.g., 0.30%), using more feed but less machine effort. If uranium is expensive but enrichment is cheap, you "squeeze" the feed harder, running a low tails assay (e.g., 0.15%) to get every last atom of U-235 out of the raw material.

4.2 Enrichment Methods

4.2.1 Gaseous Diffusion (The Manhattan Project Era)

- Force gas through porous membranes. Lighter U-235 moves slightly faster.
- *Efficiency:* Terrible. Requires thousands of stages. The Paducah, KY plant used to consume the electricity of a small country. It has been estimated that 7% of total US electricity demand was from enrichment plants at the height of the Cold War, when 90% U-235 was required, rather than the reactor grades of 3-4% for power generation. These plants have all been retired.

4.2.2 Gas Centrifuge Mechanics (The Current Standard)

The standard method for modern enrichment is the Zippe-type gas centrifuge. It is a marvel of extreme rotational physics and materials science.

- **The Physics of Separation:** UF_6 gas is fed into a vertical cylindrical rotor spinning in a vacuum at supersonic speeds (often $> 90,000$ RPM). The centrifugal force pushes the heavier $^{238}UF_6$ molecules toward the outer wall, leaving a slightly higher concentration of the lighter $^{235}UF_6$ near the central axis.
- **Counter-Current Flow:** Simple radial separation is not enough. A small thermal gradient is applied (the bottom of the cylinder is heated, the top is cooled). This creates a convection current. The gas flows downward along the outer wall (carrying U-238) and upward along the center (carrying U-235). Stationary mechanical "scoops" at the top and bottom collect the enriched and depleted streams.
- **Material Limits:** The separation efficiency of a centrifuge scales with the *square* of the wall velocity (v^2). Therefore, engineers want to spin them as fast as physically possible.
 - Early rotors used aluminum or maraging steel, which would literally tear themselves apart from the centripetal stress at higher speeds.
 - Modern rotors are constructed from high-tensile **Carbon Fiber**. The outer wall of a modern centrifuge is traveling at over Mach 2.
- **Cascades:** A single centrifuge performs very little separation (perhaps increasing enrichment from 0.71% to 0.85%). To reach reactor-grade 4.0%, hundreds of centrifuges must be piped together in series (to increase enrichment purity) and in parallel (to handle mass volume). This arrangement is called a **Cascade**. Uses $50\times$ less energy than diffusion.

4.2.3 Laser Enrichment (SILEX / GLE)

The future of enrichment lies in Separation of Isotopes by Laser Excitation (SILEX), a **molecular** laser process currently being commercialized as Global Laser Enrichment (GLE).

- **The Physics:** Due to the slight mass difference, the chemical bonds in $^{235}\text{UF}_6$ vibrate at a very slightly different frequency than $^{238}\text{UF}_6$ (known as the "isotope shift").
- **The Process (Photo-dissociation):** A highly precise, tunable laser is fired into a cold stream of UF_6 gas. The laser is tuned to the exact absorption frequency of the $^{235}\text{UF}_6$ molecules, selectively exciting them without affecting the $^{238}\text{UF}_6$.
 - This excitation breaks the molecular bond, stripping away one fluorine atom to convert the $^{235}\text{UF}_6$ gas into ionized **solid** UF_5^+ .
 - Because the ^{235}U is now locked in a solid precipitate, it can be easily mechanically or electromagnetically separated from the unaffected $^{238}\text{UF}_6$ gas.
 - *Why this matters:* Older "atomic" laser techniques (like AVLIS) required vaporizing raw uranium metal at extreme temperatures. SILEX became the industry standard because it uses the exact same UF_6 gas used by the rest of the conventional fuel cycle.
- **Efficiency & Licensing:** It is vastly more efficient than centrifuges, requiring a fraction of the stages and energy to achieve reactor-grade enrichment. GLE's planned commercial facility is currently licensed to enrich up to 8% U-235, with explicit plans to expand to nearly 20% to supply the critical **HALEU** market.
- **The Proliferation Concern (Stealth):** The primary danger of laser enrichment is not just that it is "easy," but that it is **invisible**. Gaseous diffusion plants were the size of small cities. Centrifuge cascades require massive warehouse facilities and distinct thermal/electrical signatures. A SILEX facility could theoretically be hidden inside a standard commercial warehouse with a negligible footprint, making clandestine, weapons-grade enrichment operations incredibly difficult for the IAEA to detect via satellite imagery or power grid monitoring.

5 Step 5: Fabrication

Once the enriched UF_6 gas (or HALEU/LEU+) arrives at the fuel fabrication plant, the physical manufacturing process diverges entirely based on the target reactor type. There are three primary geometries of nuclear fuel used in modern and advanced reactors:

5.1 Ceramic Oxide Fuel (LWRs & MOX)

This is the standard fuel form for the current global fleet of Light Water Reactors.

1. **Re-conversion:** UF_6 is reacted with steam and hydrogen to produce **Uranium Dioxide (UO_2) powder**.
2. **Sintering & Pellet Engineering:** The black powder is pressed into small cylinders and baked at roughly 1700°C . The result is a high-density ceramic pellet. Students often picture fuel pellets as perfect, flat-faced cylinders, but this geometry would cause the fuel rod to fail during reactor operation. The UO_2 ceramic pellets are precisely engineered with two key geometric features:

- **Dishing:** The top and bottom faces of the pellet are slightly concave (a shallow dimple). Because the center of the pellet gets much hotter than the outside ($\approx 1000^\circ\text{C}$ difference), the center expands more. The "dish" provides void space for the hot center of the ceramic to expand into. Without it, the pellet would bulge outward like a barrel and violently stretch the cladding.
 - **Chamfering:** The sharp outer edges of the cylinders are beveled or rounded off. This prevents the sharp ceramic corners from chipping during robotic loading, and prevents the edges from digging into the cladding wall as the fuel swells over its 5-year life in the core (mitigating Pellet-Cladding Interaction, or PCI).
3. **Mixed Oxide (MOX) Variant:** In countries that recycle fuel (like France), Plutonium Dioxide (PuO_2) is blended with the UO_2 powder. The physical geometry is identical to standard LWR fuel, but fabrication requires heavy shielding and automation due to plutonium's high radiotoxicity.
 4. **Rod Loading & Assembly:** Pellets are stacked into Zircaloy tubes (≈ 12 ft long). A "plenum" spring is added at the top to leave space for fission gases, and the rod is pressurized with Helium to improve heat transfer. Rods are then bundled into square lattices (e.g., 17×17 for PWRs) with space for control rods.

5.2 Solid Metal Fuel (Sodium Fast Reactors)

Advanced fast-spectrum reactors (like TerraPower's Natrium or the historic EBR-II) require much higher fissile densities, making ceramic oxides less ideal. Instead, they use solid metal alloy fuels.

1. **Alloying & Casting:** Uranium is alloyed with another metal (typically Zirconium, e.g., U-10Zr) to increase its melting point and dimensional stability. The molten metal is cast directly into solid cylindrical "slugs" rather than being pressed from powder.
2. **The Swelling Challenge (Smear Density):** Metal fuel retains heat excellently, but it swells significantly more than ceramics because fission gas bubbles become trapped in the metal matrix. To prevent the swelling metal from bursting the fuel pin, the slugs are manufactured with a smaller diameter than the cladding tube (a "smear density" of about 75%), leaving a large gap for the metal to safely expand into over its lifetime.
3. **The Sodium Bond:** Because a large physical gap would act as a thermal insulator and cause the metal fuel to melt, the gap between the metal slug and the stainless steel cladding is filled with **liquid sodium**. This sodium bond ensures excellent thermal conductivity from the fuel to the coolant.

5.3 TRISO Particle Fuel (High-Temperature Gas Reactors)

High-Temperature Gas Reactors (HTGRs) and many microreactors use completely different containment philosophies. Instead of relying on a large Zircaloy metal tube to contain the radioactive fission products, the containment is engineered directly into microscopic layers around the fuel itself.

1. **The TRISO Particle:** TRi-structural ISOtropic (TRISO) fuel consists of a tiny kernel of uranium fuel (usually Uranium Oxycarbide, UCO, or UO_2) smaller than a poppy seed.

2. **The Micro-Containment Layers:** This kernel is encapsulated in four distinct protective layers:

- **Porous Carbon Buffer:** A spongy inner layer that absorbs the physical swelling of the fuel kernel and provides space for fission gases to collect.
- **Inner Pyrolytic Carbon (IPyC):** Seals the buffer and protects the structural layer from chemical attack.
- **Silicon Carbide (SiC):** The critical structural layer. This acts as a microscopic pressure vessel, retaining essentially all radioactive fission products even at extreme core temperatures exceeding 1600°C.
- **Outer Pyrolytic Carbon (OPyC):** Protects the SiC layer from environmental degradation and provides a surface for bonding.

3. **Macroscopic Forms:** These sub-millimeter TRISO particles are incredibly robust. For reactor loading, tens of thousands of them are mixed with graphite and pressed into larger macroscopic shapes—either billiard-ball-sized spheres (“pebbles” for Pebble Bed Reactors) or cylindrical compacts inserted into large graphite blocks (for Prismatic cores).

6 Strategic Look: The HALEU Bottleneck

Current Light Water Reactors (LWRs) use LEU enriched to $\approx 3.0 - 5.0\%$. However, the future of the industry depends on a higher grade of fuel.

6.1 Who Needs HALEU and Why?

HALEU (High Assay Low Enriched Uranium) is enriched between **5% and 20%** U-235. It is the critical enabling technology for advanced (Gen IV) reactors.

- **The Customers:** High-Temperature Gas Reactors (e.g., X-energy, which packages it into TRISO particles), Sodium-Cooled Fast Reactors (e.g., TerraPower’s Natrium), and various commercial microreactors (e.g., Oklo, Radiant).
- **The Engineering Benefit:** The higher U-235 concentration allows for smaller reactor cores, significantly higher power densities, and much longer fuel cycles (some Gen IV designs are designed to run for 10–20 years without ever needing to refuel).

6.2 The Supply Chain Crisis

Until recently, the only commercial supplier of HALEU in the world was TENEX (a subsidiary of Russia’s Rosatom). Due to geopolitical shifts and subsequent Western bans on Russian uranium imports, advanced reactor startups have been left with almost no commercial fuel supply. This lack of fuel is currently the single largest bottleneck for Gen IV deployment.

6.3 Pathways to HALEU Availability

The West is frantically scrambling to rebuild a domestic HALEU supply chain from scratch. The recovery is split into two distinct phases:

6.3.1 Phase 1: The Short-Term Fix (Government Stockpiles)

To keep near-term demonstration reactors on schedule for the late 2020s, startups are relying almost entirely on the U.S. Department of Energy (DOE).

- **Downblending HEU:** The DOE is taking Highly Enriched Uranium (HEU) from defense stockpiles and "downblending" it with natural or depleted uranium to reach HALEU concentrations.
- **The LEU+ Pivot:** Because HALEU is so scarce, some reactor designers are tweaking their initial cores to run on **LEU+** (uranium enriched up to 10%), which is legally and technically easier to produce with existing infrastructure than 19.75% HALEU.

6.3.2 Phase 2: Commercial Production (Centrifuge Reliance)

For long-term commercial viability in the 2030s, massive new enrichment capacity is required. Currently, **all commercial HALEU scale-up is relying on established Gas Centrifuge technology**, as laser enrichment (SILEX) is prioritizing standard LEU for its initial commercial rollout.

- **Centrus Energy (USA):** Operates the only domestic HALEU cascade at a plant in Piketon, Ohio. It is currently a pilot-scale facility delivering small batches of HALEU to the DOE, but Centrus is actively working to scale this up to a full commercial cascade.
- **Urenco (Europe/USA):** The Western enrichment giant is expanding its existing gas centrifuge facilities (including its site in Eunice, New Mexico) to produce both LEU+ and HALEU for the commercial market.
- **Orano (France):** The French nuclear conglomerate recently announced plans to build a multi-billion-dollar centrifuge enrichment facility in the U.S. specifically to help supply the advanced reactor market.
- **Government Subsidies:** The DOE has allocated billions of dollars in recent years to guarantee contracts for these companies, essentially de-risking the massive capital required to build these new centrifuge cascades.

Where Things Are Going: The Commercialization of SILEX

While Gas Centrifuges are the current global standard, the future of the "Front End" is moving toward **Separation of Isotopes by Laser Excitation (SILEX)**. Commercialized by Global Laser Enrichment (GLE)—a joint venture between Australia's Silex Systems and Canada's Cameco—this technology is on the threshold of disrupting the nuclear fuel market. **The Energy Economics (kWh per SWU):**

- *Gaseous Diffusion (Gen I)*: $\approx 2,400 - 3,000$ kWh/SWU (Massive energy drain).
- *Gas Centrifuge (Gen II)*: $\approx 50 - 60$ kWh/SWU (The current standard).
- *SILEX (Gen III)*: Exact numbers are highly classified, but industry estimates suggest laser enrichment is **1.6 to 16 times more energy-efficient** than modern centrifuges. Because lasers selectively excite only the $^{235}\text{UF}_6$ molecules rather than applying brute-force kinetic energy to spin the entire gas mass, both power consumption and cascade footprint are drastically reduced.

Commercial Status (The Paducah Project): SILEX is not yet available on the open market, but the infrastructure is actively being built. In late 2025, GLE successfully completed a commercial-scale pilot demonstration (reaching Technology Readiness Level 6) in Wilmington, North Carolina.

Their first full-scale commercial target is the **Paducah Laser Enrichment Facility (PLEF)** in Kentucky, slated to open around **2030**. Interestingly, GLE's first act will not be enriching freshly mined uranium. Because SILEX is so remarkably efficient, they plan to "re-enrich" over 200,000 metric tons of depleted uranium (DU) "tails" left over from the obsolete Paducah gaseous diffusion plant. By squeezing the last trace amounts of U-235 out of this nuclear waste, GLE is essentially creating a massive, new uranium "mine" entirely above ground!

Enrichment Limits & The Path to HALEU: Physically, there is no limit to how high SILEX can enrich uranium. Because of its extremely high separation factor, a laser facility could easily and efficiently reach highly enriched, weapons-grade levels. However, to avoid immense regulatory costs and non-proliferation pushback, GLE is currently strictly focused on producing standard LEU (up to 5%) to feed the existing commercial reactor fleet. Expanding production to the 5%–20% **HALEU** required by next-generation advanced reactors is officially designated as "Phase 3" of their commercialization strategy.

References

- Lamarsh, J.R. & Baratta, A.J., *Introduction to Nuclear Engineering*. Section 4.6 (Nuclear Fuel Cycles).
- **Seawater Extraction:**
 - *D Chen et al. ACS Central Science: "Self-Standing Porous Aromatic Framework Electrodes for Efficient Electrochemical Uranium Extraction"* (Technical article describing an extraction method).
<https://pubs.acs.org/doi/full/10.1021/acscentsci.3c01291>

- *Kim Forsman blog*: "Energy Economics of Uranium Extraction from Seawater." (Analysis of the economics of seawater extraction).

<https://kimforsman.com/energy-economics-of-uranium-extraction-from-seawater>

- **Global Resources ("The Red Book"):**

- *OECD Nuclear Energy Agency*: "Uranium 2022: Resources, Production and Demand." (The industry bible for supply stats).

https://www.oecd-neo.org/jcms/pl_79960/uranium-2022-resources-production-and-demand-r

- **Mining Tech:**

- *World Nuclear Association*: "In Situ Leach Mining of Uranium."

<https://world-nuclear.org/information-library/nuclear-fuel-cycle/mining-of-uranium/in-situ-leach-mining-of-uranium.aspx>

- **Enrichment:**

- *Wikipedia*: "Enriched Uranium."

https://en.wikipedia.org/wiki/Enriched_uranium

- **Laser Enrichment (SILEX & GLE):**

- *World Nuclear Association*: "Uranium Enrichment." (An industry-standard, comprehensive overview of the physics of both gas centrifuges and laser enrichment, including the SILEX process).

<https://world-nuclear.org/information-library/nuclear-fuel-cycle/conversion-enrichment/uranium-enrichment.aspx>

- *Silex Systems Limited*: "The SILEX Technology." (The official technical descriptions and commercialization roadmap from the Australian developers of the process).

<https://www.silex.com.au/silex-technology/silex-uranium-enrichment-technology/>