

Lecture 30: Liquid Metal Fast Reactors (LMFR)

Physics, Engineering, and History

CBE 30235: Introduction to Nuclear Engineering — D. T. Leighton

March 30, 2026

1 Introduction: The Fast Spectrum Trade-Off

In previous lectures, we explored thermal reactors (PWRs, BWRs, HTGRs) that rely on moderators to slow neutrons down to thermal energies (≈ 0.025 eV), where the fission cross-section of ^{235}U is massive.

Liquid Metal Fast Reactors (LMFRs) abandon the moderator entirely. They operate using "fast" neutrons (in the MeV range). Because the fission cross-section collapses at high energies, maintaining a chain reaction requires heavily enriched fuel packed into a highly compact core. To remove massive amounts of heat from a very small volume without moderating the neutrons, water cannot be used. Instead, engineers turn to liquid metals: primarily **Sodium (Na)** or **Lead-Bismuth Eutectic (LBE)**.

2 The Physics of the Fast Spectrum

1. **Cross-Section Collapse and Breeding (η):** At thermal energies, σ_f for ^{235}U is ≈ 585 barns. At fast energies (1 MeV), σ_f drops to $\approx 1 - 2$ barns. So why struggle with high energies? The answer lies in η (neutrons produced per neutron absorbed in fuel).
 - For ^{239}Pu at thermal energy: $\eta \approx 2.1$.
 - For ^{239}Pu at fast energy: $\eta \approx 2.9$.

The Breeding Ratio: With nearly 3 neutrons produced per fission, we use 1 neutron to continue the chain reaction, and we have nearly 2 left over to capture in ^{238}U "blankets" to breed *more* plutonium than the reactor consumes.

2. **Actinide Burning and the Capture-to-Fission Ratio (α):** In a thermal reactor, we care strictly about *fissile* isotopes (like ^{235}U and ^{239}Pu) that fission at low energies. In a fast spectrum, however, the neutron energy is so high that it crosses the threshold to make practically *all* actinides *fissionable*.
 - **Reduced Parasitic Capture:** In a thermal reactor, ^{239}Pu has a significant chance of capturing a neutron and turning into ^{240}Pu , a non-fissile parasitic absorber. In a fast spectrum, the capture-to-fission ratio ($\alpha = \sigma_c/\sigma_f$) drops dramatically. ^{239}Pu is far more likely to simply fission than step up the actinide chain.
 - **Incinerating Nuclear Waste:** Because of this threshold shift, "waste" actinides that would poison a thermal core—such as ^{238}U , ^{240}Pu , Americium (^{241}Am), and Curium

(^{244}Cm)—can be burned as fuel. This allows fast reactors to be loaded with spent fuel from thermal reactors, transmuting highly toxic, long-lived minor actinides (which require 100,000-year geologic storage) into much shorter-lived fission products.

3. **Kinetics and the Delayed Neutron Fraction (β):** Controlling a reactor relies on the fraction of delayed neutrons (β) to provide a buffer against prompt criticality.

- In a standard thermal reactor, ^{235}U provides a comfortable $\beta \approx 0.0065$ (0.65%).
- Fast reactors, however, run primarily on Plutonium. The delayed neutron fraction for ^{239}Pu is a much lower $\beta \approx 0.0021$ (0.21%).
- *The ^{238}U Effect:* Fast cores contain a large matrix of ^{238}U . Because the neutron spectrum is highly energetic (> 1 MeV), ^{238}U undergoes direct fast fission. Remarkably, ^{238}U has a very high delayed neutron fraction ($\beta \approx 0.015$). These fast fissions pull the core's overall effective delayed neutron fraction (β_{eff}) up to around 0.003 to 0.004, making the reactor more controllable.

4. **Reactivity Feedback:** Fast reactors lack a moderator, fundamentally altering how the core responds to temperature changes.

- **Prompt Doppler Feedback:** Fast reactors rely on the *Doppler Effect* for safety. While the magnitude of the Doppler reactivity insertion is relatively small (roughly $-10^{-5} \Delta k/k$ per $^{\circ}\text{C}$), it is a *prompt* effect. The ^{238}U resonance absorption peaks broaden the instant the fuel heats up, increasing neutron capture and halting a power excursion immediately.
- **Thermal Expansion Feedback (Leakage):** This is a primary passive safety mechanism in metallic-fueled reactors like EBR-II. When the metallic fuel pins and the core grid plate heat up, they physically expand. This expansion decreases the density of the fissile material and physically spreads the core out, increasing the probability that high-energy neutrons leak out of the core rather than causing fission. The combined axial and radial expansion provides a negative reactivity insertion (roughly -1×10^{-5} to $-2 \times 10^{-5} \Delta k/k$ per $^{\circ}\text{C}$) that transitions the reactor into a safe, hot equilibrium during an accident.
- **Magnitude and Time Constants vs. Thermal Reactors:** The total temperature coefficient in a fast reactor is roughly an order of magnitude smaller than the moderator temperature coefficient in a standard thermal reactor (which ranges from roughly -10^{-4} to $-5 \times 10^{-4} \Delta k/k$ per $^{\circ}\text{C}$). However, thermal reactors experience a thermal lag of several seconds because heat must conduct out of the ceramic oxide fuel and into the water moderator before the feedback takes effect. Fast reactor feedback is driven directly by the fuel itself (Doppler broadening and physical expansion), meaning the negative reactivity is inserted almost instantaneously.

5. **Fission Poisons:** The high-energy neutron spectrum eliminates the impact of standard fission product poisons.

- **Cross-Section Reductions:** In thermal reactors, fission products like Xenon-135 ($\sigma_a \approx 2.6 \times 10^6$ barns) are highly absorbing poisons. At fast energies, the absorption cross-sections for Xe-135 and Sm-149 are reduced by many orders of magnitude (fractions of a barn).

- **Tactical Implications (No Iodine Pit):** Thermal reactors often experience "Xenon dead-time" (the Iodine pit) after a power reduction or shutdown, where the buildup of Xe-135 from the decay of I-135 prevents the reactor from restarting for several hours. Because fast reactors are immune to Xenon poisoning, they do not experience dead-time or spatial power oscillations. For a naval vessel like the USS *Seawolf*, this provided a distinct tactical advantage, allowing the submarine to maneuver rapidly, shut down, and restart immediately without being restricted by core poisoning.

3 Fuel Composition and MOX

Because the fission cross-section collapses at high neutron energies, fast reactors cannot operate on the 3% to 5% enrichment used in Light Water Reactors. They require a much higher fissile density.

- **Beginning of Cycle (BOC):** A typical LMFR core requires roughly 15% to 30% fissile material (^{239}Pu or heavily enriched ^{235}U). The remainder is fertile ^{238}U . For a large commercial core, a typical split is $\approx 20\%$ ^{239}Pu and $\approx 80\%$ ^{238}U .
- **End of Cycle (EOC):** In a breeder configuration (Conversion Ratio ≈ 1.0), the reactor breeds new ^{239}Pu at the exact rate it consumes it. At EOC, the fissile ^{239}Pu fraction remains remarkably constant at $\approx 20\%$. However, the ^{238}U fraction drops by 5% to 10%, replaced entirely by the buildup of highly radioactive fission products.
- **MOX (Mixed-Oxide) Fuel:** Fast reactors are the ultimate consumers of MOX (PuO_2 blended with depleted UO_2 leftovers from enrichment). While a thermal water reactor can run on a MOX blend of just 5% to 7% Plutonium, a fast reactor requires a "Fast MOX" blend containing upwards of 20% to 25% Plutonium to sustain criticality.

4 Fuel Element Design: Oxides vs. Metallic Alloys

Operating in a fast neutron spectrum with liquid metal coolants requires distinct fuel element geometries and materials compared to standard thermal reactors.

4.1 Cladding Materials and Neutron Economy

While Light Water Reactors universally utilize Zircaloy for fuel cladding, fast reactors generally utilize stainless steels. This departure is driven by both neutron physics and thermomechanical limits.

- **Neutron Economy (The Fast Spectrum Advantage):** In a thermal reactor, the elements comprising stainless steel (Iron, Nickel, Chromium) have relatively high thermal neutron capture cross-sections, acting as parasitic absorbers that penalize the neutron economy. Zirconium is heavily favored in thermal reactors because its thermal capture cross-section is low. However, in a fast neutron spectrum, the absorption cross-sections for Iron, Nickel, and Chromium drop substantially. The fast spectrum allows engineers to utilize thick steel structural components without negatively impacting the chain reaction.
- **Thermomechanical Limits:** Zirconium alloys lose mechanical strength at the elevated operating temperatures of a liquid metal reactor (where coolant outlet temperatures often exceed 500°C) and can interact with impurities in liquid coolants. Therefore, fast reactor

fuel pins are clad in robust stainless steels (such as 316 austenitic stainless steel) or advanced ferritic-martensitic steels (like HT9) that resist radiation damage and maintain strength at high temperatures.

4.2 Oxide Fuel Pins

When utilizing Mixed-Oxide (MOX) fuel, the physical geometry resembles a standard thermal reactor. Cylindrical ceramic pellets are stacked inside the steel cladding tubes. Because the fast core must be compact to maintain criticality without a moderator, these fuel pins are narrower than standard PWR pins and are packed tightly into hexagonal assembly wrappers to optimize the coolant-to-fuel volume ratio.

4.3 Metallic Fuel Pins (The EBR-II Approach)

Metallic fuels, such as the Uranium-Plutonium-Zirconium (U-Pu-Zr) alloy used in EBR-II, offer superior thermal conductivity compared to ceramic oxides.

- **Geometry:** The core is not a monolithic metallic block with drilled coolant channels. Such a design would induce severe thermal gradients and present risks of flow blockage. Instead, the metallic fuel is cast into thin, solid cylindrical slugs that are placed inside standard steel cladding tubes, arranged in hexagonal bundles.
- **Irradiation Swelling:** A primary engineering challenge with metallic fuel is that it expands significantly as fission products accumulate. To accommodate this swelling without rupturing the steel cladding, the solid fuel slug is manufactured with a notably smaller diameter than the inner cladding wall (operating at roughly 75% smeared density).
- **The Sodium Bond:** To bridge this physical gap and ensure efficient heat transfer from the fuel slug to the cladding, the internal void space is filled with liquid sodium, known as a *sodium bond*. As the fuel undergoes irradiation, it swells outward through the sodium bond until it contacts the cladding. By the time it makes contact, the fuel matrix has become sufficiently porous to release accumulating fission gases into a dedicated upper plenum within the pin, relieving internal pressure.

5 Coolant Selection for the Fast Spectrum

To remove heat from a highly compact fast reactor core, the coolant must possess excellent thermal conductivity. Crucially, it must also have a low macroscopic moderating power (to avoid softening the fast neutron spectrum) and a low neutron absorption cross-section. Because water acts as a strong moderator, engineers typically turn to liquid metals or inert gases.

5.1 Primary Coolant Candidates

- **Liquid Sodium (Na):** The historical standard for most fast reactors.
 - *Advantages:* Excellent heat transfer properties, a relatively low melting point (98°C), and high material compatibility with stainless steel cladding.
 - *Disadvantages:* It is highly chemically reactive; it ignites in air and reacts exothermically with water. Furthermore, it activates under neutron flux into Sodium-24 ($^{24}\text{Na} \rightarrow ^{24}\text{Mg} +$

γ , $t_{1/2} \approx 15$ hours). This high-energy gamma emission necessitates an **Intermediate Loop** of non-radioactive sodium to isolate the primary coolant from the steam generator.

- **Sodium-Potassium Alloy (NaK):** Utilized frequently in early experimental fast reactors (such as EBR-I).
 - *Advantages:* The eutectic mixture is liquid at room temperature (melting at -12.6°C). This eliminates the need for the external heating trace lines required to keep pure sodium liquid during reactor shutdowns.
 - *Disadvantages:* It is even more chemically reactive than pure sodium, and it possesses slightly lower thermal conductivity and heat capacity.
- **Lead and Lead-Bismuth Eutectic (LBE or Pb-Bi):**
 - *Advantages:* Heavy liquid metals are chemically inert with air and water, eliminating the fire and reaction risks associated with sodium. They also have exceptionally high boiling points and provide intrinsic gamma shielding.
 - *Disadvantages:* The fluid is highly dense, placing elevated structural and seismic loads on the reactor vessel. It is corrosive to standard steels at high temperatures, requiring strict coolant oxygen control to maintain a protective oxide layer on the cladding. Additionally, LBE freezes at 125°C , and the Bismuth captures neutrons to become Polonium-210, an alpha emitter that complicates maintenance.
- **Helium (He):** The primary choice for proposed Gas-Cooled Fast Reactors (GFR).
 - *Advantages:* Helium is a noble gas, meaning it is chemically inert and completely transparent to neutrons (virtually zero moderation or absorption). It operates in a single phase, eliminating boiling concerns.
 - *Disadvantages:* Gases have low heat capacity compared to liquid metals. Removing heat from a high-power-density fast core requires operating the helium at very high pressures with active pumping. Managing decay heat during a depressurization accident presents a significant engineering challenge. While it looks promising on paper, no commercial scale GFR has been constructed due to this LOCA issue.

Historical Tangent: The Soviet Liquid-Metal Submarines

The Soviet Union utilized **Lead-Bismuth Eutectic (LBE)** to avoid the water-reactive hazards of sodium, culminating in the *Alfa*-class (Project 705 Lira) submarines. Lacking the thick shielding and massive pressure vessel required for a water reactor, the *Alfa* was notably light, allowing it to reach speeds exceeding 40 knots.

However, the high freezing point of LBE (125°C) created strict operational limits. If the reactor shut down and the primary pumps lost power to their external heating coils, the coolant loop would freeze solid. This phase-change occurred in the experimental K-27 submarine in 1968, solidifying the primary loop and rendering the core unrecoverable.

6 Core Architecture: Loop vs. Pool Design

Liquid metal fast reactors generally employ one of two primary mechanical layouts to circulate coolant between the core and the intermediate heat exchangers.

- **Loop-Type Design:** In this architecture, the reactor pressure vessel contains only the core and the immediate control structures. The primary liquid metal coolant is pumped out of the vessel through external piping to an Intermediate Heat Exchanger (IHX) and then returned to the core.
 - *Historical Context:* This design was utilized in early fast reactors (such as the mercury-cooled *Clementine*), early naval reactors (the USS *Seawolf* and Soviet *Alfa* class), and test facilities like the US Fast Flux Test Facility (FFTF).
 - *Advantages:* The loop design is highly compact, making it suitable for naval applications. It also physically separates the pumps and heat exchangers from the high-radiation environment of the core, simplifying maintenance.
 - *Disadvantages:* The presence of external primary coolant piping introduces the risk of a primary pipe break, which could lead to a Loss of Coolant Accident (LOCA).
- **Pool-Type (Integral) Design:** In this architecture, the reactor core, the primary coolant pumps, and the Intermediate Heat Exchangers are all submerged together within a single, large reactor vessel filled with liquid sodium (or lead).
 - *Modern Context:* Pioneered successfully by EBR-II, this is the architecture of choice for most modern commercial fast reactor designs, including the Russian BN-series, GE-Hitachi's PRISM, and TerraPower's Natrium.
 - *Advantages:* Because all primary coolant remains inside a single low-pressure vessel, the risk of an external primary pipe break (LOCA) is virtually eliminated. Furthermore, the large volume of liquid metal provides substantial thermal inertia; in the event of a pump failure, the pool can absorb decay heat for extended periods without boiling.
 - *Disadvantages:* The reactor vessel must be significantly larger and heavier, increasing capital costs and seismic design complexity. Maintenance is also more challenging, as components must be extracted directly from the primary sodium pool.

7 The Economics and Thermodynamics of Fast Reactors

Before examining the history of fast reactors, it is necessary to understand the economic and engineering trade-offs that drove their development and eventual stagnation.

7.1 The Thermodynamic Advantages

Liquid metal coolants operate at significantly higher temperatures than pressurized water, yielding two primary benefits:

- **Electrical Efficiency:** While a standard Light Water Reactor (LWR) operates at roughly 300°C yielding a thermal efficiency of $\approx 33\%$, a Sodium Fast Reactor (SFR) operates at or above 500°C. This higher temperature allows for a more efficient Rankine cycle, pushing the plant's overall thermal efficiency closer to 40%.
- **Industrial Process Heat:** Many chemical and industrial processes (such as ammonia production, petroleum refining, and hydrogen generation) require heat exceeding 320°C. A standard LWR cannot provide this, but a high-temperature fast reactor can supply this process heat directly without relying on fossil fuels.

7.2 The Economic Penalties

- **The Intermediate Loop Capital Cost:** A standard PWR is a two-loop system (Primary Water → Secondary Steam). Because radioactive primary sodium reacts violently with water, an SFR requires a **three-loop system** (Primary Sodium → Intermediate Non-Radioactive Sodium → Tertiary Steam). This extra loop requires an additional set of heat exchangers, pumps, and heavily shielded piping, significantly increasing construction and maintenance costs.
- **The Uranium Market:** The push for fast breeder reactors in the 1960s and 70s was driven by a fear of "Peak Uranium." Engineers believed global uranium reserves were scarce, making a reactor that bred its own fuel an economic necessity. However, as large, easily accessible uranium deposits were discovered globally, enriched uranium became inexpensive. The fuel-cycle savings of a breeder could no longer offset its high capital construction costs.

7.3 Proliferation Concerns and the Fuel Cycle

The historical pursuit of fast breeder reactors raised significant international proliferation concerns, primarily due to the fuel cycle required to support them.

- **Enrichment vs. Reprocessing:** Producing weapons-grade uranium requires complex, energy-intensive isotope separation (such as gas centrifuges) because U-235 and U-238 are chemically identical. Conversely, Plutonium is a distinct chemical element from the Uranium it is bred from. Therefore, Plutonium can be extracted from spent nuclear fuel using standard chemical processes (like PUREX), representing a significantly lower technological barrier to obtaining weapons-usable material.
- **The Breeder Requirement:** The economic premise of a fast breeder reactor relies on a "closed" fuel cycle. To realize the benefit of breeding, the spent fuel must be chemically reprocessed to extract the newly created Plutonium, which is then fabricated into fresh MOX or metallic fuel. Widespread commercialization of breeder reactors would require widespread commercial reprocessing infrastructure, inherently increasing the global risk of nuclear material diversion.
- **The US Policy Shift (Clinch River):** These specific proliferation concerns, coupled with the discovery of abundant global uranium reserves and substantial project cost overruns, ultimately led the United States to abandon its commercial breeder program. The flagship Clinch River Breeder Reactor project was officially cancelled in 1983 as the US explicitly pivoted away from the commercial reprocessing of plutonium. The reactor, despite having some 70% of the equipment delivered or ordered at the time, was never finished.
- **The Heavy Water Alternative (The India Example):** It is important to note that fast reactors are not strictly necessary to breed weapons-grade Plutonium. Heavy water reactors (such as the Canadian CANDU design) operate on natural, unenriched uranium and possess online refueling capabilities. This allows operators to insert U-238, irradiate it just long enough to breed Pu-239, and extract it before it absorbs additional neutrons to become Pu-240 (an isotope that complicates weapon design). India utilized a heavy water research reactor (the CIRUS reactor, provided by Canada) to produce the plutonium for its 1974 nuclear test, demonstrating that proliferation risks are tied primarily to the existence of chemical reprocessing capabilities rather than the fast reactor itself.

8 The Historical Arc: Pioneers, Failures, and Renaissance

8.1 The Pioneers: EBR-I and the USS Seawolf (Loop Systems)

- **EBR-I (1951):** The Experimental Breeder Reactor I in Idaho was a NaK-cooled **loop-type** reactor utilizing metallic uranium fuel. It holds the historical distinction of being the first nuclear reactor in the world to generate usable electricity.
- **The S2G Naval Reactor:** In the 1950s, Admiral Rickover pursued a sodium-cooled reactor for the second nuclear submarine, the USS *Seawolf* (SSN-575). The S2G was a **loop-type** reactor. It utilized Beryllium as a partial moderator, making it an **epithermal (intermediate) spectrum** reactor.
- **The Pivot:** The *Seawolf* operated successfully for over two years. However, sodium-water reactions in the steam superheaters forced operators to bypass them, reducing power output. The difficulties of maintaining radioactive liquid metal in a confined hull compared unfavorably to the highly reliable standard PWR in the USS *Nautilus*. Driven by a desire for fleet standardization, the S2G was removed in 1959 and replaced with a PWR. Similarly, the last Soviet *Alfa*-class submarine was taken out of service in 1996. No submarines currently employ LMFR technology.

8.2 The Commercial Giant: Superphénix (Pool / Fast)

In the 1970s and 80s, fearing a global uranium shortage, France pushed to commercialize the fast breeder reactor, culminating in the 1,200 MWe Superphénix.

- **Architecture and Fuel:** To avoid the primary pipe-break vulnerability of a loop system, Superphénix was designed as a **pool-type** reactor utilizing ceramic **MOX fuel**. Over 3,000 tons of liquid sodium filled the primary vessel.
- **The Engineering Failure:** Superphénix demonstrated that scaling up a pool-type reactor introduces notable mechanical complexities. The large rotating steel plugs required to move fuel under the opaque sodium warped over time. Furthermore, the complex secondary sodium loops suffered from severe leaks. It achieved a lifetime capacity factor of less than 8% before being permanently shut down in 1998.

8.3 Accidents and Cancellations

- **Flow Blockage at Enrico Fermi Unit 1 (1966):** At this commercial fast breeder near Detroit, the flow of liquid sodium dislodged a zirconium deflector plate from the bottom of the vessel. The plate was swept up and pinned against two fuel assemblies, blocking the sodium flow. Due to the high power density, the fuel in those assemblies rapidly melted.
- **Sodium Fire: The Monju Cover-Up (1995):** At Japan's Monju loop-type reactor, a thermometer broke due to fluid vibrations. Liquid sodium poured out at 500°C, igniting in the air and reacting with humidity to produce toxic sodium hydroxide smoke. Because the leak occurred in the intermediate secondary loop, there was no radioactivity release—validating the safety necessity of the three-loop architecture. However, the operating agency attempted to conceal the extent of the damage by editing security footage, causing a scandal that severely impacted the Japanese fast reactor program.

8.4 The "Nuclear Winter" and Knowledge Loss

Following these high-profile failures and the general stagnation of the global nuclear industry in the late 20th century, fast reactor development effectively stalled. As noted by the IAEA, this decades-long gap in new construction led to a critical loss of tacit engineering knowledge. The original generation of scientists and operators who designed and ran the first liquid metal reactors largely retired or passed away. Because practical, hands-on experience with managing liquid sodium systems is incredibly difficult to pass down purely through documentation, the industry faced a severe "brain drain" before a new generation could be trained.

8.5 The Scientific Success: EBR-II (Pool / Fast)

While commercial breeders struggled, the US Experimental Breeder Reactor II (EBR-II) at Idaho National Laboratory ran with high reliability for 30 years (1964–1994), proving the concept of *Inherent Passive Safety*.

- **Architecture and Fuel:** EBR-II utilized a **pool-type** architecture combined with **metallic fuel** (U-Pu-Zr alloy).
- **The SHRT-45R Test (1986):** Engineers intentionally shut off the primary cooling pumps at full power and disabled the control rods (Loss of Flow Without Scram).
- **Hot Equilibrium vs. Cold Shutdown:** As fission power dropped, the substantial thermal inertia of the sodium pool absorbed the decay heat. The reactor settled into a hot, low-power equilibrium where natural convection matched the heat output, shutting itself down through physics. *Crucially, passive safety does not achieve a cold shutdown.* The reactor parked itself safely in a hot state without melting, providing operators an extended response time. To fully cool the reactor, operators still had to manually insert the control rods.
 - **The Necessity of Metallic Fuel:** The success of the EBR-II safety tests relied on the use of metallic fuel rather than ceramic MOX fuel. Metallic fuel has a higher coefficient of thermal expansion and higher thermal conductivity.
 - **Behavior During the Transient:** When the primary pumps were shut off, the excellent thermal conductivity of the metallic fuel allowed the pins to heat uniformly and expand almost instantly. This rapid physical elongation pushed the fissile atoms apart and increased neutron leakage, providing the immediate negative reactivity required to shut down the chain reaction.
 - **The Oxide Contrast:** If the core had been loaded with MOX, the ceramic fuel would not have expanded sufficiently to halt the transient through leakage alone. The reactor would have relied primarily on Doppler feedback, and the poor thermal conductivity of the ceramic would have resulted in significantly higher peak fuel temperatures, threatening cladding integrity.

8.6 The Modern Era: TerraPower's Sodium (Pool / Fast)

Today, the fast reactor is returning, not to breed plutonium, but to integrate with variable renewable energy. TerraPower is currently constructing the **Sodium** reactor in Kemmerer, Wyoming.

- **Architecture:** Sodium is a 345 MWe **pool-type** Sodium Fast Reactor, utilizing metallic High-Assay Low-Enriched Uranium (HALEU) fuel to capitalize on the exact passive safety physics proven by EBR-II.

- **The Innovation (Thermal Decoupling):** Past reactors often struggled with the mechanical integration of the nuclear island and the steam generation loops. Sodium physically decouples them. The reactor runs continuously at 100% power, transferring its heat into large Molten Salt thermal energy storage tanks.
- **Grid Following:** When wind or solar generation drops, the molten salt system can boil water and boost the plant's electrical output to 500 MWe for over five hours, acting as a thermal battery to meet peak grid demand.
- **Current Construction Status:** The project is actively underway. TerraPower officially broke ground on the non-nuclear facilities (such as the testing facility) in June 2024. In a historic milestone in March 2026, the US Nuclear Regulatory Commission (NRC) officially issued the construction permit for the nuclear island—the first permit granted for a commercial non-light-water reactor in over 40 years. The plant is currently targeting commercial operation by 2031.

References and Further Reading

- **U.S. Nuclear Regulatory Commission (NRC):** "Sodium-Cooled Fast Reactor (SFR) Technology and Safety Overview." (Excellent diagrams of the loop and safety systems).
<https://www.nrc.gov/docs/ML1504/ML15043A307.pdf>
- **World Nuclear Association:** "Fast Neutron Reactors." (Comprehensive overview of global fast reactor history and physics).
<https://world-nuclear.org/information-library/current-and-future-generation/fast-neutron.aspx>
- **Historical Context:** "The History of the USS Seawolf (SSN-575)." (Details on the S2G Sodium reactor issues).
<https://www.history.navy.mil/research/histories/ship-histories/danfs/s/seawolf-ii.html>
- **Wikipedia:** "Breeder reactor" (Nice summary of the breeder reactor concept with many references and a good diagram of the actinides produced in the core).
https://en.wikipedia.org/wiki/Breeder_reactor
- **Wikipedia:** "Fast neutron reactor" (Nice summary of the history and types of fast neutron reactors concept with many references).
https://en.wikipedia.org/wiki/Fast-neutron_reactor
- **Monju Accident:** IAEA INIS Repository. "Sodium leak at Monju (I): Cause and consequences." (Detailed engineering breakdown of the thermocouple failure and fire).
<https://inis.iaea.org/records/95xh9-s8868>
- **Enrico Fermi Unit 1 Melt-Down Mechanics:** U.S. NRC. "Overview of Past US SFR Operations Experience." (Contains a detailed engineering autopsy of the October 1966 accident, showing how a loose Zirconium liner plate blocked the assembly inlet nozzles).
<https://www.nrc.gov/docs/ML1914/ML19149A438.pdf>

- **EBR-II Design and Passive Safety Data:** Argonne National Laboratory. "Benchmark Specifications and Data Requirements for EBR-II Shutdown Heat Removal Tests." (An exhaustive, 200+ page engineering breakdown of the core geometry, materials, and the actual data from the 1986 SHRT-45R unprotected loss-of-flow test).
<https://publications.anl.gov/anlpubs/2012/06/73647.pdf>
- **TerraPower Natrium Architecture:** TerraPower. "Application of Natrium Sodium Fast Reactor Plants to Supply Heat and Power." (Technical report detailing the 840 MWt pool-type core design, operating temperatures, and the thermal energy storage schematics).
<https://www.terrapower.com/downloads/Process-Heat.pdf>