

current



High electrical
potential energy

Battery



Resistor

Low electrical
potential energy

Ammeter

break in the
original wire