

rough current indicator

rough voltage indicator

DC POWER SUPPLY 0-30 V 0-3 A

0.00 A

05.0 V

voltage coarse
adjust knob

voltage fine
adjust knob

current limiter
adjust knob

power switch



POWER



negative voltage out

chassis
ground

positive voltage out