
## Wood wing construction with CF/balsa replacement sparcaps

1) Laminate CF onto hard balsa



2) Cut up to make sparcap strips



3) Sand down balsa side of strips

Stock hardwood sparcaps used as depth sanding guides

4) Build normally, using wood glue

