## **NES Controller**

ID0 = Left

ID1 = Right

ID2 = Up

ID3 = Down

ID4 = A

ID5 = B

ID6 = Select

ID7 = Start

## **Playstation Controller**

ID0 = Left

ID1 = Right

ID2 = Up

ID3 = Down

ID4 = X

ID5 = Circle

ID6 = Triangle

ID7 = Square

ID8 = R1

ID9 = R2

ID10 = L1

ID11 = L2

IDTT - LZ

ID12 = Select ID13 = Start

ID14 = Left joystick left

ID15 = Left joystick right

ID16 = Left joystick up

ID17 = Left joystick down

ID18 = Right joystick left

ID19 = Right joystick right

ID20 = Right joystick up

ID21 = Right joystick down

## **Gamecube Controller**

ID0 = A

ID1 = B

ID2 = X

ID3 = Y

ID4 = Start

ID5 = Joystick left

ID6 = Joystick right

ID7 = Joystick up

ID8 = Joystick down