0This document explains how to set up the buffalo in a different way than the two previous recommendations. The 3 benefits of this method are:

- Don't need to adjust anything when moving between wifi networks (e.g. home vs. on campus)
- Can browse the internet as usual while ssh'ed into the pi
- Don't need to carry buffalo on board the duckiebot

Instructions

Reset buffalo using pencil Plug buffalo into laptop's ethernet and usb Switch buffalo into 2.4 GHz mode

Log into Buffalo wifi on your laptop (e.g. Buffalo-G-772A, could still be <vehicle>-5)
Password is either <u>from scuderia</u> as the buffalo default, or still quackquack if set up earlier
Now that you're connected to your buffalo's wifi, go to 192.168.13.1 in a browser
Username/password are admin/scuderia numbers

Click the 3rd option - (wireless access point?)
Ssid <vehicle>-2
Password quackquack
Other stuff keep default
Reboot now

After reboot finishes, unplug buffalo from laptop

Directly connect to pi using ethernet from laptop (as done in previous labs)

Ssh into pi

Pi \$ sudo nano /etc/wpa_supplicant/wpa_supplicant.conf

Replace duckietown network with the one your buffalo is going to transmit

That is, replace ssid="duckietown" with ssid="<vehicle>-2"

Leave the other stuff the same (scan_ssid, psk, priority)

Plug canakit wifi dongle into pi

Shutdown pi

Unplug ethernet cord from laptop

Plug buffalo into laptop usb and ethernet

Share ethernet connection with buffalo just like when sharing direct connection to pi

Connect to any wifi network on the laptop

Power up the pi

Wait for 30sec or so

On laptop run \$ arp -e

A second ip address should show up (like 10.42.0.79 or something)

That is the pi

Laptop \$ ssh <vehicle>.local

You're in

You can use the internet on the laptop as usual and are wirelessly connected to the pi